



## Actuator controls ACV 01.2/ACVExC 01.2

Control  
Parallel  
Profibus DP  
→ Modbus RTU  
Modbus TCP/IP  
Profinet  
Foundation Fieldbus  
HART



**Read operation instructions first.**

- Observe safety instructions.

**Purpose of the document:**

This document contains information for the commissioning, operation and maintenance staff. It is intended to support local device operation and setting modifications.

**Reference documents:**

- Operation instructions (Assembly, operation, commissioning) for actuator.
- Manual (Device integration Fieldbus) actuator controls AC 01.2 Modbus

Reference documents can be downloaded from the Internet ([www.auma.com](http://www.auma.com)) or ordered directly from AUMA (refer to <Addresses>).

<b>Table of contents</b>	<b>Page</b>
<b>1. Safety instructions.....</b>	<b>9</b>
1.1. Prerequisites for the safe handling of the product	9
1.2. Range of application	10
1.3. Warnings and notes	10
1.4. References and symbols	10
<b>2. Short description.....</b>	<b>12</b>
<b>3. Operation.....</b>	<b>13</b>
3.1. Operating the actuator from local controls	13
3.2. Actuator operation from remote	14
3.3. Menu navigation via push buttons (for settings and indications)	14
3.3.1. Menu layout and navigation	15
3.4. User level, password	16
3.4.1. Password entry	17
3.4.2. Password change	17
3.4.3. Timeout for incorrect password entry	18
3.5. Language in the display	18
3.5.1. Language change	18
<b>4. Indications.....</b>	<b>19</b>
4.1. Indications during commissioning	19
4.2. Indications in the display	19
4.2.1. Feedback signals from actuator and valve	20
4.2.2. Status indications according to AUMA classification	22
4.2.3. Status indications according to NAMUR recommendation	23
4.3. Indication lights of local controls	25
4.3.1. Indication lights: change colour	25
<b>5. Signals (output signals).....</b>	<b>27</b>
5.1. Signals via fieldbus	27
5.2. Status signals via output contacts (digital outputs)	27
5.2.1. Assignment of outputs	27
5.2.2. Coding the outputs	27
5.3. Configurable status signals	27
5.4. Analogue signals (analogue outputs)	28
5.4.1. Assignment of analogue output 1	28

5.4.2.	Signal range of analogue output 1	29
5.4.3.	Adjustment of analogue output 1	30
5.4.4.	Assignment of analogue output 2	30
5.4.5.	Signal range of analogue output 2	30
5.4.6.	Adjustment of analogue output 2	30
<b>6.</b>	<b>Operation .....</b>	<b>32</b>
6.1.	Operation mode Off	32
6.2.	Operation mode Local	32
6.2.1.	Push-to-run operation or self-retaining Local	32
6.3.	Operation mode remote	33
6.3.1.	Push-to-run operation or self-retaining Remote	33
6.4.	Operation mode EMERGENCY	34
6.5.	Operation mode EMERGENCY stop	34
6.6.	Operation mode Disabled	35
6.7.	Operation mode Service	35
<b>7.</b>	<b>Basic settings for commissioning.....</b>	<b>36</b>
7.1.	Type of seating for end positions	36
7.1.1.	Type of seating: set	36
7.2.	Torque switching	37
7.2.1.	Torque switching: set	38
7.3.	Limit switching	39
7.3.1.	Limit switching: set	39
7.3.2.	End position setting via stroke	41
7.4.	Date and time	44
7.5.	Display formats	44
7.5.1.	Date format	44
7.5.2.	Time format	45
7.5.3.	Number format	45
7.5.4.	Torque unit	45
7.5.5.	Temperature unit	45
7.5.6.	Position units	45
7.5.7.	Process factor units	46
7.5.8.	Analogue working value units (AIN)	47
7.5.9.	Analogue signal output units (AOUT)	47
7.6.	Contrast	48
<b>8.</b>	<b>Application functions.....</b>	<b>49</b>
8.1.	Speed functions	49
8.1.1.	Speed source for local operation and remote operation	49
8.1.2.	Speed for constant (internal) speed setpoint: set	50
8.1.3.	Speed range for analogue input: set	51
8.1.4.	Time for speed increase and time for speed reduction at pivot points	51
8.1.5.	Speed reduction before reaching end positions OPEN/CLOSED (soft stop in end positions)	52
8.2.	Speed profile	53
8.2.1.	Speed profile: activate	53
8.2.2.	Operation mode for speed profile: set	54
8.2.3.	Pivot points for speed profile: define	54
8.3.	Intermediate positions	56
8.3.1.	Intermediate positions of pivot points: define	57

8.3.2.	Signal behaviour of intermediate positions: set	57
8.3.3.	Hysteresis for intermediate positions: set	58
8.4.	Operation profile (operation behaviour) for intermediate positions	58
8.4.1.	Operation profile: activate	59
8.4.2.	Operation profile for intermediate positions (pivot points): set	59
8.4.3.	Off times for intermediate positions (pivot points): set	60
8.5.	Two-wire control	60
8.6.	Positioner (operation mode Remote SETPOINT)	60
8.6.1.	Positioner: activate	61
8.6.2.	Adaptive behaviour: activate deactivate	61
8.6.3.	Overrun (inner dead band): set manually	62
8.6.4.	Max. error variable (outer dead band): set manually	62
8.6.5.	Dead time: set	63
8.6.6.	Hysteresis for positioner: set	63
8.6.7.	Closing fully/opening fully (end position tolerance for setpoint)	63
8.6.8.	Setting range: limit	63
8.6.9.	Speed reduction before reaching setpoint position	64
8.6.10.	Change-over between OPEN - CLOSE control and setpoint control	65
8.6.11.	Input of setpoint position	66
8.6.12.	Input range of setpoint position	66
8.6.13.	Split Range operation	66
8.7.	Process controller	67
8.7.1.	Process controller activation	68
8.7.2.	Process controller: set modulating behaviour	68
8.7.3.	Setpoint source (input for process setpoint)	69
8.7.4.	Behaviour on loss of process setpoint	70
8.7.5.	Inverse operation	70
8.7.6.	Internal process setpoint	70
8.7.7.	Setting procedure	71
8.7.8.	Proportional gain Kp: set	71
8.7.9.	Reset time Ti: set	71
8.7.10.	Rate time Td: set	71
8.7.11.	Actual value source (input for actual process value)	72
8.7.12.	Speed source for actual process value	72
8.8.	Stepping mode	72
8.8.1.	Stepping mode: activate	73
8.8.2.	Operation mode for stepping mode	73
8.8.3.	Start and end of stepping mode	74
8.8.4.	On times and off times	74
8.9.	Modbus interface	74
8.9.1.	Bus address (slave address)	74
8.9.2.	Baud rate	75
8.9.3.	Parity/stop bit	75
8.9.4.	Monitoring time	75
8.9.5.	Response timeout	75
8.9.6.	Redundancy	76
8.9.7.	Response telegrams for AUMA redundancy II	76
8.10.	Additional inputs for fieldbus	76
8.11.	Combination of fieldbus-parallel interface	77
8.12.	Auto change-over I/O (during fieldbus failure)	78

8.13.	Functions for FO cable connection	78
8.13.1.	FO cable monitoring: activate/deactivate	78
8.13.2.	FO cable topology: check setting	79
8.13.3.	FO cable baud rate, check setting	79
8.14.	By-pass function	79
8.14.1.	By-pass function: activate	81
8.14.2.	By-pass application: configure	81
8.15.	Automatic deblocking	81
8.15.1.	Automatic deblocking function: activate	82
8.15.2.	Operation time for operation in opposite direction: set	82
8.15.3.	Number of deblocking attempts: set	82
8.15.4.	Tolerance range: set	83
8.16.	Heater system and heaters	83
8.16.1.	Heater system within the actuator controls	83
8.16.2.	Heater on control unit (actuator)	83
8.16.3.	Motor heater	84
<b>9.</b>	<b>Failure functions.....</b>	<b>85</b>
9.1.	Reversing prevention time	85
9.2.	Failure behaviour on loss of signal	85
9.2.1.	Failure reaction on loss of signal	85
9.2.2.	Failure source (failure reason) for a failure operation: set	86
9.2.3.	Failure operation (reaction of the actuator) on loss of signal	86
9.2.4.	Preset position: define	87
9.2.5.	Failure position MPV: define	87
9.2.6.	Speed for safety operation: set	87
9.2.7.	Delay time: set	88
9.3.	EMERGENCY behaviour	88
9.3.1.	EMERGENCY behaviour: activate	89
9.3.2.	EMERGENCY failure reaction	90
9.3.3.	Failure source (failure reason) for an EMERGENCY operation: set	90
9.3.4.	Operation mode for EMERGENCY behaviour	90
9.3.5.	EMERGENCY operation	91
9.3.6.	EMERGENCY position	91
9.3.7.	EMERGENCY position MPV	91
9.3.8.	EMERGENCY speed	91
9.3.9.	Torque switching: by-pass	92
9.3.10.	Motor protection: by-pass	92
9.3.11.	Stepping mode: by-pass	92
9.3.12.	Operation profile: by-pass	92
9.3.13.	Interlock: by-pass	93
9.3.14.	Local stop: by-pass	93
9.3.15.	Speed profile: by-pass	93
9.3.16.	Delay time for EMERGENCY operation	94
9.4.	Enable local controls	94
9.4.1.	Enabling function: activate	95
9.4.2.	Enabling function behaviour	95
9.5.	Priority REMOTE	95
9.5.1.	Priority REMOTE: activate	96
9.5.2.	Priority REMOTE behaviour	96
9.5.3.	Fieldbus auto enable	97

9.6.	Interlock (enabling operation commands)	97
9.6.1.	Interlock: activate	98
9.6.2.	Source of Interlock enable signal: set	98
9.6.3.	Operation mode for interlock	98
9.6.4.	Interlock behaviour (running direction)	98
9.7.	Local Stop	99
9.7.1.	Behaviour	99
9.8.	EMERGENCY stop function	99
9.9.	Partial Valve Stroke Test (PVST)	100
9.9.1.	PVST activation	101
9.9.2.	PVST source: set	101
9.9.3.	Operation mode for PVST	101
9.9.4.	Behaviour for PVST: define	102
9.9.5.	Partial stroke for PVST: set	102
9.9.6.	PVST monitoring time: set	102
9.9.7.	PVST operating time: set	102
9.9.8.	PVST reversing time: set	102
9.9.9.	PVST reminder	103
9.9.10.	Speed for PVST: set	103
9.10.	Bluetooth interface can be activated and deactivated	103
<b>10.</b>	<b>Monitoring functions .....</b>	<b>107</b>
10.1.	Torque monitoring	107
10.1.1.	Torque by-pass	107
10.1.2.	Torque limitation of torque by-pass	108
10.2.	Motor protection monitoring (thermal monitoring)	109
10.3.	Type of duty monitoring (motor starts and running time)	109
10.4.	Operating time monitoring	111
10.5.	Reaction monitoring	111
10.6.	Motion detector	112
10.6.1.	Activate motion detector	112
10.6.2.	Detection time dt	112
10.6.3.	Travel difference dx	113
10.6.4.	Delay time	113
10.7.	Monitoring of electronics power supply	113
10.8.	Temperature monitoring	114
10.9.	Heater system/heater monitoring	114
10.10.	Verification of sub-assemblies	115
10.11.	Phase failure monitoring	115
<b>11.</b>	<b>Functions: activate and enable.....</b>	<b>117</b>
11.1.	Functions: activate	117
11.2.	Functions: enable	117
<b>12.</b>	<b>Product variants.....</b>	<b>119</b>
12.1.	Multiport valve	119
12.1.1.	Actuator type: set/check	119
12.1.2.	Gear reduction ratio: set/check	119
12.1.3.	Number of ports (positions)	120
12.1.4.	Home port (zero position): set	120
12.1.5.	Positions (of valve ports): define/check	121
12.1.6.	Operate to position via push buttons of the local controls	121

12.1.7.	Operate to position from Remote	123
12.1.8.	Dead band	124
12.1.9.	Correction of inertia	124
12.1.10.	Backlash compensation	124
12.1.11.	Signalling behaviour of positions: set/check	124
12.1.12.	Hysteresis for signalling intermediate positions: set	125
<b>13.</b>	<b>Service functions.....</b>	<b>126</b>
13.1.	Direction of rotation	126
13.2.	Factory setting	126
13.3.	Languages: reload	127
13.4.	Data export	127
13.5.	Data import	127
13.6.	Actual configuration: accept	128
13.7.	Firmware update	128
13.8.	Service software	128
<b>14.</b>	<b>Diagnostics.....</b>	<b>130</b>
14.1.	Electronic device ID	130
14.2.	Bluetooth connection diagnostic	130
14.3.	Diagnostic Interface	131
14.4.	Position transmitter and potentiometer diagnostic	132
14.5.	Diagnostic Position transmitter RWG	132
14.6.	Diagnostic Position transmitter MWG	133
14.7.	Diagnostic Positioner	133
14.8.	Diagnostic On time monitoring	133
14.9.	Diagnostic Process controller	134
14.10.	Modbus interface: diagnostic	134
14.11.	Diagnostic FO cable	134
14.12.	Simulation (inspection and test function)	134
14.12.1.	Actuator signals	134
14.12.2.	Interface signals	135
<b>15.</b>	<b>Asset Management.....</b>	<b>136</b>
15.1.	Operating data	136
15.2.	Event report	137
15.3.	Characteristics	138
15.3.1.	Torque-travel characteristic	138
15.3.2.	Position-time characteristic	140
15.3.3.	Temperature-time characteristic	141
15.4.	Histograms	141
15.4.1.	Motor running time-position (histogram)	141
15.4.2.	Motor running time-temperature (histogram)	142
15.4.3.	Motor running time-torque (histogram)	143
15.5.	Maintenance (information and signals)	143
15.6.	Operating times display	145
15.7.	Device temperature display	145
<b>16.</b>	<b>Corrective action.....</b>	<b>146</b>
16.1.	Primary fuses	146
16.2.	Fault indications and warning indications	146

---

<b>17.</b>	<b>Appendix.....</b>	<b>153</b>
17.1.	Selection overview for output contacts and indication lights (digital outputs DOUT)	153
17.2.	Selection list of binary signals for digital inputs (DIN)	156
	<b>Index.....</b>	<b>159</b>
	<b>Parameter index.....</b>	<b>163</b>



## 1. Safety instructions

### 1.1. Prerequisites for the safe handling of the product

<b>Standards/directives</b>	<p>The end user or the contractor must ensure that all legal requirements, directives, guidelines, national regulations and recommendations with respect to assembly, electrical connection, commissioning and operation are met at the place of installation. They include among others:</p> <ul style="list-style-type: none"> <li>Standards and directives such as IEC 60079 "Explosive atmospheres": <ul style="list-style-type: none"> <li>Part 14: Electrical installations design, selection and erection.</li> <li>Part 17: Electrical installations inspection and maintenance.</li> </ul> </li> <li>Applicable configuration guidelines for fieldbus applications.</li> </ul>
<b>Safety instructions/warnings</b>	<p>All personnel working with this device must be familiar with the safety and warning instructions in this manual and observe the instructions given. Safety instructions and warning signs on the device must be observed to avoid personal injury or property damage.</p>
<b>Qualification of staff</b>	<p>Assembly, electrical connection, commissioning, operation, and maintenance must be carried out by suitably qualified personnel authorised by the end user or contractor of the plant only.</p> <p>Prior to working on this product, the staff must have thoroughly read and understood these instructions and, furthermore, know and observe officially recognised rules regarding occupational health and safety.</p> <p>Work performed in potentially explosive atmospheres is subject to special regulations which have to be observed. The end user or contractor of the plant is responsible for respect and control of these regulations, standards, and laws.</p>
<b>Electrostatic charging</b>	<p>Highly efficient charge generating processes (processes more efficient than manual friction) on the device surface must be excluded at any time, since they will lead to propagating brush discharges and therefore to ignition of a potentially explosive atmosphere.</p> <p>This also applies to fireproof coatings or covers available as an option.</p>
<b>Ignition dangers</b>	<p>Gearboxes were subjected to an ignition hazard assessment in compliance with the currently applicable standard according to ISO 80079-36/ -37. Hot surfaces, mechanically generated sparks as well as static electricity and stray electric currents were identified and assessed as major potential ignition sources. Protective measures to prevent the likelihood that ignition sources arise were applied to the gearboxes. This includes in particular lubrication of the gearbox, the IP protection codes and the warnings and notes contained in these operation instructions.</p>
<b>Commissioning</b>	<p>Prior to commissioning, imperatively check that all settings meet the requirements of the application. Incorrect settings might present a danger to the application, e.g. cause damage to the valve or the installation. The manufacturer will not be held liable for any consequential damage. Such risk lies entirely with the user.</p>
<b>Operation</b>	<p>Prerequisites for safe and smooth operation:</p> <ul style="list-style-type: none"> <li>Correct transport, proper storage, mounting and installation, as well as careful commissioning.</li> <li>Only operate the device if it is in perfect condition while observing these instructions.</li> <li>Immediately report any faults and damage and allow for corrective measures.</li> <li>Observe recognised rules for occupational health and safety.</li> <li>Observe national regulations.</li> <li>During operation, the housing warms up and surface temperatures &gt; 60 °C may occur. To prevent possible burns, we recommend checking the surface temperature prior to working on the device using an appropriate thermometer and wearing protective gloves.</li> </ul>

<b>Protective measures</b>	The end user or the contractor are responsible for implementing required protective measures on site, such as enclosures, barriers, or personal protective equipment for the staff.
<b>Maintenance</b>	To ensure safe device operation, the maintenance instructions included in this manual must be observed. Any device modification requires prior written consent of the manufacturer.

## 1.2. Range of application

AUMA actuator controls are exclusively designed for the operation of AUMA actuators. Other applications require explicit (written) confirmation by the manufacturer. The following applications are not permitted, e.g.:

- motor control
- pump control

No liability can be assumed for inappropriate or unintended use.

Observance of these operation instructions is considered as part of the device's designated use.

## 1.3. Warnings and notes

The following warnings draw special attention to safety-relevant procedures in these operation instructions, each marked by the appropriate signal word (DANGER, WARNING, CAUTION, NOTICE).



**Indicates an imminently hazardous situation with a high level of risk. Failure to observe this warning results in death or serious injury.**




**Indicates a potentially hazardous situation with a medium level of risk. Failure to observe this warning could result in death or serious injury.**



**Indicates a potentially hazardous situation with a low level of risk. Failure to observe this warning could result in minor or moderate injury. May also be used with property damage.**



**Potentially hazardous situation. Failure to observe this warning could result in property damage. Is not used for personal injury.**

Safety alert symbol  warns of a potential personal injury hazard.

The signal word (here: DANGER) indicates the level of hazard.

## 1.4. References and symbols

The following references and symbols are used in these instructions:

**Information** The term **Information** preceding the text indicates important notes and information.



Symbol for CLOSED (valve closed)



Symbol for OPEN (valve open)



**Via the menu to parameter**

Describes the menu path to the parameter. When using the push buttons of local controls, the required parameter can be quickly found on the display. Display texts are shaded in grey: **Display**.

➔ **Result of a process step**

Describes the result of a preceding process step.

**Warning signs at the device**

The following warning signs can be attached to the device.



**General warning sign**

General warning of a danger zone.



**Hot surface**

Warning of hot surfaces, e.g. possibly caused by high ambient temperatures or strong direct sunlight.



**Electrical voltage**

Hazardous voltage! Warning of electric shock. At some devices, the warning sign additionally includes a time interval, e.g. 30 s. Once power supply is switched off, you will have to wait for the indicated period. Only then may the device be opened.

## 2. Short description

**Actuator controls** ACV 01.2/ACVExC 01.2 actuator controls are used to operate AUMA actuators and are supplied ready for use.

The functions of the actuator controls include standard valve control in OPEN-CLOSE duty, positioning, process control, logging of operating data, diagnostic functions right through control via various interfaces (e.g. Fieldbus, Ethernet and HART).

**Local controls/  
AUMA CDT** Operation, setting, and display can be performed directly at the actuator controls or alternatively from REMOTE via a fieldbus interface.

When set to local control, it is possible to

- operate the actuator via the local controls (push buttons and display) and perform settings (contents of these instructions).
- read in or out data or modify and save settings via AUMA CDT software (accessory), using a computer (laptop or PC). The connection between computer and actuator controls is wireless via Bluetooth interface (not included in these instructions).

### Intrusive - Non-Intrusive

- Intrusive version (control unit: electromechanical):  
Limit and torque setting is performed via switches in the actuator.
- Non-Intrusive version (control unit: electronic):  
Limit and torque setting is performed via the controls, without removal of actuator or actuator controls covers. For this purpose, the actuator is equipped with an MWG (magnetic limit and torque transmitter), also capable to supply analogue torque feedback signals/torque indication and analogue position feedback signals/position indication at the actuator controls output.

### 3. Operation

#### 3.1. Operating the actuator from local controls

Local actuator operation is performed using the local controls push buttons of actuator controls.

Figure 1: Local controls



- [1] Push button for operation command in direction OPEN
- [2] Push button STOP
- [3] Push button for operation command in direction CLOSE
- [4] Push button RESET
- [5] Selector switch


#### CAUTION

**Hot surfaces, e.g. possibly caused by high ambient temperatures or strong direct sunlight!**



*Risk of burns*

→ Verify surface temperature and wear protective gloves.

→ Set selector switch [5] to position **Local control** (LOCAL).



➔ The actuator can now be operated using the push buttons [1 – 3]:

- Run actuator in direction OPEN: Press push button [1] .
- Stop actuator: Press push button STOP [2].
- Run actuator in direction CLOSE: Press push button [3] .

#### Information

The OPEN and CLOSE operation commands can be given either in push-to-run or in self-retaining operation mode. In self-retaining mode, the actuator runs to the defined end position after pressing the button, unless another command has been received beforehand. For further information, please refer to the Manual (Operation and setting).

#### Information

The OPEN and CLOSE operation commands can be given either in push-to-run or in self-retaining operation mode. For further information, please refer to <Push-to-run operation or self-retaining local> chapter.

### 3.2. Actuator operation from remote


#### CAUTION

#### Risk of immediate actuator operation when switching on!

*Risk of personal injuries or damage to the valve*

- If the actuator starts unexpectedly: Immediately turn selector switch to **0** (OFF).
- Check input signals and functions.

- Set selector switch to position **Remote control** (REMOTE).



- ➔ Now, the actuator can be remote-controlled via fieldbus.


**Information** For actuators equipped with a positioner, it is possible to change over between **OPEN - CLOSE control** (Remote OPEN-CLOSE) and **setpoint control** (Remote SET-POINT). For further information, refer to chapter <Change-over between OPEN - CLOSE control and setpoint control>.

**Information** For actuators equipped with a positioner, it is possible to change over between **OPEN - CLOSE control** (Remote OPEN-CLOSE) and **setpoint control** (Remote SET-POINT). For further information, please refer to the Manual (Operation and setting).

### 3.3. Menu navigation via push buttons (for settings and indications)


Menu navigation for display and setting is made via the push buttons [1 – 4] of the local controls.

Set the selector switch [5] to position **0** (OFF) when navigating through the menu.



The bottom row of the display [6] serves as navigation support and explains which push buttons [1 – 4] are used for menu navigation.

Figure 2:



[1–4] Push buttons or navigation support

[5] Selector switch

[6] Display

Table 1: Important push button functions for menu navigation


Push buttons	Navigation support on display	Functions
[1] ▲	Up ▲	Change screen/selection
		Change values
		Enter figures from 0 to 9
[2] ▼	Down ▼	Change screen/selection
		Change values
		Enter figures from 0 to 9
[3] ↵	Ok	Confirm selection
	Save	Save
	Edit	Enter <Edit> menu
	Details	Display more details
[4] C	Setup	Enter Main menu
	Esc	Cancel process
		Return to previous display

- Backlight**
- The display is illuminated in white during normal operation. It is illuminated in red in case of a fault.
  - The screen illumination is brighter when operating a push button. If no push button is operated for 60 seconds, the display will become dim again.

3.3.1. Menu layout and navigation


**Groups** The indications on the display are divided into 3 groups:

Figure 3: Groups



**ID** Status menu and main menu are marked with an ID.


Figure 4: Marking with ID



**Group selection** It is possible to select between status menu **S** and main menu **M**:

For this, set selector switch to **0** (OFF), hold down push button **C** for approx. 2 seconds until a screen containing the ID **M...** appears.

Figure 5: Select menu groups




You return to the status menu if:

- the push buttons on the local controls have not been operated within 10 minutes
- or by briefly pressing **C**

**Direct display via ID**

When entering the ID within the main menu, screens can be displayed directly (without clicking through).

Figure 6: Direct display (example)



Display indicates in the bottom row: **Go to**


1. Press push button **▲ Go to**.  
Display indicates: **Go to menu M0000**
2. Use push buttons **▲▼ Up ▲ Down ▼** to select figures 0 to 9.
3. Press push button **↵ Ok** to confirm first digit.
4. Repeat steps 2 and 3 for all further digits.
5. To cancel the process: Press **C Esc**.

**3.4. User level, password**

**User level** The user level defines which menu items or parameters can be displayed or modified by the active user.

There are 6 different user levels. The user level is indicated in the top row:

Figure 7: User level display (example)



**Password** A password must be entered to allow parameter modification. The display indicates: **Password 0\*\*\***

A specific password is assigned to each user level and permits different actions.

Table 2:









User levels and authorisations	
Designation (user level)	Authorisation/password
Observer (1)	Verify settings No password required
Operator (2)	Change settings Default factory password: 0000
Maintenance (3)	Reserved for future extensions
Specialist (4)	Change device configuration e.g. type of seating, assignment of output contacts Default factory password: 0000
Service (5)	Service staff Change configuration settings
AUMA (6)	AUMA administrator

**Unauthorised access is made easier due to insecure password!**

→ We urgently recommend changing the password during initial commissioning.



### 3.4.1. Password entry

1. Select desired menu and hold down push button  for approx. 3 seconds.  
→ Display indicates the set user level, e.g. **Observer (1)**
2. Select higher user level via  **Up**  and confirm with  **Ok**.  
→ Display indicates: **Password 0\*\*\***
3. Use push buttons  **Up**  to select figures 0 to 9.
4. Confirm first digit of password via push button  **Ok**.
5. Repeat steps 1 and 2 for all further digits.  
→ Having confirmed the last digit with  **Ok**, access to all parameters within one user level is possible if the password entry is correct.

### 3.4.2. Password change

Only the passwords of same or lower access level may be changed.


Example: If the user is signed in as **Specialist (4)**, he/she can change passwords as for password levels (1) through (4).

**M ▶** **Device configuration M0053**  
**Service functions M0222**  
**Change passwords M0229**

Menu item **Service functions M0222** is only visible, if user level **Specialist (4)** or higher is selected.

#### Select main menu

1. Set selector switch to position **0** (OFF).




#### Change passwords

2. Press push button **C Setup** and hold it down for approx. 3 seconds.

→ Display goes to main menu and indicates: **▶ Display**

3. Select parameter **Change passwords** either:


- click via the menu **M ▶** to parameter, or
- via direct display: press  and enter ID **M0229**

- Display indicates: **▶ Change passwords**

- The user level is indicated in the top row (1 – 6), e.g.:



- For user level 1 (view only), passwords cannot be changed. To change passwords, you must change to a higher user level. For this, enter a password via a parameter.

4. For a user level between 2 and 6: Press push button  **Ok**.

→ The display indicates the highest user level, e.g.: **For user 4**

5. Select user level via push buttons  **Up**  and confirm with  **Ok**.

→ Display indicates: **▶ Change passwords Password 0\*\*\***

6. Enter current password (→ enter password).

→ Display indicates: **▶ Change passwords Password (new) 0\*\*\***

7. Enter new password (→ enter password).

→ Display indicates: **▶ Change passwords For user 4 (example)**

8. Select next user level via push buttons  **Up**  or cancel the process via **Esc**.

**3.4.3. Timeout for incorrect password entry**

A timeout for incorrect password entry is provided with actuator controls. This prevents unauthorised access by systematic trials. The timeout is active for incorrect entries via the local controls as well as incorrect entries via our software tools (AUMA CDT, AUMA Assistant App). After five subsequent incorrect trials, further entry is inhibited for one minute. Each further incorrect entry doubles the timeout period. An active timeout is displayed on the screen. An individual timeout is available for each user level. This means that you may still log on with user level 3 if user level 4 is inhibited.

The incorrect entry counter can be reset in two ways:

1. Correct password entry with successful access authorisation.
2. 8 hours after the last incorrect entry.


**3.5. Language in the display**

The display language can be selected.

**3.5.1. Language change**

M ▶ **Display M0009**  
**Language M0049**

- Select main menu** 1. Set selector switch to position **0** (OFF).



2. Press push button **C Setup** and hold it down for approx. 3 seconds.

➡ Display goes to main menu and indicates: ▶ **Display**

**Change language**

3. Press **↵ Ok**.

➡ Display indicates: ▶ **Language**

4. Press **↵ Ok**.

➡ Display indicates the selected language, e.g.: ▶ **Deutsch**

5. The bottom row of the display indicates:

- **Save** → continue with step 10
- **Edit** → continue with step 6

6. Press **↵ Edit**.

➡ Display indicates: ▶ **Observer (1)**

7. Select user level via **▲▼ Up ▲ Down ▼** resulting in the following significations:

- black triangle: ▶ = current setting
- white triangle: ▷ = selection (not saved yet)

8. Press **↵ Ok**.

➡ Display indicates: **Password 0\*\*\***

9. Enter password (→ enter password).

➡ Display indicates: ▶ **Language** and **Save** (bottom row)

**Language selection**

10. Select new language via **▲▼ Up ▲ Down ▼** resulting in the following significations:

- black triangle: ▶ = current setting
- white triangle: ▷ = selection (not saved yet)

11. Confirm selection via **↵ Save**.

➡ The display changes to the new language. The new language selection is saved.


4. Indications

4.1. Indications during commissioning

LED test

When switching on the power supply, all LEDs on the local controls illuminate for approx. 1 second. This optical feedback indicates that the voltage supply is connected to the controls and all LEDs are operable.

Figure 8: LED test




Language selection

During the self-test, the language selection can be activated so that the selected language is immediately indicated in the display. For this, set selector switch to position 0 (OFF).

Activate language selection:

1. Display indicates in the bottom line: **Language selection menu? 'Reset'**
2. Hold down push button **RESET** until display of the following text in the bottom line: **Language menu loading, please wait.**

Figure 9: Self-test



The language selection menu follows the startup menu.

Startup menu


The current firmware version is displayed during the startup procedure:

Figure 10: Startup menu with firmware version: 05.00.00–xxxx




If the language selection feature has been activated during the self-test, the menu for selecting the display language will now be indicated. For further information on language setting, please refer to chapter <Language in the display>.

Figure 11: Language selection




If no entry is made over a longer period of time (approx. 1 minute), the display automatically returns to the first status indication.

4.2. Indications in the display

 **Menus and functions depend on the actuator controls firmware version!**  
→ Should menus or functions be unavailable, please contact the AUMA Service.

**Status bar** The status bar (first row in the display) indicates the operation mode [1], the presence of an error [2] and the ID number [3] of the current display indication.


Figure 12: Information in the status bar (top)



- [1] Operation mode
- [2] Error symbol (only for faults and warnings)
- [3] ID number: S = Status page

**Navigation support** If further details or information are available with reference to the display, the following indications **Details** or **More** appear in the navigation support (bottom display row). Then, further information can be displayed via the push button.

Figure 13: Navigation support (bottom)



- [1] shows list with detailed indications
- [2] shows further available information

The navigation support (bottom row) is faded out after approx. 3 seconds. Press any push button (selector switch in position 0 (OFF)) to fade in the navigation support.

#### 4.2.1. Feedback signals from actuator and valve


Display indications depend on the actuator version.

##### Valve position (S0001)

This indication is only available if a position transmitter (potentiometer, EWG, RWG or MWG) is installed in the actuator.


- **S0001** on the display indicates the valve position in % of the travel.
- The bar graph display appears after approx. 3 seconds.
- When issuing an operation command, an arrow indicates the direction (OPEN/CLOSE).

Figure 14: Valve position and direction of operation



Reaching the preset end positions is additionally indicated via (CLOSED) and (OPEN) symbols.

Figure 15: End position CLOSED/OPEN reached




- 0% Actuator is in end position CLOSED
- 100% Actuator is in end position OPEN

### Torque (S0002)

- S0002 on the display indicates the torque applied at the actuator output.
- The bar graph display appears after approx. 3 seconds.


Figure 16: Torque



#### Select unit

The push button allows to select the unit displayed (percent %, Newton metre Nm or "foot-pound" ft-lb)

Figure 17: Units of torque



#### Display in percent

100 % indication equals the max. torque indicated on the name plate of the actuator.

Example: Torque range on name plate = 20 – 60 Nm.

- 100 % corresponds to 60 Nm of nominal torque.
- 50 % corresponds to 30 Nm of nominal torque.

### Operation commands (S0003)

The display S0003 indicates:


- active operation commands, like e.g.: Operation in direction CLOSE or in direction OPEN
- the actual value E2 as bar graph indication and as value between 0 and 100 %.
- for setpoint control (positioner): setpoint E1
- for stepping mode or for intermediate positions with operation profile: pivot points and operation behaviour of pivot points

The navigation support (bottom row) is faded out after approx. 3 seconds and the axis/axes for pivot point display are shown.

#### OPEN - CLOSE control

Active operation commands (OPEN, CLOSE, ...) are shown above the bar graph display. The figure below shows the operation command in direction CLOSE.

Figure 18: Display for OPEN - CLOSE control




E2 Actual position value

#### Setpoint control

If the positioner is enabled and activated, the bar graph indication for E1 (position setpoint) is displayed.

The direction of the operation command is displayed by an arrow above the bar graph indication. The figure below shows the operation command in direction CLOSE.

Figure 19: Indication for setpoint control (positioner)



#### Pivot point axis

The pivot points and their operation behaviour (operation profile) are shown on the pivot point axis by means of symbols.

The symbols are only displayed if at least one of the following functions is activated:

Operation profile M0294

Timer CLOSE M0156

Timer OPEN M0206

Figure 20: Examples: on the left pivot points (intermediate positions); on the right stepping mode



Table 3: Symbols along the pivot point axis

Symbol	Pivot point (intermediate position) with operation profile	Stepping mode
	Pivot point without reaction	End of stepping mode
◀	Stop during operation in direction CLOSE	Start of stepping mode in direction CLOSE
▶	Stop during operation in direction OPEN	Start of stepping mode in direction OPEN
◆	Stop during operation in directions OPEN and CLOSE	–
◁	Pause for operation in direction CLOSE	–
▷	Pause for operation in direction OPEN	–
◇	Pause for operation in directions OPEN and CLOSE	–

#### 4.2.2. Status indications according to AUMA classification


These indications are available if the parameter **Diagnostic classific. M0539** is set to **AUMA**.

##### Warnings (S0005)

If a warning has occurred, the display shows **S0005**:

- the number of warnings occurred
- a blinking question mark after approx. 3 seconds

Figure 21: Warnings



For further information, please also refer to <Corrective action>.


### Not ready REMOTE (S0006)

The S0006 display shows indications of the Not ready REMOTE group.

If such an indication has occurred, the display shows S0006:

- the number of indications occurred
- a blinking crossbar after approx. 3 seconds

Figure 22: Not ready REMOTE indications




For further information, please also refer to <Corrective action>.

### Fault (S0007)

If a fault has occurred, the display shows S0007:

- the number of faults occurred
- a blinking exclamation mark after approx. 3 seconds

Figure 23: Fault



For further information, please also refer to <Corrective action>.

## 4.2.3. Status indications according to NAMUR recommendation

These indications are available, if the parameter **Diagnostic classific. M0539** is set to **NAMUR**.


### Out of Specification (S0008)

The S0008 indication shows out of specification indications according to NAMUR recommendation NE 107.

If such an indication has occurred, the display shows S0008:

- the number of indications occurred
- a blinking triangle with question mark after approx. 3 seconds

Figure 24: Out of specification



For further information, please also refer to <Corrective action>.

### Function check (S0009)


The S0009 indication shows function check indications according to NAMUR recommendation NE 107.

If an indication has occurred via the function check, the display shows S0009:

- the number of indications occurred
- a blinking triangle with a spanner after approx. 3 seconds



Figure 25: Function check



For further information, please also refer to <Corrective action>.


### Maintenance required (S0010)

The **S0010** indication shows maintenance indications according to NAMUR recommendation NE 107.

If such an indication has occurred, the display shows **S0010**:

- the number of indications occurred
- a blinking square with an oilcan after approx. 3 seconds

Figure 26: Maintenance required



For further information, please also refer to <Corrective action>.


### Failure (S0011)

The **S0011** indication shows the causes of the failure indication according to NAMUR recommendation NE 107.

If such an indication has occurred, the display shows **S0011**:

- the number of indications occurred
- a blinking circle with a cross after approx. 3 seconds

Figure 27: Failure



For further information, please also refer to <Corrective action>.



### 4.3. Indication lights of local controls

Figure 28: Arrangement and signification of indication lights



- [1] Marking with symbols (standard)
- [2] Marking with figures 1 – 6 (option)
- 1 End position CLOSED reached (blinking: operation in direction CLOSE)
- 2 Torque fault CLOSE
- 3 Motor protection tripped
- 4 Torque fault OPEN
- 5 End position OPEN reached (blinking: operation in direction OPEN)
- 6 Bluetooth connection active

#### Modify indication light assignment (indications)

Different indications can be assigned to LEDs 1 – 5.

M ▶ **Device configuration** M0053  
     **Local controls** M0159  
         **Indication light 1 (left)** M0093  
         **Indication light 2** M0094  
         **Indication light 3** M0095  
         **Indication light 4** M0096  
         **Indicat. light 5 (right)** M0097  
         **Signal interm. pos.** M0167

#### Default values (Europe):

**Indication light 1 (left)** = End p. CLOSED, blink  
**Indication light 2** = Torque fault CLOSE  
**Indication light 3** = Thermal fault  
**Indication light 4** = Torque fault OPEN  
**Indicat. light 5 (right)** = End p. OPEN, blink  
**Signal interm. pos.** = OPEN/CLOSED = Off

#### Further setting values:

Refer to <Appendix>/<Selection overview for output contacts and indication lights>

#### 4.3.1. Indication lights: change colour

User level required to make changes: AUMA (6)

M ▶ **Device configuration** M0053  
     **Local controls** M0159

Table 4:

Parameters	Menu	Default values for European variant	Setting values
Colour ind.light 1	M0838	Yellow	Yellow Green Yellow/green
Colour ind.light 2	M0839	Red	Red Blue Purple
Colour ind.light 3	M0840	Red	Red Yellow Orange
Colour ind.light 4	M0841	Red	Red Blue Purple
Colour ind.light 5	M0842	Green	Green Red Orange

**Information** Default values can vary for other variants.

## 5. Signals (output signals)

### 5.1. Signals via fieldbus

The feedback signals via Modbus RTU can be read using the appropriate Modbus function codes.

For further information, please refer to the Manual (Device integration fieldbus) Modbus.

### 5.2. Status signals via output contacts (digital outputs)

- Conditions** Output contacts are only available if a parallel interface is provided in addition to the fieldbus interface.
- Characteristics** Output contacts are used to send status signals (e.g. reaching the end positions, selector switch position, faults...) as binary signals to the control room.
- Status signals only have two states: active or inactive. Active means that the conditions for the signal are fulfilled.

#### 5.2.1. Assignment of outputs

The output contacts (outputs DOUT 1 – 6) can be assigned to various signals.

Required user level: **Specialist (4)** or higher.

**M ▶** Device configuration M0053  
I/O interface M0139  
Digital outputs M0110  
Signal DOUT 1 M0109

**Default values:**

Signal DOUT 1 = Fault  
Signal DOUT 2 = End position CLOSED  
Signal DOUT 3 = End position OPEN  
Signal DOUT 4 = Selector sw. REMOTE  
Signal DOUT 5 = Torque fault CLOSE  
Signal DOUT 6 = Torque fault OPEN

**Further setting values:**

Refer to <Appendix>/<Selection overview for output contacts and indication lights>

#### 5.2.2. Coding the outputs

The output signals **Coding DOUT 1** – **Coding DOUT 6** can be set either to high active or low active.

- High active = output contact closed = signal active
  - Low active = output contact open = signal active
- Signal active means that the conditions for the signal are fulfilled.

Required user level: **Specialist (4)** or higher.

**M ▶** Device configuration M0053  
I/O interface M0139  
Digital outputs M0110  
Coding DOUT 1 M0102

**Default values:**

Coding DOUT 1 = Low active  
Coding DOUT 2–Coding DOUT 6 = High active

### 5.3. Configurable status signals

- Requirements** <Additional inputs> or additional <Parallel interface>.

The status signals described here are collective signals of various other signals. For configuration, the contained signals can be selected from a list and activated (●) or deactivated (○) individually.

The status signals can either be assigned to a digital output (output contact) or to an indication light (LED).

For detailed information on these signals, refer to [page 146, Fault indications and warning indications](#) chapter.


### Configure status signals

Required user level: **Specialist (4)** or higher.

- M ▶** **Device configuration** M0053  
     **Config. of signals** M0860  
         **Failure (configurable)** M0879  
         **Fault (Cfg)** M0880  
         **Warnings (Cfg)** M0881  
         **Not ready REMOTE (Cfg)** M0882

A dot in the display indicated whether the signal is active or not.

Figure 29: Example



Black dot (●): Signal active

White dot (○): Signal not active

Activation/deactivation is switched on/off by push button **Ok**.

## 5.4. Analogue signals (analogue outputs)

<b>Conditions</b>	The actuator is equipped with a position transmitter.
<b>Characteristics</b>	Depending on the actuator equipment, different signals, such as travel, torque or output speed can be recorded and issued as continuous values, e.g. 4 to 20 mA. Actuator controls are equipped with up to two analogue outputs, AOUT1 and AOUT2.

### 5.4.1. Assignment of analogue output 1

Required user level: **AUMA (6)**.

- M ▶** **Device configuration** M0053  
     **I/O interface** M0139  
         **Analogue outputs** M0335  
         **Signal AOUT 1** M0131

**Default value:** **Actual position**

**Information** The signal range of the output (e.g. 0/4 – 20 mA) is set via a separate parameter (**Signal range AOUT1** M0129).

#### Setting values:

- Not used** Analogue output 1 is not assigned.
- Actual position** Position feedback of the valve position (actual position value E2)

Condition: Position transmitter installed in the actuator.

An adjustment to the end positions or the defined travel is not required. An automatic adjustment is done via the end positions (LSC (WSR) and LSO (WOEL)).


For torque seating, the end positions OPEN and CLOSED of the limit switching should be set as close as possible to the end positions of the valve to minimise the deviation of the feedback.

#### Torque Torque feedback E6

Condition: MWG position transmitter in actuator.

The zero point is in the centre of the selected output range (10 mA or 12 mA). The torque in direction CLOSE is indicated with 0 – 10 mA or 4 – 12 mA, the torque in direction OPEN with 10 – 20 mA or 12 – 20 mA. For 127 % of the maximum nominal output torque, 0 or 4 mA are indicated in direction CLOSE, and 20 mA are indicated in direction OPEN.

Figure 30: Actual torque value



-127% = maximum nominal torque in end position CLOSED reached

+127% = maximum nominal torque in end position OPEN reached

**Input AIN 1** Analogue value transmitted via AIN1 (refer to wiring diagram) to the actuator.

Condition: An analogue signal (e.g. 0 – 20 mA) is connected to the analogue input AIN 1.

**Input AIN 2** Analogue value transmitted via AIN 2 (refer to wiring diagram) to the actuator.

Condition: An analogue signal (e.g. 0 – 20 mA) is connected to the analogue input AIN 2.

**Fieldbus AOUT 1** Analogue value transmitted from the fieldbus to the actuator.

The value is transmitted via fieldbus in per mil (value: 0 – 1000) and can be sent as continuous value. e.g. 4 to 20 mA, via output **Signal AOUT 1**.

**Fieldbus AOUT 2** If another analogue value is transmitted via fieldbus to the actuator, it can be sent as continuous value. e.g. 4 to 20 mA, via output **Signal AOUT 2**.

**Temp. ctrls norm. ‰** Actuator controls temperature (normalised) in per mil.

Condition: MWG position transmitter in actuator.

**Temp. ctrl unit norm ‰** Control unit temperature (normalised) in per mil.

Condition: MWG position transmitter in actuator.

### 5.4.2. Signal range of analogue output 1

Required user level: **Specialist (4)** or higher.

**M ▶** **Device configuration** M0053  
**I/O interface** M0139  
**Analogue outputs** M0335  
**Signal range AOUT1** M0129

**Default value:** 0 - 20 mA

**Setting values:**

**0 - 20 mA** Analogue output 1 generates a 0 – 20 mA signal.

**4 - 20 mA** Analogue output 1 generates a 4 – 20 mA signal.

**20 - 0 mA** Analogue output 1 generates a 20 – 0 mA signal.

**20 - 4 mA** Analogue output 1 generates a 20 – 4 mA signal.

**X to Y mA** The signal range (X-Y) of the analogue output can be freely configured using two parameters.

**5.4.3. Adjustment of analogue output 1**

Initial values and end values of the signal range can be corrected by  $\pm 10\%$  of the maximum value range (20 mA)

Example: Parameter **Signal range AOUT1** = 4 - 20 mA

The initial value (4 mA) can be adapted within a range of 2 mA to 6 mA.

The end value (20 mA) can be adapted within a range of 18 mA to 22 mA.

Required user level: **Specialist (4)** or higher.

M ▶ **Device configuration** M0053  
**I/O interface** M0139  
**Analogue outputs** M0335  
**Adjustment AOUT 1** M0544  
**0/4 mA (initial value)** M0140  
**20 mA (final value)** M0210

**Default value:** 0

**Setting ranges:** -10.0 ... 10.0 % (in %)

**5.4.4. Assignment of analogue output 2**

Required user level: **Specialist (4)**.

M ▶ **Device configuration** M0053  
**I/O interface** M0139  
**Analogue outputs** M0335  
**Signal AOUT 2** M0132

**Default value:** Torque

**Setting values:**

Description see <Assignment of analogue output 1>.

**5.4.5. Signal range of analogue output 2**

Required user level: **Specialist (4)** or higher.

M ▶ **Device configuration** M0053  
**I/O interface** M0139  
**Analogue outputs** M0335  
**Signal range AOUT2** M0130

**Default value:** 0 - 20 mA

**Setting values:**

<b>0 - 20 mA</b>	Analogue output 2 generates a 0 – 20 mA signal.
<b>4 - 20 mA</b>	Analogue output 2 generates a 4 – 20 mA signal.
<b>20 - 0 mA</b>	Analogue output 2 generates a 20 – 0 mA signal.
<b>20 - 4 mA</b>	Analogue output 2 generates a 20 – 4 mA signal.
<b>X to Y mA</b>	The signal range (X-Y) of the analogue output can be freely configured using two parameters.

**5.4.6. Adjustment of analogue output 2**

Initial values and end values of the signal range can be corrected by  $\pm 10\%$  of the maximum value range (20 mA)

Example: Parameter **Signal range AOUT1** = 4 - 20 mA

The initial value (4 mA) can be adapted within a range of 2 mA to 6 mA.

The end value (20 mA) can be adapted within a range of 18 mA to 22 mA.

Required user level: **Specialist (4)** or higher.

M ▶ Device configuration M0053  
I/O interface M0139  
Analogue outputs M0335  
Adjustment AOUT 2 M0545  
0/4 mA (initial value) M0141  
20 mA (final value) M0211  
**Default values:** 0  
**Setting ranges:** -10.0 ... 10.0 % (in %)

## 6. Operation

Different operation modes (states) are available. The current operation mode is indicated in the first line of the display:


Figure 31: Example: Operation mode Off



This chapter describes the characteristics of the different operation modes; the respective functions are described in separate chapters.

### 6.1. Operation mode Off

The selector switch is in position **0** (OFF).




#### Characteristics

- The indication in the top row of the display shows: **Off**
- Electric operation is not possible (not even EMERGENCY operation).
- The controls remain fully operative as far as signalling is concerned (controls' power supply is maintained).
- Push buttons **▲▼←→C** can be used for menu navigation via the display.

### 6.2. Operation mode Local

Selector switch is in position **Local control** (LOCAL).



#### Properties

- The indication in the top row of the display shows: **Local**
- In motor operation, the actuator can be controlled locally via the push buttons **↑** (OPEN), **STOP**, **↓** (CLOSE).
- Faults and warnings without automatic reset can be confirmed with the push button **RESET**.

#### 6.2.1. Push-to-run operation or self-retaining Local

Parameter **Self-retaining Local M0076** determines the actuator operation behaviour to operation commands via push buttons on local controls.

**M ▶** **Customer settings M0041**  
**Local controls M0075**  
**Self-retaining Local M0075**

**Default value:** **OPEN and CLOSE**

**Setting values:**

**Off (push-to-run op.)** Push-to-run operation activated, self-retaining off:

Actuator only runs in directions **OPEN** or **CLOSE** while an operation command is being received. The actuator stops if the operation command is cancelled.

**OPEN** In direction **OPEN** = self-retaining (in direction **CLOSE** push-to-run operation):

After an operation command in direction **OPEN**, the actuator continues to run, even if the operation command is cancelled (self-retaining). The actuator is either stopped by the **STOP** command or if end position **OPEN** or an intermediate position **OPEN** has been reached.

**CLOSE** In direction **CLOSE** = self-retaining (in direction **OPEN** push-to-run operation):



After an operation command in direction CLOSE, the actuator continues to run, even if the operation command is cancelled (self-retaining). The actuator is either stopped by the CLOSE command or if end position CLOSED or an intermediate position CLOSED has been reached.

#### OPEN and CLOSE

In directions OPEN and CLOSE = self-retaining:

After an operation command, the actuator continues to run in directions OPEN or CLOSE, even if the operation command is cancelled (self-retaining). The actuator is either stopped by the STOP command or if an end position or intermediate position has been reached.

Direct reversal of operation is not possible. Operation commands in directions OPEN or CLOSE must be stopped first by STOP command. Only then is an operation command into the opposite direction allowed.


#### OPEN & CL w/o STOP

In directions OPEN and CLOSE = self-retaining without stop:

Direct reversal of operation is also possible without the STOP command. However, operation can be stopped at any time by the STOP command.

### 6.3. Operation mode remote

Selector switch is in position **Remote control** (REMOTE).



#### Properties

The indication in the top row of the display shows the set source of the operation commands:

- **Remote** (parallel interface)
- **Remote II** (parallel interface, service box)
- **Fieldbus** (channel 1 or channel 2)

Depending on the control, a distinction is made between:

- **OPEN-CLOSE control** (operation mode Remote OPEN-CLOSE): Control is made via binary operation commands OPEN, STOP, CLOSE.
- **Setpoint control** (operation mode Remote SETPOINT): Control via analogue operation commands, e.g. 4 – 20 mA.

#### Information

- Binary signals (e.g. +24 V DC) via digital inputs are only recognised as valid operation commands if the signal is present for at least 10 ms.
- If a positioner or process controller is available, change-over between OPEN-CLOSE control (operation mode Remote OPEN-CLOSE) and setpoint control (operation mode Remote SETPOINT) is possible. Refer to chapter <Change-over between OPEN-CLOSE control and setpoint control>.

#### 6.3.1. Push-to-run operation or self-retaining Remote

Parameters **Self-retaining Remote M0100**, **Self-retaining Remote II M01193** and **Self-retaining Remote II M0101** determine the operation behaviour of the actuator to binary operation commands (OPEN, STOP, CLOSE), controlling the actuator “from Remote” via the I/O interface.

“Self-retaining” parameters have no impact on operation commands transmitted via fieldbus. When equipped with fieldbus interface, setting of these parameters is only required if digital inputs (OPEN, STOP, CLOSE) are available in addition to the fieldbus interface.



**Customer settings** M0041  
I/O interface M0015  
Self-retaining Remote M0100  
Self-retaining Remote II M0101

**Default values:**

Self-retaining = Off (push-to-run op.)

Self-retaining Remote II = OPEN and CLOSE

**Setting values for parameters** Self-retaining Remote M0100 and Self-retaining Remote II M0101:

Off (push-to-run op.) Push-to-run operation activated, self-retaining off:

Actuator only runs in directions OPEN or CLOSE while an operation command is being received. The actuator stops if the operation command is cancelled.

**OPEN** In direction OPEN = self-retaining (in direction CLOSE push-to-run operation):

After an operation command in direction OPEN, the actuator continues to run, even if the operation command is cancelled (self-retaining). The actuator is either stopped by the STOP command or if end position OPEN or an intermediate position OPEN has been reached.

**CLOSE** In direction CLOSE = self-retaining (in direction OPEN push-to-run operation):

After an operation command in direction CLOSE, the actuator continues to run, even if the operation command is cancelled (self-retaining). The actuator is either stopped by the CLOSE command or if end position CLOSED or an intermediate position CLOSED has been reached.

**OPEN and CLOSE** In directions OPEN and CLOSE = self-retaining:

After an operation command, the actuator continues to run in directions OPEN or CLOSE, even if the operation command is cancelled (self-retaining). The actuator is either stopped by the STOP command or if an end position or intermediate position has been reached.

Direct reversal of operation is not possible. Operation commands in directions OPEN or CLOSE must be stopped first by the STOP command. Only then is an operation command into the opposite direction allowed.

**OPEN & CL w/o STOP** In directions OPEN and CLOSE = self-retaining without stop:

Direct reversal of the operation direction without STOP command is possible.

Direct reversal of operation is also possible without the STOP command. However, operation can be stopped at any time by the STOP command.

#### 6.4. Operation mode EMERGENCY

**See also:** Failure function <EMERGENCY behaviour>

- Characteristics**
- The indication in the top row of the display shows: **EMERGENCY**
  - The operation mode EMERGENCY is initiated by the EMERGENCY signal.
  - The actuator performs an EMERGENCY operation. For example, the actuator moves to a predefined EMERGENCY position (i.e. end position OPEN or end position CLOSED).
  - As long as the EMERGENCY signal is present, the actuator does not respond to any other operation commands (EMERGENCY signal has top priority).



**The actuator can start immediately when switching on!**

*Risk of personal injuries or damage to the valve.*

- Ensure that the EMERGENCY signal is present when switching on.
- Should the actuator start unexpectedly: Immediately set selector switch to position **0** (OFF).

#### 6.5. Operation mode EMERGENCY stop

**See also:** Failure function <EMERGENCY stop function>

**Condition** An EMERGENCY stop button (latching) is either located on the electrical connection or outside.

- Characteristics**
- The indication in the top row of the display shows: **EMCY stop**

- In an emergency, the EMERGENCY stop button can be used to interrupt the power supply of the motor control (contactors or thyristors).
- Operation mode EMERGENCY stop supersedes all other operation modes.
- A new operation command can only be executed once the pressed EMERGENCY stop button is released and operation mode EMERGENCY Stop is cancelled using a Reset command.
- Once operation mode EMERGENCY Stop is cancelled (Reset command), incoming analogue operation commands (e.g. 0/4 – 20 mA) or incoming operation commands via fieldbus will immediately be executed again.

## 6.6. Operation mode Disabled

**See also:** Application function <Local controls:enable>

- Characteristics**
- The indication in the top row of the display shows: **Disabled**
  - The operation via the push buttons on the local controls is disabled.
  - Operation mode **Disabled** is possible in selector switch positions LOCAL and OFF.

Table 5: Functions depending on the selector switch position:

Selector switch is in position	Function during indication = Disabled
Local control (LOCAL)	Actuator cannot be operated locally
0 (OFF)	Local menu operation not possible

- For control via fieldbus interface, the fieldbus disables or enables the operation.

## 6.7. Operation mode Service

**Conditions:** Set selector switch = position **Local control** (LOCAL) or **Remote control** (REMOTE).  
Display indicates in the first row: **Service**

- Characteristics**
- The indication in the top row of the display shows: **Service**
  - For operation mode Service, a PC or laptop with AUMA CDT service software is required. AUMA service uses this software (e.g. during commissioning or maintenance) to perform settings at the actuator controls.

**Information** In selector position **Local control** (LOCAL), press any push button to exit the service operation mode and to activate operation mode Local.

## 7. Basic settings for commissioning

**Definition** Basic settings such as type of seating, torque and limit switching are required for safe commissioning of the actuator controls together with the actuator. Basic settings for display, such as date and time or display formats, can be changed, if required.

### 7.1. Type of seating for end positions


- Function**
- Selection of the type of seating (according to valve manufacturer's specifications)
    - Limit seating in end position
    - Torque seating in end position
  - For end positions OPEN and CLOSED, the following can be set individually:

#### Limit seating

Actuator controls switch off the actuator in the end positions (OPEN/CLOSED) set via limit switching.

For end position seating via limit switching, you have to account for the overrun of the actuator. Overrun [1] is the travel from switching off until complete standstill. The overrun depends on the inertia of both the actuator and the valve and the delay time of the actuator controls.

Figure 32: Limit seating



P Tripping position

[1] Overrun

#### Torque seating

Actuator controls switch off the actuator in the end positions via torque tripping.

For this, the torque switching has to be set to the tripping torque specified by the valve manufacturer. When reaching the end position, the torque increases within the valve seat. Actuator controls switch off the actuator once the set tripping torque has been reached.

With this setting, the limit switching is used for signalling and must be set to trip shortly **before** reaching the end position.

#### 7.1.1. Type of seating: set

##### NOTICE

##### Valve damage due to incorrect setting!

- The type of seating setting (limit or torque seating) must match the selection for the valve.
- Only change the setting with prior consent of the valve manufacturer.


M ▶ Customer settings M0041  
 Type of seating M0012  
 End position CLOSED M0086  
 End position OPEN M0087

**Default value:** Limit

##### Setting values:

**Limit** Seating in end positions via limit switching.

**Torque** Seating in end positions via torque switching.

- |                         |   |
|-------------------------|---|
| <b>Select main menu</b> | <p>1. Set selector switch to position <b>0</b> (OFF).</p>  <p>2. Press push button <b>C Setup</b> and hold it down for approx. 3 seconds.</p> <p>➔ Display goes to main menu and indicates: ▶ <b>Display</b></p>   |
| <b>Select parameter</b> | <p>3. Select parameter either:</p> <ul style="list-style-type: none"> <li>➔ click via the menu <b>M ▶</b> to parameter, or</li> <li>➔ via direct display: Press <b>▲</b> and enter ID <b>M0086</b> or <b>M0087</b></li> </ul> <p>➔ Display indicates: <b>End position CLOSED</b></p>  |
| <b>CLOSE or OPEN</b>    | <p>4. Use <b>▲▼ Up ▲ Down ▼</b> to select:</p> <ul style="list-style-type: none"> <li>➔ ▶ <b>End position CLOSED</b></li> <li>➔ ▶ <b>End position OPEN</b></li> </ul> <p>➔ The black triangle ▶ indicates the current selection.</p> <p>5. Press <b>↵ Ok</b>.</p> <p>➔ Display indicates the current setting: <b>Limit</b> or <b>Torque</b></p> <p>➔ The bottom row of the display indicates either:</p> <ul style="list-style-type: none"> <li>- <b>Edit</b> → continue with step 6</li> <li>- <b>Save</b> → continue with step 10</li> </ul> <p>6. Press <b>↵ Edit</b>.</p> <p>➔ Display indicates: ▶ <b>Specialist (4)</b></p> |
| <b>User login</b>       | <p>7. Use <b>▲▼ Up ▲ Down ▼</b> to select user:</p> <p><b>Information:</b> Required user level: <b>Specialist (4)</b> or higher</p> <p>➔ The symbols have the following meaning:</p> <ul style="list-style-type: none"> <li>- black triangle: ▶ = current setting</li> <li>- white triangle: ▷ = selection (not saved yet)</li> </ul> <p>8. Press <b>↵ Ok</b>.</p> <p>➔ Display indicates: <b>Password 0***</b></p> <p>9. Enter password (→ enter password).</p> <p>➔ The screen indicates the pre-set type of seating (▶ <b>Limit</b> or ▶ <b>Torque</b>) by means of a black triangle ▶.</p>                                    |
| <b>Change settings</b>  | <p>10. Use <b>▲▼ Up ▲ Down ▼</b> to select new setting.</p> <p>➔ The symbols have the following meaning:</p> <ul style="list-style-type: none"> <li>- black triangle: ▶ = current setting</li> <li>- white triangle: ▷ = selection (not saved yet)</li> </ul> <p>11. Confirm selection via <b>↵ Save</b>.</p> <p>➔ The setting for the type of seating is complete.</p> <p>12. Back to step 4 (CLOSED or OPEN): Press <b>↵ Esc</b>.</p>   |

## 7.2. Torque switching

- |                   |  |
|-------------------|--|
| <b>Conditions</b> | <p>MWG in actuator (non-intrusive version).</p> <p>For torque switches within the actuator (intrusive version), the torque switching is set as described in the operation instructions pertaining to the actuator.</p> |
| <b>Function</b>   | <ul style="list-style-type: none"> <li>• Overload protection across full travel</li> <li>• Tripping in end positions (for torque seating)</li> <li>• Tripping in during manual operation also possible</li> </ul>      |

- Indication or setting either in percent %, Newton metre Nm or in pounds per foot. ft-lb

**Read more** <Torque monitoring> chapter

### 7.2.1. Torque switching: set

Once the set torque is reached, the torque switches will be tripped (overload protection of the valve).

**Information** The torque switches may also trip during manual operation.

#### NOTICE

#### Valve damage due to excessive tripping torque limit setting!


- The tripping torque must suit the valve.
- Only change the setting with the consent of the valve manufacturer.

**M ▶** Customer settings M0041  
Torque switching M0013  
Trip torque CLOSE M0088  
Trip torque OPEN M0089

**Default value:** According to order data

**Setting range:** Torque range according to actuator name plate

**Select main menu** 1. Set selector switch to position **0** (OFF).



2. Press push button **C Setup** and hold it down for approx. 3 seconds.

➔ Display goes to main menu and indicates: ▶ **Display**

**Select parameter** 3. Select parameter either:

- click via the menu **M ▶** to parameter, or
- via direct display: press **▲** and enter ID **M0088**.

➔ Display indicates: **Trip torque CLOSE**

**CLOSE or OPEN** 4. Use **▲ ▼ Up ▲ Down ▼** to select:

- ▶ **Trip torque CLOSE**
- ▶ **Trip torque OPEN**

➔ The black triangle ▶ indicates the current selection.

5. **↵** Press **OK**.

➔ Display shows the set value.

➔ The bottom row indicates: **Edit Esc**

6. **↵** Press **Edit**.

➔ Display indicates:

- **Specialist (4)** → continue with step 7
- in bottom row **Up ▲ Down ▼ Esc** → continue with step 11

**User login** 7. Use **▲ ▼ Up ▲ Down ▼** to select user:

**Information:** Required user level: **Specialist (4)** or higher.

➔ The symbols have the following meanings:

- black triangle: ▶ = current setting
- white triangle: ▷ = selection (not saved yet)

8. **↵** Press **OK**.

➔ Display indicates: **Password 0\*\*\***

- Change value**
9. Enter password (→ enter password).
    - Display shows the set value.
    - The bottom row indicates: **Edit Esc**
  10. ↵ Press **Edit**.
  11. Enter new value for tripping torque via ▲ ▼ Up ▲ Down ▼.
 

**Information:** The adjustable torque range is shown in round brackets.
  12. Save new value via ↵ **Save**.
    - The tripping torque is set.
  13. Back to step 4 (CLOSED or OPEN): Press ↵ **Esc**.
- Information**
- The following fault signals are issued if the torque setting performed has been reached **in mid-travel**:
- In the display of the local controls: Status indication **S0007 Fault = Torque fault OPEN** or **Torque fault CLOSE**
- The fault has to be acknowledged before the operation can be resumed. The acknowledgement is made:
1. either by an operation command in the opposite direction.
    - For **Torque fault OPEN**: Operation command in direction CLOSE
    - For **Torque fault CLOSE**: Operation command in direction OPEN
  2. or, in case the torque applied is lower than the preset tripping torque:
    - in selector switch position **Local control** (LOCAL) via push button **RESET**.
    - in selector switch position **Remote control** (REMOTE):
      - via the fieldbus, command reset. (byte 1 bit 3 of output data), if the fieldbus is the active command source.
      - via a digital input (I/O interface) with RESET command if a digital input is configured for signal **RESET** and the I/O interface is the active command source.

### 7.3. Limit switching

- Conditions** Electronic control unit with MWG in the actuator (non-intrusive version)  
For an electro-mechanical control unit equipped with switches in the actuator (intrusive version), the limit switches are set as described in the operation instructions.
- Functions**
- Tripping in end positions (limit seating)
  - Signalling the end positions (torque seating)

#### 7.3.1. Limit switching: set



**If the valve cannot be operated during commissioning, only one end position can be set. The other end position must then be set via the stroke.**

→ For this, refer to [page 41, End position setting via stroke](#).

#### NOTICE


#### Valve damage at valve/gearbox due to incorrect setting!

- When setting with motor operation: Stop actuator **prior** to reaching end of travel (press STOP push button).
- For limit seating, provide for sufficient backlash between end position and mechanical end stop due to potential overrun.



**Customer settings** M0041  
**Limit switching** M0010  
**Set end pos. CLOSED?** M0084  
**Set end pos. OPEN?** M0085




- Select main menu**
1. Set selector switch to position **0** (OFF).  

  2. Press push button **C** and hold it down for approx. 3 seconds.  
 ➔ Display goes to main menu and indicates: ► **Display**
- Select parameter**
3. Select parameter either:
    - click via the menu **M** ► to parameter, or
    - via direct display: press ▲ and enter ID **M0084**.
 ➔ Display indicates: **Set end pos.CLOSED?**
- CLOSED or OPEN**
4. Select via ▲ ▼ Up ▲ Down ▼:
    - ► **Set end pos.CLOSED? M0084**
    - ► **Set end pos. OPEN? M0085**
 ➔ The black triangle ► indicates the current selection.
  5. Press **Ok**.  
 ➔ The display indicates either:
    - **Set end pos.CLOSED? CMD0009** → continue with step 9
    - **Set end pos. OPEN? CMD0010** → continue with step 12
    - **Specialist (4)** → continue with step 6
- User login**
6. Use ▲ ▼ Up ▲ Down ▼ to select user:  
**Information:** Required user level: **Specialist (4)** or higher  
 ➔ The symbols have the following meaning:
    - black triangle: ► = current setting
    - white triangle: ▷ = selection (not saved yet)
  7. Press **Ok** to confirm selected user.  
 ➔ Display indicates: **Password 0\*\*\***
  8. Enter password (→ enter password).  
 ➔ The display indicates either:
    - **Set end pos.CLOSED? CMD0009** → continue with step 9
    - **Set end pos. OPEN? CMD0010** → continue with step 12
- Set end position**  
**CLOSED CMD0009**
9. Set end position CLOSED again :
    - 9.1 For large strokes: Set selector switch in position **Local control** (LOCAL) and operate actuator in motor operation via push button **I** (CLOSE) in direction of the end position.  
**Information:** Stop actuator **before** reaching end of travel (press **STOP** push button to avoid damage).
    - 9.2 Engage manual operation.
    - 9.3 Turn handwheel until valve is closed.
    - 9.4 Turn handwheel by approximately half a turn (overrun) in the opposite direction of end position.
    - 9.5 Turn back the handwheel by an amount equal to the overrun.
    - 9.6 Set selector switch to position **0** (OFF).  
 ➔ Display indicates: **Set end pos.CLOSED? Yes No**



**Confirm new end position**

10. Press **↵** **Yes** to confirm new end position.
  - ➔ Display indicates: **End pos. CLOSED set!**
  - ➔ The left LED is illuminated (standard version) and thus indicates that the end position CLOSED setting is complete.



11. Make selection:
  - **Edit** → back to step 9: Set end position CLOSED "once again"
  - **Esc** → back to step 4; either set end position OPEN or exit the menu.


**Set end position OPEN**  
**CMD0010**

12. Re-set end position OPEN:
  - 12.1 For large strokes: Set selector switch in position **Local control** (LOCAL) and operate actuator in motor operation via push button **☰** (OPEN) in direction of the end position.  
**Information:** Stop actuator **before** reaching end of travel (press **STOP** push button to avoid damage).
  - 12.2 Engage manual operation.
  - 12.3 Turn handwheel until valve is open.
  - 12.4 Turn handwheel by approximately half a turn (overrun) in the opposite direction of end position.
  - 12.5 Turn back the handwheel by an amount equal to the overrun.
  - 12.6 Set selector switch to position **0** (OFF).

➔ Display indicates: **Set end pos. OPEN? Yes No**

**Confirm new end position**

13. Press **↵** **Yes** to confirm new end position.
  - ➔ Display indicates: **End pos. OPEN set!**
  - ➔ The right LED is illuminated (standard version) and thus indicates that the end position OPEN setting is complete.



14. Make selection:
  - **Edit** → back to step 12: Set end position OPEN "once again"
  - **Esc** → back to step 4; either set end position CLOSED or exit the menu.

**Information** If an end position cannot be set: Check the type of control unit in actuator.

### 7.3.2. End position setting via stroke



**For all applications not allowing to operate the valve during commissioning, the second end position can be set via the stroke.**

- The basics are the MWG incremental values shown in this chapter.
- The first end position either OPEN or CLOSED, depending on the valve position during commissioning, can be set as usual using the limit switching. For this, refer to [page 39, Limit switching: set.](#)

**NOTICE****Valve damage at valve/gearbox due to incorrect setting!**

- When setting with motor operation: Stop actuator **prior** to reaching end of travel (press STOP push button).
- For limit seating, provide for sufficient backlash between end position and mechanical end stop due to potential overrun.

**MWG incremental values depending on the actuator type**

Depending on the generation, the MWG of actuator controls can represent the following revolutions:

**Generation 1:** 512 turns at a value of 16 bit

**Generation 2:** 544 turns at a value of 16 bit

**Information**

The type of generation integrated within the actuator can be identified by the item "Positioner" of the order-related data sheet. This data sheet can be downloaded from the website **www.auma.com** via "Service & Support".

Table 6: Determine the generation via the order-related data sheet

Value on the order-related data sheet	MWG generation
30.1	1
30.2, 30.4, 30.5	2

The table below lists the number of incremented values per revolution at the output drive of the respective actuator.

Table 7: Incremented values per revolution (multi-turn actuator)

Actuator	Incremented values per revolution Generation 1	Incremented values per revolution Generation 2
SA 07.2 / SA 07.6	125.490	118.108
SA 10.2	128	120.461
SA 14.2 / SA 14.6	127.543	120.041
SA 16.2	128	120.461

Table 8: Incremented values per revolution (part-turn actuator)

Actuator	Incremented values per 1/4 revolution Generation 1	Incremented values per 1/4 revolution Generation 2
SQ 05.2	665.546	626.397
SQ 07.2	665.546	626.397
SQ 10.2	851.899	801.788
SQ 12.2	1703.798	1603.575
SQ 14.2	3918.737	3688.222

Finally, the incremented values per revolution are to be multiplied by the stroke. Thereafter, the end position can be set via stroke.



**Customer settings M0041**


**Limit switching M0010**

**Set end pos. CLOSED? M0084**

**Set end pos. OPEN? M0085**

**Select main menu**

1. Set selector switch to position **0** (OFF).



2. Press push button **C** and hold it down for approx. 3 seconds.
- ➔ Display goes to main menu and indicates: ▶ **Display**


- |   |  |
|---|--|
| <b>Select parameter</b>                                   | <p>3. Select parameter either:</p> <ul style="list-style-type: none"> <li>→ click via the menu <b>M ▶</b> to parameter, or</li> <li>→ via direct display: Press <b>▲</b> and enter ID <b>M0084</b></li> </ul> <p>➔ Display indicates: <b>Set end pos.CLOSED?</b></p>   |
| <b>OPEN or CLOSED</b>                                     | <p>4. Select via <b>▲ ▼ Up ▲ Down ▼</b>:</p> <ul style="list-style-type: none"> <li>→ <b>▶ Set end pos.CLOSED? M0084</b></li> <li>→ <b>▶ Set end pos. OPEN? M0085</b></li> </ul> <p>➔ The black triangle <b>▶</b> indicates the current selection.</p> <p>5. Press <b>↵ Ok</b>.</p>  |
| <b>Information</b>  | <p>If the end position CLOSED (or end position OPEN) is to be set via stroke, the end position OPEN (or end position CLOSED) must be set first via limit switching. For this, refer to <a href="#">page 39, Limit switching: set</a>.</p> <p>➔ The display indicates either:</p> <ul style="list-style-type: none"> <li>- <b>Set end pos.CLOSED? CMD0009</b> → continue with step 9</li> <li>- <b>Set end pos. OPEN? CMD0010</b> → continue with step 12</li> <li>- <b>Specialist (4)</b> → continue with step 6</li> </ul>  |
| <b>Log on user</b>  | <p>6. Use <b>▲ ▼ Up ▲ Down ▼</b> to select user:</p> <p><b>Information:</b> Required user level: <b>Specialist (4)</b> or higher</p> <p>➔ The symbols have the following meaning:</p> <ul style="list-style-type: none"> <li>- black triangle: <b>▶</b> = current setting</li> <li>- white triangle: <b>▷</b> = selection (not saved yet)</li> </ul> <p>7. Press <b>↵ Ok</b> to confirm selected user.</p> <p>➔ Display indicates: <b>Password 0***</b></p> <p>8. Enter password (→ enter password).</p> <p>➔ The display indicates either:</p> <ul style="list-style-type: none"> <li>- <b>Set end pos.CLOSED? CMD0009</b> → continue with step 9</li> <li>- <b>Set end pos. OPEN? CMD0010</b> → continue with step 12</li> </ul> |
| <b>Set end position<br/>CLOSED via stroke<br/>CMD0009</b> | <p><b>Information:</b> If the end position CLOSED is to be set via stroke, the end position OPEN must be set first via limit switching. For this, refer to <a href="#">page 39, Limit switching: set</a>.</p> <p>9. Display indicates: <b>Set end pos.CLOSED? Stroke Yes No</b></p> <p>10. Press <b>▼ Down ▼</b>.</p> <p>➔ Now, the incremented values for end position CLOSED can be set.</p> <p>11. Use <b>▲ ▼ Up ▲ Down ▼</b> to adapt the incremented value in compliance with the table at the beginning of this chapter.</p>   |



**Do not enter 0 as incremented value. Otherwise both set values are at the same valve position.**

**Confirm incremented  
value**

12. Press **↵ Save** to confirm new end position.
- ➔ Display indicates: **End pos. CLOSED set!**
- ➔ The left LED is illuminated (standard version) and thus indicates that the end position CLOSED setting is complete.



**Set end position  
CLOSED via stroke**  
CMD0010


13. Select:
  - **Edit** → back to step 9: Set end position CLOSED "once again"
  - **Esc** → back to step 4; either set end position OPEN or exit the menu.
- Information:** If the end position OPEN is to be set via stroke, the end position CLOSED must be set first via limit switching. For this, refer to [page 39, Limit switching: set](#).
14. Display indicates: **Set end pos.CLOSED? Stroke Yes No**
15. Press **▼ Down ▼**.
- ➡ Now, the incremented values for end position OPEN can be set.
16. Use **▲▼ Up ▲ Down ▼** to adapt the incremented value in compliance with the table at the beginning of this chapter.



**Do not enter 0 as incremented value. Otherwise both set values are at the same valve position.**

**Confirm incremented  
value**

17. Press **↵ Save** to confirm new end position.
- ➡ Display indicates: **End pos. OPEN set!**
- ➡ The right LED is illuminated (standard version) and thus indicates that the end position OPEN setting is complete.



18. Select:
  - **Edit** → back to step 12: Set end position OPEN "once again"
  - **Esc** → back to step 4; either set end position CLOSE or exit the menu.

**Information** If an end position cannot be set: Check the type of control unit in actuator.

## 7.4. Date and time

After commissioning, we recommend checking and setting date and time. Date and time are required for the event report function.

In case of a mains failure, date and time are stored. This data will only have to be checked after a longer downtime.

**M ▶** Display **M0009**  
Date and time **M0221**

- Information**
- The date format, e.g. day/month/year, can be changed via the parameter **Date format M0310**.
  - The time format, e.g. 12/24h can be changed via the parameter **Time format M0050**.

## 7.5. Display formats

The indications on the display can be represented in different formats: Country-specific spellings, for example, can be accounted for.

### 7.5.1. Date format

The data can be represented in day/month/year or in year/month/day.

**M ▶** Display **M0009**  
Date format **M0310**  
**Default value:** **DD.MM.YYYY**

**Setting values:**

**MM/DD/YYYY** Indication in: Month/day/year, example: 01/21/2009

DD.MM.YYYY	Indication in: Day/month/year, example: 21.01.2009
YYYY-MM-DD	Indication in: Year/month/day, example: 2009-01-21

### 7.5.2. Time format

The time can be indicated in 12 or 24 hour format.

M ▶ **Display** M0009  
Time format M0050

**Default value:** 24h

**Setting values:**

12h Indication of hour/minute/second in 12-hour format, example: 02:25:09 PM  
24h Indication of hour/minute/second in 24-hour format, example: 14:25:09

### 7.5.3. Number format

The number format determines the sign for indicating the decimal places. Either a decimal point or a decimal comma can be used to separate integral numbers and decimal places.

M ▶ **Display** M0009  
Number format M0231

**Default values:**

- For English as display language = xx.x
- For all other display languages = xx,x

**Setting values:**

xx.x Indication of the decimal places using a decimal point, example: 20.0 mA  
xx,x Indication of the decimal places using a decimal comma, example: 20,0 mA

### 7.5.4. Torque unit

The torque can be indicated in different units.

M ▶ **Display** M0009  
Torque unit M0051

**Default value:** Nm

**Setting values:**

Nm Indication in Nm  
ft-lb Indication in foot-pound  
% Indication in percent

### 7.5.5. Temperature unit

The temperature unit can either be displayed in Celsius [°C] or Fahrenheit [°F].

M ▶ **Display** M0009  
Temperature unit M0052

**Default value:** °C

**Setting range:** °C or °F

### 7.5.6. Position units

The valve position (e.g. actual position, setpoint position) or other positions (e.g. pivot points) are indicated in percent of the travel on the actuator controls display (default setting).. By activating the parameter **Position**, you may select other physical units instead of percent to represent the positions. Furthermore, both scaling and maximum value may be adapted. The change-over affects all screens indicating a position. This includes status pages such as S0001 S0003, but also the representation of characteristics (e.g. position-time) as well as histograms.

**Activate position unit**

Required user level: **Specialist (4)** or higher.

M ▶ **Display** M0009  
**Units** M1205  
**Position** M1206  
**Position activation** M1207

**Default value:** Function not active

**Setting values:**

**Function not active** <Units of position> function deactivated. Position indications in the display (e.g. the valve position **S0001**) are indicated in percent.

**Function active** <Units of position> function activated. Position indications in the display are not shown in percent but in the unit set for the values in parameter group **Position**.

**Set max. value, scaling and unit**

Required user level: **Specialist (4)** or higher.

M ▶ **Display** M0009  
**Units** M1205  
**Position** M1206  
**Max. value at 100.0 %** M1208  
**Scaling** M1209  
**Unit** M1210

**Default values:**

**Max. value at 100.0 %** = 1000

**Scaling** = 1

**Unit** = mA

**Setting ranges/values:**

**Max. value at 100.0 %** = 1 – 1000

**Scaling** = 0.001 – 1000 (multiplier factor for unit)

**Unit** = mA; °C; bar; m³/h; m³/min; m; cm; mm; °

**7.5.7. Process factor units**

Process factors (e.g. process setpoint, actual process value...) are shown in percent of travel in the actuator controls display (default setting). By activating the parameter **Process factor**, you may select other physical units apart from percent. The change-over affects all screens indicating a process value.

**Activate process factor units**

Required user level: **Specialist (4)** or higher.

M ▶ **Display** M0009  
**Units** M1205  
**Process factor** M1211  
**Proc. var. activation** M1212

**Default value:** Function not active

**Setting values:**

**Function not active** <Process factor units> deactivated. Position indications in the display are shown in percent.

**Function active** <Process factor units> activated. Position indications in the display are not shown in percent but in the unit set for the values in parameter group **Process factor**.

**Set max. value, scaling and unit**

Required user level: **Specialist (4)** or higher.

M ▶ Display M0009  
Units M1205  
Process factor M1211  
Max. value at 100.0 % M1213  
Scaling M1214  
Unit M1215

**Default values:**  
Max. value at 100.0 % = 1000  
Scaling = 1  
Unit = mA

**Setting ranges/values:**  
Max. value at 100.0 % = 1 – 1000  
Scaling = 0.001 – 1000 (multiplier factor for unit)  
Unit = mA; °C; bar; m³/h; m³/min; m; cm; mm; °

#### 7.5.8. Analogue working value units (AIN)

##### Activate working value units (AIN)

Required user level: Specialist (4) or higher.

M ▶ Display M0009  
Units M1205  
Working values (AIN) M1216  
Work. val. activ. (AIN) M1217

**Default value:** Function not active

**Setting values:**

Function not active <Working value units (AIN)> function deactivated.

Function active <Working value units (AIN)> function activated.

##### Set max. value, scaling and unit

Required user level: Specialist (4) or higher.

M ▶ Display M0009  
Units M1205  
Working values (AIN) M1216  
Max. value at 100.0 % M1217  
Scaling M1218  
Unit M1219

**Default values:**  
Max. value at 100.0 % = 1000  
Scaling = 1  
Unit = mA

**Setting ranges/values:**  
Max. value at 100.0 % = 1 – 1000  
Scaling = 0.001 – 1000 (multiplier factor for unit)  
Unit = mA; °C; bar; m³/h; m³/min; m; cm; mm; °

#### 7.5.9. Analogue signal output units (AOUT)

##### Activate signal output units (AOUT)

Required user level: Specialist (4) or higher.

M ▶ Display M0009  
Units M1205  
Signal outputs (AOUT) M1221  
Sig. outp. activ. (AOUT) M1222

**Default value:** Function not active**Setting values:**

Function not active &lt;Signal output units (AOUT)&gt; function deactivated.

Function active &lt;Signal output units (AOUT)&gt; function activated.

**Set max. value, scaling and unit**

Required user level: Specialist (4) or higher.

M ▶ Display M0009  
 Units M1205  
 Signal outputs (AOUT) M1221  
 Max. value at 100.0 % M1223  
 Scaling M1224  
 Unit M1225

**Default values:**

Max. value at 100.0 % = 1000

Scaling = 1

Unit = mA

**Setting ranges/values:**

Max. value at 100.0 % = 1 – 1000

Scaling = 0.001 – 1000 (multiplier factor for unit)

Unit = mA; °C; bar; m³/h; m³/min; m; cm; mm; °

**7.6. Contrast**

The contrast can be used to adapt the display backlight (light or dark background).

M ▶ Display M0009  
 Contrast M0230



## 8. Application functions

**Definition** Application functions are functions used to adapt the actuator controls to special applications. This includes device functions, communication functions and device information.

If they are enabled, these functions can be programmed by the user for his/her specific task using parameters.

### 8.1. Speed functions

SAV/SARV actuators can be controlled via ACV actuator controls using individual speed setpoints for operations in direction OPEN or CLOSE. This chapter describes control in standard operation (operation modes Local and Remote). Settings and behaviour in e.g. emergencies (operation mode EMERGENCY) as well as failure behaviour (on loss of signal) are described together with the respective safety functions.

#### 8.1.1. Speed source for local operation and remote operation

The actuator speed for local operation (via local controls) and remote operation can be provided from different speed sources. The speed can be set individually for each operation direction (OPEN/CLOSE). The input signal of the respective speed source can either be programmed as consistent or variable speed value.

- as constant, internal value (programmable speed)
- as constant, external value (via fieldbus)
- as variable, external value (via analogue signal)

As a general rule, the speed source has already been set in the factory according to the indications on the order.

Required user level: **Specialist (4)**

**M ▶** **Customer settings** M0041  
**Speed functions** M1699  
 Sp. source LOC OP M1700  
 Sp. source LOCAL CL M2039  
 Sp. source REM OP M1701  
 Sp. source REM CL M2040

1)

**Default value:** Fieldbus

**Setting values:**

**Fieldbus** The actuator speed is specified externally, via fieldbus. For this, constant speed values which may be programmed via fieldbus are provided (0 – 100 % or 0 – 1,000 per mil). For parameter configuration via fieldbus interface refer to Manual (Device integration fieldbus).

**Internal 1 – Internal 4** The actuator is controlled with a constant speed. For this, four programmable internal speed values are available. The four internal speed values are programmed via parameters **Speed internal1 M1930 – Speed internal 4 M1933**.

**2 DigIn: "Internal (1-4)"** Speed selection via two external signals. For this setting, changing between the four internally programmed, constant speeds (**Internal 1 – Internal 4**) is possible.

Two digital inputs have to be configured as control signals for speed selection.

**Analogue input** The actuator speed is specified/modified externally via an analogue value (e.g. 0 – 20 mA). An analogue input has to be defined as speed source.

#### Configuration of digital inputs for external speed selection

For setting of parameter **Sp. source... = 2 DigIn: "Internal (1-4)"** (external speed selection)

- 1) For the Multiport Valve product variant, the speed specifications are only made via both parameters "Speed source LOCAL **CLOSED**" (M5039) and "Speed source REMOTE **CLOSED**" (M5040). They are valid for both directions of rotation (counterclockwise = CCW and clockwise = CW).

According to the present description, two digital inputs have to be configured as control signals to allow for external speed selection.

Required user level: **Specialist (4)**

**M ▶** **Device configuration** M0053  
**I/O interface** M0139  
**Digital inputs** M0116

**Example** Use inputs DIN 5 and DIN 6 as control signals for external speed selection:

Parameter: **Signal DIN 5** M0122 = **Speed int. sel. bit 0**

Parameter: **Signal DIN 6** M0123 = **Speed int. sel. bit 1**

Table 9:

Input signals (DIN) for external speed selection		Output speed <sup>1)</sup>
Speed int. sel. bit 0	Speed int. sel. bit 1	
0	0	Speed internal1
0	1	Speed internal2
1	0	Speed internal3
1	1	Speed internal 4
0 = low level (0 V DC or input open)		
1 = high level (standard: +24 V DC)		

1) Speed value for coding both digital inputs with "high active"

**Information** The logic for the digital inputs may be inverted. Depending on the parameter setting (e.g. **Coding DIN 6** M0128), the input is either **High active** or **Low active**. Default setting is **High active**.

#### Configuration of analogue input for speed

For setting of parameter **Sp. source...** = **Analogue input**.

An analogue input (AIN 1 or AIN 2) has to be configured as described to be able to use an external (analogue) speed setpoint.

Required user level: **Specialist (4)**.

**M ▶** **Device configuration** M0053  
**I/O interface** M0139  
**Analogue inputs** M0389  
**Signal AIN 1** M0135  
**Signal AIN 2** M0138

**Example** Use analogue input AIN 1 for speed setpoint:

Parameter **Signal AIN 1** M0135 = **Interface speed**

**Information** The speed range for the analogue input is determined via parameters **Speed rem. min.** M1936 and **Speed rem. max** M1937.

### 8.1.2. Speed for constant (internal) speed setpoint: set

For setting of parameter **Sp. source...** (internal speed setpoint)

- **Sp. source...** = **Internal 1/Internal 2/Internal 3/Internal 4**
- **Sp. source...** = **2 DigIn: "Internal (1-4)"**

If the actuator is controlled via an external speed source, the internal speed values described here will not have an impact on the operation behaviour.

**M ▶** **Customer settings** M0041  
**Speed functions** M1699  
**Speed internal1** M1930  
**Speed internal2** M1931  
**Speed internal3** M1932

### Speed internal 4 M1933

**Default values:** 45 rpm

**Setting range:** The adjustable speed range is indicated on the actuator name plate.

#### 8.1.3. Speed range for analogue input: set

This setting is only effective if one of the speed sources is either set to **Analogue input** or **Fieldbus**.

M ▶ **Customer settings** M0041  
**Speed functions** M1699  
**Speed rem. min.** M1936  
**Speed rem. max** M1937

**Default values:**

**Speed rem. min.** = 6 rpm ( $\pm$  0/4 mA)

**Speed rem. max** = 60 rpm ( $\pm$  20 mA)

**Setting values:**

**Speed rem. min.** = 6 ... 240 rpm (revolutions/minute)


**Speed rem. max** = 6 ... 240 rpm (revolutions/minute)

The adjustable speed range is indicated on the actuator name plate.

#### 8.1.4. Time for speed increase and time for speed reduction at pivot points

The transition time from a low to a high speed can be set. This applies e.g. to speed transition within pivot point range. Refer to <Speed profile>.

Figure 33: Example of time for speed increase



n Output speed  
P Pivot point  
t Operating time (travel)  
t<sub>↑</sub> Time for speed increase

#### Set time for speed increase

M ▶ **Customer settings** M0041  
**Speed functions** M1699  
**Time speed incr.** M1769

**Default values:**

**Time speed incr.** = 0.2 s (seconds) from lower to higher speed


**Setting ranges:**

**Time speed incr.** = 0.1 – 10.0 (seconds)

**8.1.5. Speed reduction before reaching end positions OPEN/CLOSED (soft stop in end positions)**

Prior to reaching the end position, the speed can be linearly reduced within a programmable range.

Figure 34: Example of speed reduction in end positions



$n$  Current speed in direction OPEN/CLOSE

$n_z$  Target speed for end positions

$\Delta$  Speed reduction range before end positions

**Activate speed reduction before reaching end positions**

Required user level: **Specialist (4)** or higher.

- M ▶ Customer settings M0041  
Speed functions M1699  
Speed adapt.prior end M1906  
Speed red.pr.end pos. M1903

**Default value:** Function active

**Setting values:**

Function not active <Speed reduction range> function deactivated.

Function active <Speed reduction range> function activated.

**Adjust speed reduction range before reaching end position**

Within this range before the end position, the current speed will be linearly reduced to the target speed (Targ.speed end pos. M1905 parameter).

**Information** If the current speed is lower than the target speed, the speed is increased to the target speed!

- M ▶ Customer settings M0041  
Speed functions M1699  
Speed adapt.prior end M1906  
Speed red. range M1904

**Default value:** 5.0 %

**Setting range:** 0.0 ... 25.0 % (in % before reaching the end position, in relation to the full travel)

**Set target speed before reaching end position**

The actuator runs to the end position at the target speed set by means of this parameter.

- M ▶ Customer settings M0041  
Speed functions M1699  
Speed adapt.prior end M1906

Targ.speed end pos. M1905

**Default values:** 8 (rpm)

**Setting range:** 6 ... 240 rpm (revolutions/minute)

The adjustable speed range is indicated on the actuator name plate.

## 8.2. Speed profile


**Properties** The <Speed profile> function is used to change the actuator speed to a new predefined value once the pivot point is reached. This way, different speed value settings of up to ten sections across the overall travel (separately for each direction of operation OPEN/CLOSE, if required) can be made. Thus, a valve specific speed profile can be defined across the travel.

The speed between two pivot points is linearly interpolated (straight line). The speed before to an end position (OPEN/CLOSED) to the first/last pivot point and vice versa is constant (linearly even) to the first/last pivot point speed. Speed reduction prior to end positions (parameter ) is not active.

The speed profile for EMERGENCY operations can be deactivated as desired.

**Application** This function is used for special applications to avoid pressure surges. Pressure surges might occur e.g. in case of a quick change of flow speed e.g. when quickly closing a gate valve.

Figure 35: Example of a speed profile



**Information** The speed profile can also be used for modulating actuators with activated positioner. Refer to <Positioner> chapter.

### 8.2.1. Speed profile: activate

Required user level: Specialist (4) or higher.

M ▷ **Device configuration** M0053  
**Application functions** M0178  
**Activation** M0212  
**Speed profile** M2122

**Default value:** Function not active

**Setting values:**

**Function not active** <Speed profile> function deactivated.

Function active <Speed profile> function activated.

### 8.2.2. Operation mode for speed profile: set

The speed values set at pivot points can be set identically or individually for both operation directions (OPEN/CLOSE).

M ▷ Customer settings M0041  
Speed profile M2065  
Speed profile mode M2116


Default value: Different profile

Setting values:

**Different profile** Speed values at each pivot point can be set individually for each operation direction (OPEN/CLOSE).

**Identical profile** Identical speed values for both operation directions. This setting copies the preset speed values in operation direction OPEN to the pivot points in operation direction CLOSE.

Figure 36: Example: Different speed profile for operation direction OPEN/CLOSE



### 8.2.3. Pivot points for speed profile: define

Up to nine pivot points can be defined for each operation direction (OPEN/CLOSE)

M ▷ Customer settings M0041  
Speed profile M2065  
Pivot points OPEN M2067  
Pivot points CLOSE M2066

**Information** Pivot points in operation direction CLOSE are only visible if the profile is different (parameter setting Speed profile mode = Different profile).

#### Activate pivot points

At least one pivot point must be activated to use the speed profile.

### Example: Activate pivot point 1 in operation direction OPEN

M ▶ Customer settings M0041  
Speed profile M2065  
Pivot points OPEN M2067  
Pivot point 1 OPEN M2125  
Pivot point 1 OPEN M2076

#### Setting values:

Function active <Speed profile> function is activated for the pivot point. When reaching the pivot point, the actuator changes the speed to the value preset for this pivot point.

Function not active <Speed profile> function is deactivated for the pivot point. The actuators passes the pivot point without modifying the speed.

#### Define positions of pivot points

Each pivot point can be set to a value between 0 % and 100 % of the travel.

**Information** The position of pivot points must be in ascending order (e.g. position 1 before position 2). If this is not the case, the actuator cannot be operated and actuators controls generate a fault signal: Config.fault speed prof.

#### Define pivot points for operation direction OPEN:

M ▶ Customer settings M0041  
Speed profile M2065  
Pivot points OPEN M2067  
Pivot point 1 OPEN M2125  
...  
Pivot point 9 OPEN M2133

Parameters for setting the positions (with default values):

Pivot 1 position OPEN	M2096	=10.0 %
Pivot 2 position OPEN	M2097	=20.0 %
Pivot 3 position OPEN	M2098	=30.0 %
Pivot 4 position OPEN	M2099	=40.0 %
Pivot 5 position OPEN	M2100	=50.0 %
Pivot 6 position OPEN	M2101	=60.0 %
Pivot 7 position OPEN	M2102	=70.0 %
Pivot 8 position OPEN	M2103	=80.0 %
Pivot 9 position OPEN	M2104	=90.0 %

**Setting range:** 0.0 ... 100.0 % (in % before the end position, in relation to the full travel)

#### Define pivot points for operation direction CLOSE:

M ▶ Customer settings M0041  
Speed profile M2065  
Pivot points CLOSE M2066  
Pivot point 1 CLOSE M2134  
...  
Pivot point 9 CLOSE M2142

Parameters for setting the positions (with default values):

Pivot 1 position CLOSE	M2105	=10.0 %
Pivot 2 position CLOSE	M2106	=20.0 %
Pivot 3 position CLOSE	M2108	=30.0 %
Pivot 4 position CLOSE	M2109	=40.0 %
Pivot 5 position CLOSE	M2110	=50.0 %
Pivot 6 position CLOSE	M2111	=60.0 %
Pivot 7 position CLOSE	M2112	=70.0 %
Pivot 8 position CLOSE	M2113	=80.0 %

Pivot 9 pos. CLOSE M2114 =90.0 %

**Setting range:** 0.0 ... 100.0 % (in % before the end position, in relation to the full travel)

### Set speeds for pivot points

**Information** For **multi-turn actuators**, parameters for setting the **speeds** are displayed (according to description in this section). For **part-turn actuators**, parameters for setting the **operating times** are displayed (refer to section <Operating times for pivot points: set>)

### Set speeds for operation direction OPEN:

M ▶ Customer settings M0041  
     Speed profile M2065  
     Pivot points OPEN M2067  
         Pivot point 1 OPEN M2125  
         ...  
         Pivot point 9 OPEN M2133

Parameters for setting speeds:

Pivot 1 speed OPEN M1969  
 Pivot 2 speed OPEN M1971  
 Pivot 3 speed OPEN M1973  
 Pivot 4 speed OPEN M1975  
 Pivot 5 speed OPEN M1977  
 Pivot 6 speed OPEN M1979  
 Pivot 7 speed OPEN M1981  
 Pivot 8 speed OPEN M1983  
 Pivot 9 speed OPEN M2072

**Default value:** 45.0 rpm (for all pivot points)

**Setting range:** 6 ... 240 rpm (revolutions/minute). The adjustable speed range is indicated on the actuator name plate.

### Set speeds for operation direction CLOSE:

M ▶ Customer settings M0041  
     Speed profile M2065  
     Pivot points CLOSE M2066  
         Pivot point 1 CLOSE M2134  
         ...  
         Pivot point 9 CLOSE M2142

Parameters for setting speeds:

Pivot 1 speed CLOSE M1970  
 Pivot 2 speed CLOSE M1972  
 Pivot 3 speed CLOSE M1974  
 Pivot 4 speed CLOSE M1976  
 Pivot 5 speed CLOSE M1978  
 Pivot 6 speed CLOSE M1980  
 Pivot 7 speed CLOSE M1982  
 Pivot 8 speed CLOSE M1984  
 Pivot 9 speed CLOSE M2073

**Default value:** 45.0 rpm (for all pivot points)

**Setting range:** 6 ... 240 rpm (revolutions/minute). The adjustable speed range is indicated on the actuator name plate.

## 8.3. Intermediate positions

**Conditions** The actuator is equipped with a position transmitter.



- Characteristics**
- With the actuator controls, up to 8 intermediate positions can be set to any value between 0 % and 100 % of the travel.
  - Each intermediate position can be activated or deactivated individually.
  - When reaching an intermediate position, a signal can be generated.
  - A hysteresis can be defined for each pivot point.

### 8.3.1. Intermediate positions of pivot points: define

Each intermediate position can be set to a value between 0 and 100 % of the travel.

M ▶ Customer settings M0041  
Intermediate positions M0143  
Pivot points M0160  
Pivot point 1 M0249

**Default values:** 0.0 % for all 8 intermediate positions

**Setting range:** 0.0 % (CLOSED) to 100.0 % (OPEN) of the travel

**Information** The pivot points also apply to the <Operation profile> function.

### 8.3.2. Signal behaviour of intermediate positions: set

Reaching a pivot point (intermediate position) can be signalled:

- via fieldbus (refer to separate operation instructions)
- via indication lights (LEDs) of the local controls or
- via output contacts

Each pivot point (intermediate position) can be assigned a specific signal behaviour.

M ▶ Customer settings M0041  
Intermediate positions M0143  
Signal behaviour M0266  
Signal behaviour 1 M0269

**Default value:** No signal

**Setting values:**





- No signal
- C  O
- C  O
- C  O
- Behaviour **A**: "Off", intermediate position is not signalled.
- Behaviour **B**: Signal is active from reaching the pivot point (P) up to end position OPEN (100 %)
- Behaviour **C**: Signal is active from end position CLOSED (0 %) until reaching the pivot point (P).
- Behaviour **D**: When passing the pivot point (P), a pulse signal is issued.

Figure 37: Signal behaviour (A to D) of the intermediate positions



**Special characteristics of B, C and D**

Behaviour of **B** and **C**: The signal is directly activated when reaching the set pivot point (P).

Behaviour **D**: The signal is activated shortly before reaching the set pivot point (P). The switch-on point is determined by pulse duration (+/- range around the pivot point). Pulse duration depends on parameter **Outer dead band M0148** and amounts to 1.0 % of the travel for default setting.

**Information** For behaviours B and C, the signal might be omitted if, e.g. when using a positioner, pivot point (P) is not fully reached due to the dead band. In this case, behaviour D can be selected as the dead band is considered.


**8.3.3. Hysteresis for intermediate positions: set**

The hysteresis determines the **tripping point** of the signal.

**Example** Parameter **Pivot point 6 M0253** is set to 50.0 % of the travel.

Parameter **Hysteresis 6 M0282** is set to 1.0 %.

Figure 38: Signal behaviour B, C, D for hysteresis = 1 %



P1 Switching on point (●)

P2 Switch-off point (○)

pT Pulse duration = 2 times XT + hysteresis

Required user level: **AUMA (6)**.

**M ▶** **Customer settings** **M0041**  
**Intermediate positions** **M0143**  
**Hysteresis** **M0267**  
**Hysteresis 1** **M0277**

**Default values:** 0.5 % for all 8 positions

**Setting range:** 0.0 % to 5.0 % of the travel (from OPEN to CLOSED)

**Information** For signal behaviour D, the value XT (parameter **Outer dead band M0148**) determines pulse duration pT and influences **switch-on point P1**.

**8.4. Operation profile (operation behaviour) for intermediate positions**

**Conditions** Function <Positioner>, parameter **Positioner M0158** = **Function active** (Required user level: **Specialist (4)** or higher)

**Characteristics** The function <Operation profile> can be used to define the operation behaviour of the actuator when reaching an end position. Example: The actuator stops and only continues its operation after another operation command.

This function is required in special applications to avoid water hammer, possibly also in combination with the timer.

#### 8.4.1. Operation profile: activate

Required user level: **Specialist (4)** or higher.

M ▶ **Device configuration** M0053  
**Application functions** M0178  
**Activation** M0212  
**Operation profile** M0294

**Default value:** Function not active

**Setting values:**

**Function not active** Function <Operation profile> deactivated.  
**Function active** Function <Operation profile> activated.

#### 8.4.2. Operation profile for intermediate positions (pivot points): set

When reaching an intermediate position, the operation behaviour of the actuator may be set.

M ▶ **Customer settings** M0041  
**Intermediate positions** M0143  
**Operation behaviour** M0257  
**Operation behaviour 1** M0258

**Default value:** Off

**Setting values:**

**Off** No intermediate stop, actuator continues the operation.

**Stop in OPEN**

- Actuator stops at pivot point during operation in direction OPEN.
- The operation command has to be cleared by means of the STOP command and a new operation command has to be sent to resume operation.
- This function is not active in operation mode Remote SETPOINT.

**Stop in CLOSED**

- Actuator stops at pivot point during operation in direction CLOSE.
- The operation command has to be cleared by means of the STOP command and a new operation command has to be sent to resume operation.
- This function is not active in operation mode Remote SETPOINT.

**Stop in OPEN & CL.**

- Actuator stops automatically upon reaching the pivot point.
- The operation command has to be cleared by means of the STOP command and a new operation command has to be sent to resume operation.
- This function is not active in operation mode Remote SETPOINT.

**Off time in OPEN** Actuator stops at pivot point during operation in direction OPEN. If an operation command in direction OPEN is present at the end of the pause time, the actuator resumes operation into direction OPEN. If an operation command in direction CLOSE is present during the pause time, the pause is aborted and operation into direction CLOSE resumed.

**Off time in CLOSED** When reaching the pivot point, the actuator stops during operation in direction CLOSE. If an operation command in direction CLOSE is present at the end of the pause time, the actuator resumes operation into direction CLOSE. If an operation command in direction OPEN is present during the pause time, the pause is interrupted and operation into direction OPEN resumed.

**Off time in OPEN & CL.** Actuator stops automatically upon reaching the pivot point. If an operation command in direction OPEN or CLOSE is present at the end of the pause time, the actuator resumes operation depending on the operation command.

**Information** The actuator stops for each activated intermediate position for which operation behaviour **Stop in OPEN**, **Stop in CLOSED** or **Stop in OPEN & CL.** is assigned.

**8.4.3. Off times for intermediate positions (pivot points): set**

An off time can be defined for each pivot point.

If a pivot point is reached with the operation behaviour **Off time in OPEN**, **Off time in CLOSED** or **Off time in OPEN & CL.**, the actuator controls generate a signal during off time: **Operation pause active**

Required user level: **Specialist (4)** or higher.

M ▶ **Customer settings** M0041  
**Intermediate positions** M0143  
**Off times** M0268  
**Off time 1** M0285

**Default values:** 00:01.0 min:s (1 second)

**Setting ranges:** 00:00.2 ... 30:00.0 min : s (0.2 seconds – 30 minutes)

**8.5. Two-wire control**

- Conditions**
- <Additional inputs> or additional <parallel interface>
  - Operation mode **Remote** (Selector switch = position **Remote control**).

**Characteristics** With the <Two-wire control> function, the actuator can be operated to end position OPEN or CLOSED via **one** digital input.

**Information** In this function, the actuator only reacts to commands via the input **OPEN / CLOSE**. Other inputs to which the operation commands OPEN, STOP, CLOSE were assigned, do not have any function.

**Execute operation commands via digital input:**

Designation of digital input **OPEN / CLOSE**

(Wiring diagram designation: OPEN / CLOSE)

- Default setting**
- Input **OPEN / CLOSE** = **low level** (0 V DC or input open):  
Actuator runs in direction CLOSE.
  - Input **OPEN / CLOSE** = **high level** (standard: +24 V DC):  
Actuator runs in direction OPEN.

**Configuration of digital input**

For the two-wire control, a digital input for the **OPEN / CLOSE** signal has to be configured.

Required user level: **Specialist (4)**

M ▶ **Device configuration** M0053  
**I/O interface** M0139  
**Digital inputs** M0116

**Example** Use input DIN 5 for signal **OPEN / CLOSE**:

**Parameter:** **Signal DIN 5 M0122** = **OPEN/CLOSE**

**Information** The logic for the digital inputs may be inverted. Depending on the parameter setting (e.g. **Coding DIN 6 M0128**), the input is either **High active** or **Low active**. Default setting is **High active**.

**8.6. Positioner (operation mode Remote SETPOINT)**

**Conditions** This function requires one of the following equipments within the actuator:

- Electronic control unit (non-intrusive version)
  - Potentiometer
  - Electronic position transmitter EWG/RWG
- Further conditions for the positioner operation mode:
- Positioner enabled and activated.

- Operation mode **Remote** (selector switch = position **Remote control**).
- Characteristics** The positioner records setpoint position E1 and actual position value E2 for comparison. Depending on the detected deviation, the actuator motor then runs in direction OPEN or CLOSE.
- Information**
- If the actuator is controlled via a setpoint (e.g. 0 – 20 mA), the status indication **S0003** on the display shows both setpoint position E1 and actual position value E2.
  - If the status indication **S0003** only shows the actual position value E2, OPEN-CLOSE control is active and there is no setpoint control via the positioner. In this case, you have to change-over to setpoint control first, refer to <Change-over between OPEN-CLOSE control and setpoint control> chapter.

#### 8.6.1. Positioner: activate

Required user level: **Specialist (4)** or higher.

M ▶ **Device configuration** M0053  
**Application functions** M0178  
**Activation** M0212  
**Positioner** M0158

**Default value:** Function not active

**Setting values:**

**Function not active** Function <Positioner> deactivated.  
**Function active** Function <Positioner> activated.

#### 8.6.2. Adaptive behaviour: activate deactivate

Adaptive positioning may reduce the number of starts and compensate for the overrun of the actuator.

M ▶ **Customer settings** M0041  
**Positioner** M0145  
**Adaptive behaviour** M0147

**Default value:** Adaptive I

**Setting values:**


**Off** Adaptive behaviour switched off.  
**Adaptive I** Adaptive behaviour for precise positioning (high positioning accuracy).

Due to the inertia of both actuator and valve, the valve position changes only slightly after switching off the actuator (overrun). The positioner determines the resulting error between setpoint and actual value for both directions and automatically adapts the inner dead bands  $X_i$  and therefore switching point P2.

On the basis of the determined inner dead bands  $X_i$  and the set hysteresis (parameters **Posit. hyst. OPEN** M0598 or **Posit. hyst. CLOSE** M0599), the outer dead bands  $X_T$  are automatically determined.

This reduces the error caused by the overrun after only a few operations and a high positioning accuracy is achieved.

Figure 39: Positioner positioning behaviour



- E1 Setpoint  
 E2 Actual value  
 P1 Switch-on point  
 P2 Switch-off point in direction OPEN  
 P3 Setpoint reached  
 $X_T$  Max. error (outer dead band)  
 $X_{i1}$  Overrun in direction OPEN (inner dead band OPEN)  
 $X_{i2}$  Overrun in direction CLOSE (inner dead band CLOSE)

**Adaptive II** Contrary to adaptive positioner 1, adaptive positioner 2 will not be subject to oscillation. The positioner detects overshooting and enlarges the inner dead band in steps of 0.1 % until the overshooting is cancelled. After entering the idle state, the inner dead band will be gradually reduced after a certain time (10.6 s).

### 8.6.3. Overrun (inner dead band): set manually

The inner dead band determines the switch-off point of the actuator and, therefore, influences the overrun.

The inner dead band may be set individually for the directions OPEN and CLOSE.

Manual setting is only possible if the adaptive behaviour, parameter **Adaptive behaviour M0147**, is switched off.

- M ▶** **Customer settings M0041**  
     **Positioner M0145**  
         **Dead band OPEN M0234**  
         **Dead band CLOSE M0235**

**Default values:** 0.5 % (for dead band OPEN and CLOSE)

**Setting ranges:** 0.0 % to 10.0 % (for dead band OPEN and CLOSE)

- Information**
- Inner dead bands may not be set wider than outer dead bands.
  - Inner dead bands may not be set too narrow as this may cause unnecessary switching procedures (premature wear) or oscillation of the actuator.

### 8.6.4. Max. error variable (outer dead band): set manually

The outer dead band determines the switching-on point of the actuator.

The motor starts if the actual value (input signal E2) or a change in setpoint is higher than the maximum error variable determined by the outer dead band.

Manual setting is only possible if the adaptive behaviour, parameter **Adaptive behaviour M0147**, is switched off.

M ▶ Customer settings M0041  
Positioner M0145  
Outer dead band M0148

**Default value:** 1.0 %

**Setting range:** 0.1 – 10.0 %

#### 8.6.5. Dead time: set

The dead time prevents the operation to a new setpoint position within a pre-determined time.

M ▶ Customer settings M0041  
Positioner M0145  
Dead time M0149

**Default value:** 3.0 s

**Setting range:** = 0.2 – 60.0 (seconds)

**Information** Actuator controls ensure that the max. permissible number of starts of the actuator is not exceeded. This can be achieved by setting the dead time to a sufficiently high value.

#### 8.6.6. Hysteresis for positioner: set

The hysteresis determines the switching accuracy. It can be used to reduce the number of starts for example.

This setting can only be made if the adaptive behaviour, parameter **Adaptive behaviour** M0147, is set to **Adaptive I**.

M ▶ Customer settings M0041  
Positioner M0145  
Posit. hyst. OPEN M0598  
Posit. hyst. CLOSE M0599

**Default values:** 0.5 % for OPEN and CLOSE

**Setting range:** 0.2 % to 5.0 % of travel (from OPEN to CLOSED)

#### 8.6.7. Closing fully/opening fully (end position tolerance for setpoint)

If the end positions cannot be reached due to inaccurate analogue setpoint signals (0/4 mA or 20 mA), a tolerance for the setpoint within the end position range can be set. If the tolerance is exceeded or not reached, the actuator continues the operation until the full end position has been reached. This ensures that the actuator opens and closes fully.

M ▶ Customer settings M0041  
Positioner M0145  
Tolerance CLOSE M0150  
Tolerance OPEN M0151

**Default values:**

Tolerance CLOSE = 0.0 %

Tolerance OPEN = 100.0 %

**Setting ranges:** (in percent of the travel)

Tolerance CLOSE = 0.0 – 5.0 %

Tolerance OPEN = 95 – 100.0 %

#### 8.6.8. Setting range: limit


Setting range can be limited in directions OPEN and/or CLOSE.

This prevents end position(s) OPEN and/or CLOSED from being approached in modulating duty. The actuator stops when reaching the set limit value.



For OPEN-CLOSE control (LOCAL or REMOTE OPEN-CLOSE operation mode), this limitation is not active. The valve can then be run into the end positions either via the local controls or from remote.

Figure 40: Limitation of setting range



[1] Permissible actuator travel for setpoint control

[2] Permissible actuator travel for OPEN-CLOSE control

#### Activate limitation

M ▷ Customer settings M0041  
Positioner M0145  
Limit setting range M0845

Default value: Function not active

#### Setting values:

Function not active Limitation deactivated.

Function active Limitation activated.

#### Adjust setting limits

M ▷Parameters Customer settings M0041  
Positioner M0145  
Limit OPEN M0162  
Limit CLOSE M0161

#### Default values:

Limit OPEN = 100.0 %

Limit CLOSE = 0.0 %

Setting ranges: 0.0 ... 100.0 % of setting range

### 8.6.9. Speed reduction before reaching setpoint position

**Characteristics** The function adapts the setpoint depending on the error variable compared to the setpoint. In case of a low error variable compared to the setpoint, the actuator runs at low speed. For a high error variable, the actuator runs at maximum speed. The maximum speed is then equal to the current speed.

**Application** For modulating duty with high positioning accuracy.

#### Activate speed reduction before reaching setpoint position

Required user level: Specialist (4) or higher.

M ▷ Customer settings M0041  
Speed functions M1699  
Speed functions M2148  
Speed red.prior setp. M0835

Default value: Function active

#### Setting values:

Function not active <Speed reduction> function deactivated.



**Function active** <Speed reduction> function activated.

#### Set speed reduction range

Range in relation to the setpoint, where the speed – depending on the deviation from the setpoint – is either reduced or increased from the current speed to the “target speed” (parameter **Target speed at setp.** M1939).

**M ▶** **Customer settings** M0041  
**Speed functions** M1699  
**Speed functions** M2148  
**Speed red. range** M0836

**Default value:** 10.0 %

**Setting range:** 2.0 – 20.0 (deviation from the setpoint in %)

#### Set target speed before reaching setpoint position

Minimum speed for modulating duty.

**M ▶** **Customer settings** M0041  
**Speed functions** M1699  
**Speed functions** M2148  
**Target speed at setp.** M1939

**Default values:** 10 rpm

**Setting range:** 6 ... 240 rpm

The adjustable speed range is indicated on the actuator name plate.

### 8.6.10. Change-over between OPEN - CLOSE control and setpoint control

For actuators equipped with a positioner, it is possible to change over between **OPEN - CLOSE control** (Remote OPEN-CLOSE) and **setpoint control** (Remote SETPOINT).

#### Change-over via fieldbus command:

For control via fieldbus interface, the change-over is done via fieldbus command **Fieldbus SETPOINT**.

#### Switching behaviour:

- **Fieldbus SETPOINT** = 0 = Remote OPEN-CLOSE:  
The actuator reacts to operation commands OPEN, STOP, CLOSE
- **Fieldbus SETPOINT** = 1 = Remote SETPOINT:  
The actuator reacts to a setpoint signal (e.g. 0,0 ... 100,0 %)

If the operation commands are not transmitted via fieldbus commands, but via <Additional inputs> or additional <Parallel interface>, a digital input for the MODE signal has to be available and configured for change-over.

#### Configuration of digital input

Required user level: **Specialist (4)**.

**M ▶** **Device configuration** M0053  
**I/O interface** M0139  
**Digital inputs** M0116

**Example** Use input DIN 1 for change-over:

**Parameter:** **Signal DIN 1** M0118

**Setting value:** **MODE** (wiring diagram designation: MODE)

**Information** The logic for the digital inputs may be inverted. Depending on the parameter setting (e.g. **Coding DIN 4** M0126), the input is either **High active** or **Low active**. Default setting of **MODE** input is **Low active**.

**Change-over via digital input MODE****Switching behaviour for coding** Low active:

(Default factory setting)

- Input **MODE** = **low level** (0 V DC or input open) = Remote SETPOINT  
The actuator reacts to a setpoint signal (e.g. 0/4 – 20 mA)
- Input **MODE** = **high level** (standard: +24 V DC) = Remote OPEN-CLOSE:  
The actuator reacts to operation commands OPEN, STOP, CLOSE.

**8.6.11. Input of setpoint position**

In Modbus RTU version, the setpoint position is transmitted via the fieldbus interface, channel 1 or channel 2.

**Actuator controls with two additional analogue inputs**

The setpoint position can also be fed via an analogue input. In this case, one of the inputs AIN 1 or AIN 2 has to be configured as setpoint position.

Required user level: **AUMA (6)**.

**M ▷** Device configuration **M0053**  
           I/O interface **M0139**  
           Analogue inputs **M0389**  
             Signal AIN 1 **M0135**  
             Signal AIN 2 **M0138**

**Setting value:** Setpoint position

**Information** The AC will only react to the additional analogue input if high level (standard: +24 V DC) is present at the I/O INTERFACE input (refer to wiring diagram).

**8.6.12. Input range of setpoint position**

The input range defines the signal range, i.e the initial and the end value of the setpoint signal. For example: 0 – 20 mA, 4 – 20 mA or another value.

In Modbus RTU version, the input range for setpoint position is set to 0.0 % ... 100.0 %.

**Actuator controls with two additional analogue inputs**

If the setpoint position is fed via an analogue input, the signal range of the respective input (AIN1 or AIN2) has to be correctly set. The configuration is then made via parameters.

Required user level: **Specialist (4)** or higher.

**M ▷** Device configuration **M0053**  
           I/O interface **M0139**  
           Analogue inputs **M0389**  
             Low limit AIN 1 **M0133**  
             High limit AIN 1 **M0134**

**Default values:**

Low limit AIN 1 = 0 mA

High limit AIN 1 = 20 mA

**Setting values:** 0 ... 20 mA

**Information** If set accordingly, the lower limit **Low limit AIN 1** can be used for monitoring the setpoint signal. Refer to <Failure behaviour on loss of signal>.

**8.6.13. Split Range operation**

- Requirements**
- <Additional inputs> or additional <Parallel interface>.
  - <Positioner> function must be enabled and activated:

**Function** In Split Range operation, a setpoint position E1 can be shared by up to three positioners. A typical application example is a pipeline with a by-pass. The actuator mounted on the by-pass reacts in the lower limit (e.g. 0 – 10 mA), the actuator on the main valve in the upper limit (e.g. 10 – 20 mA). If the setpoint position is within the setpoint range defined for the individual actuator, the actuator behaviour will be identical to standard positioner operation. If the setpoint position is higher or lower than the upper or the lower limit of the setpoint range of the respective actuator, the actuator will run to positions OPEN or CLOSED.

The upper and lower limit of the respective actuator is defined via the analogue input. (<Input range of setpoint position>)

In addition, the upper and lower limit of the total target value (valid for all actuators grouped in a split range operation).

#### Activate split range operation

Required user level: **Specialist (4)** or higher.

**M ▶** **Device configuration** M0053  
**Application functions** M0178  
**Activation** M0212  
**Split range operation** M01650

**Default value:** Function not active

**Setting values:**

**Function not active** <Split range operation> function deactivated.

**Function active** <Split range operation> function activated.

#### Set total target value range

The set lower limit of total target value is used as failure source for failure behaviour during split range operation: <Failure behaviour on loss of signal>

**M ▶** **Customer settings** M0041  
**Positioner** M0145  
**Low limit target value** M01651  
**High limit target value** M01652

**Default values:**

**Low limit target value** = 0.0 mA

**High limit target value** = 20.0 mA

**Setting ranges:** 0.0 ... 20.0 mA

## 8.7. Process controller

**Requirements** This function requires one of the following equipments within the actuator:

- Electronic control unit with MWG (non-intrusive version)
- Potentiometer
- Electronic position transmitter EWG/RWG


Further conditions for the process controller operation mode:

- Process controller enabled and activated.
- Operation mode **Remote** (Selector switch = position **Remote control**).

**Characteristics** The following figure illustrates the function of the process controller:

The process controller [2] receives the process setpoint E7 and the actual process value E4 (e.g. from a sensor). On the basis of both values, the process controller calculates the position setpoint E1 for positioner [3]. In turn, the positioner [3] compares this target setpoint with the actual position value E2 of the valve and issues the operation commands (OPEN - CLOSE) for the actuator.

Figure 41: Process controller function



- [1] Actuator controls
- [2] Process controller
- [3] Positioner
- [4] Actuator
- [5] Position transmitter e.g. EWG/RWG/MWG
- [6] Sensor
- [7] Valve
- E1 Position setpoint (internal)
- E2 Actual position value
- E4 Actual process value
- E7 Process setpoint

**Application** The process controller can be used to control pressure, flow or flow rates, flow levels and temperature.

#### 8.7.1. Process controller activation

Required user level: **Specialist (4)** or higher.

**M ▶** **Device configuration** M0053  
**Application functions** M0178  
**Activation** M0212  
**Process controller** M0741

**Default value:** Function not active

**Setting values:**

**Function not active** <Process controller> function deactivated.

**Function active** <Process controller> function activated.

#### 8.7.2. Process controller: set modulating behaviour

Three controller types are available to ideally adapt the modulating behaviour of the process controller to the respective application.


M▷ Customer settings M0041  
Process controller M0742  
Modulating behaviour M0887

Default value: PI controller

Setting values:

**P controller** P controllers immediately react to an error variable (i.e. actively) and amplify the input signal (error variable) proportionally to the set amplification. Setting parameter: Proport. gain  $K_p$  M0744


Figure 42: Step response of P controller



**P controller application** For uncritical closed-loop applications allowing to accept continuous error variables in the event of failures, e.g. pressure, flow, filling level and temperature control.

**PI controller** PI controllers consist of a P fraction immediately (actively) reacting to an error variable and an I fraction for chronological integration of the input signal (error variable). Due to the additional time constant of the I fraction, the output value takes more time to reach the target status (i.e. inertia of control loop response) whereas positioning accuracy increases at the same time (lower control deviation). Parameters for setting the time constant: Reset time  $T_i$  M0745


Figure 43: Step response of PI controller



**PI controller application** Quick control circuits not allowing continuous error variables, e.g. pressure, temperature and ratio control.

**PID controller** Compared to the PI controller, the PID controller has an additional D fraction accounting for changes in the error variable (change rate). The D fraction quickly reacts to changes, even to minor error variables with large output values. Parameter for setting the D fraction: Rate time  $T_d$  M0746

Figure 44: Step response of PID controller



**PID controller use** For precise and highly dynamic control not allowing a continuous error variable.

### 8.7.3. Setpoint source (input for process setpoint)

M▷ Customer settings M0041  
Process controller M0742

**Setpoint source** M0743**Default value:** I/O interface**Setting values:****I/O interface** The process setpoint is defined via an analogue input (AIN 1 or AIN 2) of the I/O interface.**Fieldbus interface** The process setpoint is defined via fieldbus.**Internal setpoint** The process setpoint is generated internally via actuator controls. Parameters **Internal setpoint 1** M0749 / **Internal setpoint 2** M0750**Information** To use internal setpoint 2, a digital input must be configured accordingly.**8.7.4. Behaviour on loss of process setpoint****M ▷** **Customer settings** M0041  
**Process controller** M0742  
**Beh. setpoint failure** M0747**Default value:** Internal setpoint 1**Setting values:****Internal setpoint 1** In case of process setpoint signal loss, actuator controls switch to the internal setpoint 1. Parameter **Internal setpoint 1** M0749**Internal setpoint 2** In case of process setpoint signal loss, actuator controls switch to the internal setpoint 2. Parameter **Internal setpoint 2** M0750**Failure behaviour** In case of process setpoint signal loss, failure behaviour procedure is activated. Parameter **Failure behaviour** M0378**Last setpoint** In case of process setpoint signal loss, the last available process setpoint will still be used as setpoint.**8.7.5. Inverse operation**

As standard, the valve is opened by the modulating actuator as soon as the actual process value falls below the process setpoint. Depending on the process, it may, however, be necessary that the valve closes as soon as the actual process value falls below the process setpoint. In this case, the respective parameters are used to set the process controller to inverse operation.

**M ▷** **Customer settings** M0041  
**Process controller** M0742  
**Inverse operation** M0748**Default value:** Function not active**Setting values:****Function not active** Inverse operation is deactivated.**Function active** Inverse operation is activated.**8.7.6. Internal process setpoint**

An internal process setpoint may be set with this parameter. The internal process setpoint is used if:

- Parameter **Setpoint source** M0743 is set to **Internal setpoint** or
- Parameter **Beh. setpoint failure** M0747 is set to **Internal setpoint 1** or **Internal setpoint 2**.

**M ▷** **Customer settings** M0041  
**Process controller** M0742  
**Internal setpoint 1** M0749  
**Internal setpoint 2** M0750

**Default value:** 50.0 %

**Setting range:** 0.0 ... 100.0 %

### 8.7.7. Setting procedure

The setting of the process controller largely depends on the area of controller application. A PI controller suffices for most applications.

- Procedure**
1. Operate the controller as PI controller, i.e. set the parameters as follows:
    - Proportional gain  $K_p = 1$
    - Reset time  $T_i = 1,000$  s
    - Rate time  $T_d = 0$
  2. Double proportional gain  $K_p$  until the control loop starts to oscillate.
  3. Reduce proportional gain  $K_p$  to 60 % of the set value.
  4. Decrease reset time  $T_i$  until the error variable equals zero.

### 8.7.8. Proportional gain $K_p$ : set

In the event of an error variable, the P portion immediately (i.e. actively) changes the position value proportionally to the error variable.

If a small error variable already requires a major valve position adjustment, the proportional gain  $K_p$  must be increased.

**Information** If the reaction is too extreme (overshoot), the value must be reduced. If the reaction is too weak, the value must be increased.

**M ▶** Customer settings M0041  
 Process controller M0742  
 Proport. gain  $K_p$  M0744

**Default value:** 1.0

**Setting range:** 0.1 ... 10.0

### 8.7.9. Reset time $T_i$ : set

The reset time determines the I portion of the controller. The more inert a system, the higher this value should be set.

- Information**
- Increase  $T_i$  in case of propensity for oscillation.
  - Decrease  $T_i$  if the reactions are excessively delayed.
  - Starting value for fast processes (e.g. pressure): 10 s
  - Starting value for slow processes (e.g. temperature): 1000 s

**M ▶** Customer settings M0041  
 Process controller M0742  
 Reset time  $T_i$  M0745

**Default value:** 1,000 s (seconds)

**Setting range:** 1 ... 1000 s

### 8.7.10. Rate time $T_d$ : set

The rate time determines the D portion of the controller. Typically, no setting is required here ( $= 0$ ), since actuator and valve – due to the operating time – cannot react abruptly to a sudden occurrence of an error variable.

- Information**
- Increase  $T_d$  in case of propensity for oscillation.
  - Initial value for actuators: 0 s

**M ▶** Customer settings M0041  
 Process controller M0742  
 Rate time  $T_d$  M0746

**Default value:** 0 s (seconds)

Setting range: 1 ... 100 s

**8.7.11. Actual value source (input for actual process value)**

M ▶ Customer settings M0041  
 Process controller M0742  
 Actual value source M0756

Default value: I/O interface

**Setting values:**

I/O interface The actual process value is defined via an analogue input (AIN 1 or AIN 2) of the I/O interface.

Fieldbus interface The actual process value is defined via the fieldbus.

**8.7.12. Speed source for actual process value**

The actuator speed for control via the actual process value can be specified by different sources.

M ▶ Customer settings M0041  
 Process controller M0742  
 Speed source PID M1968

Default value: Fieldbus

**Setting values:**

Fieldbus The actuator speed is specified externally, via fieldbus. For this, four constant speed values which may be programmed via fieldbus are available.

Internal 1 – Internal 4 The actuator is controlled with a constant speed. For this, four programmable internal speed values are available. The four internal speed values are programmed via parameters Speed internal1 M1930 – Speed internal 4 M1933.

2 DigIn: "Internal (1-4)" External speed selection. For this setting, two external signals may be used to change between the four internally programmed, constant speeds (Internal 1 – Internal 4).

Two digital inputs have to be configured as control signals for speed selection.

Analogue input The actuator speed is specified/modified externally via an analogue value (e.g. 0 – 20 mA). An analogue input has to be defined as speed source.

The speed range for the analogue input is determined via parameters Speed rem. min. M1936 and Speed rem. max M1937.

**8.8. Stepping mode**

**Conditions** This function requires one of the following equipments within the actuator:


- Electronic control unit (non-intrusive version)
- Potentiometer
- Electronic position transmitter EWG/RWG

**Characteristics**

- With stepping mode, the operating time can be increased for the entire or any portion of the valve travel.
- Stepping mode can be individually activated for the directions OPEN and CLOSE.



Figure 45: Stepping mode



- [1] Stepping range OPEN
- [2] Stepping range CLOSE
- P1 Start of stepping mode
- P2 End of stepping mode
- t1 Operating time for normal operation
- t2 Operating time for stepping mode
- t3 Running time
- t4 Off time

#### 8.8.1. Stepping mode: activate

Stepping mode can be individually activated for the directions OPEN and CLOSE.  
Required user level: **Specialist (4)** or higher.

**M▷** **Device configuration** M0053  
**Application functions** M0178  
**Activation** M0212  
**Timer CLOSE** M0156  
**Timer OPEN** M0206

**Default value:** Function not active

**Setting values:**

**Function not active** Function <Stepping mode> deactivated.  
**Function active** Function <Stepping mode> activated.

#### 8.8.2. Operation mode for stepping mode

Stepping mode can be activated via operation modes Local and/or Remote.

**M▷** **Customer settings** M0041  
**Timer** M0142  
**Step mode CLOSE** M0157  
**Step mode OPEN** M0207

**Default value:** Off both directions

**Setting values:**

**Off** Stepping mode is switched off.

<b>Remote</b>	Stepping mode is active in the operation modes: <b>Remote</b> , <b>Remote II</b> , <b>Fieldbus</b>
<b>Local</b>	Stepping mode is active in the operation modes: <b>Local</b> , <b>Service</b>
<b>Remote and local</b>	Stepping mode is active in the operation modes: <b>Remote</b> , <b>Remote II</b> , <b>Fieldbus</b> , <b>Local</b> , <b>Service</b>
<b>Information</b>	The timer cannot be by-passed in <Operation mode EMERGENCY>.

### 8.8.3. Start and end of stepping mode

Start and end of stepping mode can be individually set for both directions.

**M ▶** **Customer settings** M0041  
**Timer** M0142  
**End stepping CLOSE** M0152  
**Start stepping CLOSE** M0153  
**Start stepping OPEN** M0154  
**End stepping OPEN** M0155

**Default values:**

**End stepping CLOSE** = 0.0 %  
**Start stepping CLOSE** = 100.0 %  
**Start stepping OPEN** = 0.0 %  
**End stepping OPEN** = 100.0 %

**Setting ranges:**

**End stepping CLOSE** = 0.0 – 99.9 %  
**Start stepping CLOSE** = 0.1 – 100.0 %  
**Start stepping OPEN** = 0.0 – 99.9 %  
**End stepping OPEN** = 0.1 – 100.0 %

### 8.8.4. On times and off times

On or off times can be set individually for directions OPEN and CLOSE.

**M ▶** **Customer settings** M0041  
**Timer** M0142  
**On time CLOSE** M0163  
**Off time CLOSE** M0164  
**On time OPEN** M0165  
**Off time OPEN** M0166

**Default values:** 00:05.0 min : s (= 5 seconds; for all on and off times)

**Setting ranges:** 00:01.0 ... 00:05.00.0 min : s (= 1 second up to 30 minutes; for all on and off times)

## 8.9. Modbus interface

### 8.9.1. Bus address (slave address)

The bus address can be entered manually via the push buttons at local controls according to the description below.

**M ▶**  
**Customer settings** M0041  
**Modbus** M0341  
**MD1 slave address** M0342  
**MD2 slave address** M0409

**Default value:** 247

**Setting range:** 1 ... 247

**Information** Parameter **MD2 slave address** is only available if parameter **Redundancy** M0800 is set to **AUMA redundancy I**. For settings **AUMA redundancy II** and **Loop redundancy**, the address of the second channel is automatically assigned automatically: **MD1 slave address** = **MD2 slave address**

### 8.9.2. Baud rate

M ▶

**Customer settings** M0041  
**Modbus** M0341  
**Baud rate** M0343

**Default value:** Auto

**Setting range:** 9.6 ... 115.2 kbit/s

**Information** The baud rate setting must correspond to the setting at the master.

### 8.9.3. Parity/stop bit

M ▶

**Customer settings** M0041  
**Modbus** M0341  
**Parity/stop bit** M0782

**Default value:** Even, 1 stop bit

**Setting ranges:**

Even, 1 stop bit

Odd, 1 stop bit

None, 2 stop bits

None, 1 stop bit

**Information** The parity setting must correspond to the setting at the master.

### 8.9.4. Monitoring time

Monitoring time of Modbus connection

This time should exceed the cycle time of the Modbus data transmission to all connected devices. If no valid Modbus telegram was received within this time, the "DATA EX" status is left and failure behaviour or change-over of the communication channel is initiated, if applicable.

M ▶

**Customer settings** M0041  
**Modbus** M0341  
**Monitoring time** M0781

**Default value:** 15 s (seconds)

**Setting range:** 0 ... 60 s

### 8.9.5. Response timeout

Unless the AUMATIC application provides an answer to a Modbus request within the time set here, the Modbus interface answers this request with Exception Code 6 (Busy Acknowledge).

M ▶

**Customer settings** M0041  
**Modbus** M0341  
**Response Timeout** M0916

**Default value:** 2.5 s (seconds)

**Setting range:** 0.1 ... 5.0 s

**8.9.6. Redundancy**

Redundancy can be entered manually via the push buttons the local controls according to the description below.

M ▷

Device configuration M0054

Modbus M0799

Redundancy M0800

Default value: None

Setting values:

None

No redundancy

AUMA redundancy I

Redundant line topology with universal redundancy behaviour according to AUMA redundancy type I.

AUMA redundancy II

Redundant line topology with universal redundancy behaviour according to AUMA redundancy type II.

Loop redundancy

Redundant loop topology in combination with the SIMA Master Station

Information

For detailed information on redundancy types, refer to Manual Device integration Modbus.

**8.9.7. Response telegrams for AUMA redundancy II**

When using AUMA redundancy II, response telegrams can be sent on both channels.

M ▷

Device configuration M0053

Modbus M0799

Behaviour TxM0801

Default value: Tx active channel

Setting values:

Tx active channel

Response telegrams are only sent via the active channel.

Tx both channels

Response telegrams are sent via both channels, the active and the passive channel.

**8.10. Additional inputs for fieldbus**

Actuator controls with fieldbus interface can be equipped with additional digital and analogue inputs. Depending on the version, up to 6 digital inputs (default: 24 V DC) and two analogue 0/4 –20 mA inputs are available.

If additional inputs are available, operation commands can be sent both via fieldbus and the additional inputs.

For manual change-over between fieldbus interface and the additional inputs, a digital input has to be available and configured.

For automatic change-over (in the event of fieldbus failure), the <Auto change-over I/O (fieldbus failure)> function is required.

**Configuration of additional inputs**

Required user level: Specialist (4).

M ▷

Device configuration M0053

I/O interface M0139

Digital inputs M0116

Analogue inputs M0389

Example

- Use digital inputs DIN 2 to 4 for operation commands:  
Signal DIN 2 M0120 = CLOSE  
Signal DIN 3 M0119 = OPEN  
Signal DIN 4 M0118 = STOP

- Use digital input DIN 6 for manual change-over:  
Signal DIN 6 M0121 = I/O interface (wiring diagram designation: I/O interface)

**Information** The logic for the digital inputs may be inverted. Depending on the parameter setting (e.g. Coding DIN 6 M0128), the input is either **High active** or **Low active**. Default setting is **High active**.

#### Manual change-over via I/O interface input

##### Switching behaviour for coding **High active**

(Default factory setting)

- Input I/O interface = **low level** (0 V DC or input open):  
Actuator controls react to operation commands via fieldbus only.
- Input I/O interface = **high level** (standard: +24 V DC):  
Actuator controls react to additional input signals only.  
Irrespective of the signal assignment of the additional inputs, the fieldbus communication with the DCS will remain intact.

### 8.11. Combination of fieldbus-parallel interface

Actuator controls with fieldbus interface may be additionally equipped with a parallel interface. Depending on the version, up to 6 digital inputs (default: 24 V DC) and up to two analogue 0/4 –20 mA inputs are available via parallel interface.

For this combined version, operation commands can be executed both via fieldbus and the inputs of the parallel interface (I/O interface).

For manual change-over between fieldbus interface and parallel interface, a digital input has to be available and configured.

The <Auto change-over I/O (during bus failure)> function is required for automatic change-over (bus failure).

#### Configuration of I/O interface inputs

Required user level: **Specialist (4)**

M ▶ **Device configuration M0053**  
I/O interface M0139  
Digital inputs M0116  
Analogue inputs M0389

- Example**
- Use digital inputs DIN 2 to 4 for operation commands:  
Signal DIN 2 M0120 = **CLOSE**  
Signal DIN 3 M0119 = **OPEN**  
Signal DIN 4 M0118 = **STOP**
  - Use digital input DIN 6 for manual change-over:  
Signal DIN 6 M0121 = I/O interface (wiring diagram designation: I/O interface)

**Information** The logic for the digital inputs may be inverted. Depending on the parameter setting (e.g. Coding DIN 6 M0128), the input is either **High active** or **Low active**. Default setting is **High active**.

#### Manual change-over via I/O interface input

##### Switching behaviour for coding **High active**

(Default factory setting)

- Input I/O interface = **low level** (0 V DC or input open):  
Actuator controls react to operation commands via fieldbus only.
- Input I/O interface = **high level** (standard: +24 V DC):  
Actuator controls react to parallel interface signals only.  
Irrespective of the signal assignment of the inputs of the parallel interface, the fieldbus communication with the DCS will remain intact.

**Change-over to passive channel**

Required user level: **Specialist (4)** or higher.

- M ▷** **Device configuration** **M0053**  
**Application functions** **M0178**  
**Activation** **M0212**  
**Fieldbus operation** **M1236**

**Default value:** **Commands&feedback**

**Setting values:**

**Commands&feedback** Operation commands can be executed both via fieldbus and the inputs of the parallel interface (I/O interface).

**Feedback only** Operation commands are exclusively permitted via parallel interface (I/O) interface. Fieldbus is only used for feedback signals.

**8.12. Auto change-over I/O (during fieldbus failure)**

**Requirements** The function is only available for a combination of additional bus inputs or parallel interface (I/O) and a fieldbus interface.

**Properties** If this function is activated, automatic change-over to the parallel interface (I/O) will be performed on loss of fieldbus communication.

Change-over is performed before activation of <Failure behaviour> or <EMERGENCY behaviour>.

**Activate auto change-over I/O**

Required user level: **Specialist (4)** or higher.

- M ▷** **Device configuration** **M0053**  
**Application functions** **M0178**  
**Activation** **M0212**  
**Auto change-over I/O** **M0790**

**Default value:** **Function not active**

**Setting values:**

**Function not active** <Auto change-over I/O (fieldbus failure)> function deactivated.

**Function active** <Auto change-over I/O (fieldbus failure)> function activated.

**8.13. Functions for FO cable connection**

**Requirements** FO cable module or FO coupler (for explosion-proof actuators) within actuator controls.

**8.13.1. FO cable monitoring: activate/deactivate**

Actuator controls monitor the FO cable signal for communication, connection and signal strength.

- M ▷** **Device configuration** **M0053**  
**FOC connection** **M0600**  
**FO cable monitoring** **M0709**

**Default value:** **On (not final device)**

**Setting values:**

**On (not final device)** Monitoring is activated.

On loss of FOC connection, the following is signalled: **Wrn FOC**

**Off (final device)** Monitoring is deactivated.

This setting is used if the actuator is the last participant within line topology, or for all actuators within star topology.

### 8.13.2. FO cable topology: check setting

Required user level: .

M ▶

Device configuration M0053

FOC connection M0600

FO cable topology M0637

Default value: Star/line

Setting values:

Star/line Star, line topology

Ring Ring topology

### 8.13.3. FO cable baud rate, check setting

Required user level: .

M ▶

Device configuration M0053

FOC connection M0600

FO cable baud rate M0642

Default value: Auto

Setting values:

Auto Automatic baud rate selection

9.6 kbit/s – 12000 kbit/s Setting depending on fieldbus systems and FO cable module or FO coupler.

### 8.14. By-pass function

**Application** The by-pass function is used, e.g. for district heating pipelines. Under high pipeline pressure, the gate valve of the main valve cannot be used, pressure compensation via by-pass valve is therefore required.

**Requirements** • <Additional inputs> or additional <Parallel interface>.

**Function** Two MOVs – one main valve and one by-pass valve – are linked via enable signals **Bypass Sync In** and **By-pass Sync Out**. Operation commands can only be executed if one of the two actuators sends the enable signal to the other device. Enable depends on the end position. This ensures that only the following operation commands may be executed:

- The main valve can only be operated in directions OPEN or CLOSE if the by-pass valve is in end position OPEN.

Figure 46: Function




Table 10: Main valve reaction to by-pass valve position

By-pass valve		Main valve
Position	Enable signal Bypass Sync OUT	Release (available operation commands)
End position OPEN	High level (release) (Default: +24 V DC)	in directions OPEN and CLOSE
Other position	Low level (interlock) (0 V DC or input open-circuit):	No operation possible <sup>1)</sup>

1) In case of an operation command, the "Interlock by-pass" signal is sent (no release).

Table 11: By-pass valve reactions to main valve position

Main valve		By-pass valve
Position	Enable signal Bypass Sync OUT	Release (available operation commands)
End position CLOSED	High level (release) (Standard: +24 V DC)	in directions OPEN or CLOSE
Other position	Low level (interlock) (0 V DC or input open-circuit):	In direction OPEN or CLOSE <sup>1)</sup>

1) In case of an operation command in direction CLOSE, the "Interlock by-pass" signal is sent (no release).

## EMERGENCY behaviour

The EMERGENCY behaviour of the by-pass function has the same properties as the <EMERGENCY behaviour> function with the following differences:

In an EMERGENCY situation, both actuator controls receive the EMERGENCY signal at the same time. This signal starts the EMERGENCY operation specially defined for the by-pass function. (Parameter **EMCY operation** M0204 is therefore not available in the <EMERGENCY behaviour> function).

### EMERGENCY operation procedure

1. By-pass valve is opened first.
2. Once the by-pass valve is fully opened, the main valve is closed.
3. Once the main valve is fully closed, the by-pass valve is fully opened.

### Configuration of digital inputs

Required user level: **Specialist (4)** or higher.

M ► **Device configuration** M0053  
I/O interface M0139



### Digital inputs M0116

**Example** Use input DIN4 for signal Bypass Sync In:  
Use input DIN6 for signal EMERGENCY:

#### Setting values:

- Signal DIN 5 M0122 = By-pass Sync In  
(wiring diagram designation: BYPASS SYNC IN)
- Signal DIN 6 M0121 = EMERGENCY  
(wiring diagram designation: NOT / EMERGENCY)

**Information** The logic for the digital inputs may be inverted. Depending on the parameter setting (e.g. Coding DIN 6 M0128), the input is either High active or Low active. Default setting is High active.

### Configuration of digital output

Required user level: Specialist (4) or higher.

M ▷ Device configuration M0053  
I/O interface M0139  
Digital outputs M0110

**Example** Use output DOUT6 for signal Bypass Sync Out:

**Parameters:** Signal DOUT 6 M0111

**Setting value:** Bypass Sync Out (wiring diagram designation: BYPASS SYNC OUT)

#### 8.14.1. By-pass function: activate

Required user level: Specialist (4) or higher.

M ▷ Device configuration M0053  
Application functions M0178  
Activation M0212  
By-pass function M0941

**Default value:** Function not active

#### Setting values:

Function not active Bypass function deactivated.

Function active Bypass function activated.

#### 8.14.2. By-pass application: configure

The actuators for the two MOVs (valves) have to be configured according to their application (main or by-pass valve).

M ▷ Customer settings M0041  
By-pass function M0942  
By-pass application M0943

**Default value:** Main valve

#### Setting values:

Main valve Actuator for main valve.

By-pass valve Actuator for by-pass valve.

#### 8.15. Automatic deblocking

**Requirements** This function requires one of the following equipments within the actuator:

- Electronic control unit
- Electronic position transmitter EWG/RWG

This function CANNOT be combined with the functions listed below:

- By-pass function
- Operation profile
- If the setting range was limited for the positioner (parameter **Limit setting range M0845** = Function active)

For actuator controls in SIL version, we DISADVISE using the automatic deblocking function.

**NOTICE****Unexpected starting of actuator!**

*When using automatic deblocking with level-controlled operation command evaluation, unexpected starting of actuator into the wrong direction might occur when trying to eliminate a double-sided torque fault (torque faults in directions OPEN and CLOSE are present at the same time).*

→ Use automatic deblocking only in combination with edge controlled operation command evaluation (parameter **Com. eval. REMOTE M1709**).

**Properties**

In case of torque switch tripping in intermediate position (i.e. prior to reaching the end position), the actuator automatically attempts to reach the end position by operation into the opposite direction and executing the actual operation command once again.

The torque fault signal is suppressed during automatic deblocking. Should torque switching trip again once automatic deblocking is complete, the actuator is switched off and actuator controls signal a torque fault.

**8.15.1. Automatic deblocking function: activate**

Required user level: **Specialist (4)** or higher.

- M ▷ **Device configuration M0053**  
**Application functions M0178**  
**Activation M0212**  
**Automatic deblocking M1678**

**Default value:** Function not active

**Setting values:**

Function not active	Function deactivated.
Function active	Function activated.

**8.15.2. Operation time for operation in opposite direction: set**

The actuator controls remember the first seating position and operate the actuator for the set operation time into opposite direction.

Required user level: **Specialist (4)** or higher.

- M ▷ **Customer settings M0041**  
**Automatic deblocking M1680**  
**Oper. time opposite M1681**

**Default value:** 3 s

**Setting ranges:** 1 ... 60 s (seconds)

**8.15.3. Number of deblocking attempts: set**

Required user level: **Specialist (4)** or higher.

- M ▷ **Customer settings M0041**  
**Automatic deblocking M1680**  
**Deblocking attempts M1682**

**Default value:** 3

**Setting ranges:** 1 ... 5

#### 8.15.4. Tolerance range: set

Tolerance range (+/-) for initial torque seating position, within which a torque fault will be signalled after unsuccessful automatic deblocking.

Required user level: **Specialist (4)** or higher.

M ▷ **Customer settings** M0041  
**Automatic deblocking** M1680  
**Tolerance range** M1683

**Default value:** 10 %

**Setting ranges:** 5 ... 30 % (percentage of operating time into opposite direction)

#### 8.16. Heater system and heaters

Possible components:

- Heater system within the actuator controls
- Heaters within the actuator:
  - Control unit heater in switch compartment
  - Motor heater (within motor housing)

##### 8.16.1. Heater system within the actuator controls

The heater system is generally used for low temperature (in low temperature version up to -60 °C). For an installed heater system, the other heaters (control unit, motor heater) will also be connected to the heater system.

Wiring diagram designation: R5 H

Marking of variants within the wiring diagram code (position 11)

- **B** = 115 V AC or 230 V AC externally supplied
- **C, E, H** = internally supplied via actuator controls

The heater system is temperature-controlled. The heater system will automatically be activated for a temperature range between -5 °C and -10 °C and ensures that the temperature within the controls housing does not fall below -20 °C.

##### 8.16.2. Heater on control unit (actuator)

**Properties** For AUMA actuators with AC actuator controls, a resistance type heater is installed on the control unit (within actuator switch compartment).

The heater minimises condensation within the actuator switch compartment.

Wiring diagram designation: R1 H

Marking within the wiring diagram code: position 11 = A – H

**Information** The proper function of the heater can be monitored. For further information, refer to <Heater system/heater monitoring>.

##### Activate/deactivate heater on control unit

The heater on the control unit of the actuator can be activated/deactivated. Activation/deactivation can either be permanent or automatically when exceeding/falling short of defined temperature values. An electronic control unit (MWG) is required for automatic setting.

**Information** If the heater is deactivated, heater monitoring is also deactivated (parameter **Heater monitor**)!

Required user level: **Specialist (4)**.

M ▷ **Device configuration** M0053  
**Actuator** M0168  
**Heater control unit** M1338

**Default value:** Auto

**Setting values:****Off** Heater is deactivated.**On** Heater is activated.**Auto** Heater is automatically activated/deactivated by the actuator controls:

- For temperatures exceeding +40 °C within the switch compartment = deactivated
- For temperatures of less than +35 °C within the switch compartment = activated

**8.16.3. Motor heater**

The motor heater minimises condensation within the motor and improves the start-up behaviour for extremely low temperatures.

Wiring diagram designation: R4 H

Marking within the wiring diagram code: position 11 = D (motor heater externally supplied), G (motor heater internally supplied)

## 9. Failure functions

**Definition** Failure functions are started by certain events and lead to a defined action of the controls or the actuator. A failure operation can be started by a manual action (e.g. pressing an EMERGENCY stop button). In general, a failure operation is automatically started by a fault signal from a monitoring function (e.g. loss of signal).

### 9.1. Reversing prevention time

**Application** Prevention of impermissible operation states such as: Operation command in direction OPEN, actuator still runs in direction CLOSE due to the delay time.

**Properties** The reversing prevention time (off-time between two operation commands in opposite direction) prevents a restart for a defined interval once the motor has switched off.

#### Parameters and instructions for setting

Required user level: AUMA (6).

M ▷ **Device configuration** M0053  
**Switchgear** M0173  
**Revers. prevent. time** M0174

**Default values:** For 3-phase AC motors = 1.0 s seconds

For 1-phase AC motors = 2.5 s seconds

**Setting range:** 0.3 ... 30.0 s seconds

### 9.2. Failure behaviour on loss of signal

**Characteristics** The failure behaviour can be used to define AC reaction to loss of signal or a defective signal.

Only in operation mode Remote will the failure behaviour react to a signal loss. In operation modes Local or Off, there will be no reaction.

As soon as the cause for initiating the failure function is eliminated (connection restored), the operation commands from the master can be executed again at once.

The last received operation command is deleted once the connection is aborted. To ensure a defined behaviour, a valid operation command must be transmitted to the actuator upon resuming communication.

#### 9.2.1. Failure reaction on loss of signal

Required user level: Specialist (4) or higher.

M ▷ **Customer settings** M0041  
**Failure behaviour** M0378  
**Signal loss beh.** M0379

**Default value:** Good signal first

#### Setting values:

**Good signal first** The <Failure behaviour> is only initiated if the monitored signal fails (falling edge). This setting ensures that if the signal is missing, the actuator will not start when switching on (Good signal first).

**Immediately active** The <Failure behaviour> is immediately initiated if the monitored signal is missing (is not present).

For the setting **Immediately active**:



### Risk of immediate actuator operation when switching on!

*Risk of personal injuries or damage to the valve.*

- Ensure that the signal set under parameter **Source M0385** is present when switching on.
- If the actuator starts unexpectedly: Immediately turn selector switch to position **Local operation** (LOCAL) or **0** (OFF).

## 9.2.2. Failure source (failure reason) for a failure operation: set

M ▷ **Customer settings M0041**  
**Failure behaviour M0378**  
**Source M0385**

**Default value:** Active interface

### Setting values:

**Fieldbus interface**

Failure behaviour is initiated in case of fieldbus communication loss.

**I/O interface**

The failure behaviour is initiated in case of setpoint loss (setpoint position, process setpoint, actual process value).

The monitoring depends on the preset setpoint range, e.g.:

- Setpoint = 4 – 20 mA, E1 lower than 3.7 mA = loss of signal
- Setpoint = 10 – 20 mA, E1 lower than 9.7 mA = loss of signal
- For a setpoint range of 0 – 20 mA, monitoring is not possible.
- Actuator controls will only respond to a setpoint signal loss, if a signal is present at the **MODE** input, i.e. actuator controls are in operation mode Remote SET-POINT (setpoint control).

**Information**

**Active interface**

In case of fieldbus communication loss (if the fieldbus interface is active) or loss of setpoints (if the I/O interface is active), the failure behaviour is initiated.

Possible failure reasons in case of fieldbus communication loss:

- The connection to the master is interrupted.
- The master does not send telegrams to the actuator controls.
- The pre-set connection monitoring time is less than the cycle time of the Modbus communication.

## 9.2.3. Failure operation (reaction of the actuator) on loss of signal

The failure operation defines which action is executed by the actuator once the failure behaviour is initiated.

M ▷ **Customer settings M0041**  
**Failure behaviour M0378**  
**Failure operation M0384**

**Default value:** STOP

### Setting values:

**STOP**

The actuator stops in the current position.

**CLOSE**

The actuator runs to end position CLOSED.

**OPEN**

The actuator runs to end position OPEN.

**Approach position**

The actuator runs to the specified position. Conditions:

- The function <Positioner> is activated.
- Parameter **Source M0385** is set to **I/O interface** (for fieldbus control: **Active interface**)

**Execute last CMD** The actuator executes the last operation command before it is stopped.  
If the last operation command was a setpoint definition via analogue input (AIN 1/AIN 2), the lower limit of the setpoint position is used (parameter **Low limit AIN 1/Low limit AIN 2**). The actuator is operated to the defined end position, usually end position CLOSED.

#### Behaviour depending on the selector switch position

Once the failure operation is triggered, the defined position is approached. If the actuator is then moved to another position (e.g. by manual operation), it will try to perform the set failure operation while the selector switch is in position **Remote control** (REMOTE).

**Information** To prevent a new approach to the failure position during manual operation, the selector switch must be set to position **Local control** (LOCAL) or **0** (OFF) **prior** to operating the handwheel.

#### 9.2.4. Preset position: define

If the **Approach position** failure operation is set, the actuator runs to the preset failure position indicated here.

Required access level: **Specialist (4)** or higher.

M ▶ **Customer settings** M0041  
**Failure behaviour** M0378  
**Fail.pos.OPEN CLOSE** M0387

**Default value:** 50.0 %

**Setting range:** 0.0 ... 100.0 % (from end position OPEN to CLOSED)

#### 9.2.5. Failure position MPV: define

This parameter is only available in multiport valve version.

If the **Approach position** failure operation is set, the actuator runs to the preset failure position indicated here.

Required user level: **Specialist (4)** or higher.

M ▶ **Customer settings** M0041  
**Failure behaviour** M0378  
**Failure position MPV** M1172

**Default value:** 0.0 °

**Setting range:** 0.0 ... 360 °

#### 9.2.6. Speed for safety operation: set

The speed during safety operation may be set individually for both direction (OPEN/CLOSE).

Required user level: **Specialist (4)** or higher.

M ▶ **Customer settings** M0041  
**Failure behaviour** M0378  
**Failure speed OPEN** M1935  
**Failure speed CLOSE** M2042

**Default value:** 45 rpm

**Setting ranges:** 6 ... 240 rpm

The adjustable speed range is indicated on the actuator name plate.

**9.2.7. Delay time: set**

A failure operation is only performed once the delay time has expired. This prevents a short-term loss of signal, which does not have an effect on the process, from directly starting a failure operation

Required user level: **Specialist (4)** or higher.

M ▶ **Customer settings** M0041  
**Failure behaviour** M0378  
**Delay time** M0386


**Default value:** 00:03.0 min:s (3 seconds)

**Setting range:** 0.0 ... 30:00.00.0 min:s (30 minutes)

**Time behaviour in case of bus communication loss**

The connection monitoring time (parameter **Monitoring time** M0781) is started with the last Modbus query-response cycle prior to communication failure. If no valid Modbus telegram was received within this connection monitoring time, this is considered as loss of bus communication and the delay time is started. At the end of the delay time, the failure operation will be executed.

Figure 47: Time behaviour

**9.3. EMERGENCY behaviour**

**Application** The EMERGENCY behaviour can be used to determine the actuator behaviour in an emergency.

- Characteristics**
- The function <EMERGENCY behaviour> is initiated by the EMERGENCY signal.
  - The actuator performs a defined EMERGENCY operation. For example, the actuator moves to a predefined EMERGENCY position (i.e. end position OPEN or end position CLOSED).
  - As long as the EMERGENCY signal is present, the actuator does not respond to any other operation commands (EMERGENCY signal has top priority).
  - After initiating the EMERGENCY behaviour, binary operation commands (via digital inputs) may have to be sent again.
  - Analogue operation commands (e.g. 0/4 – 20 mA) or operation commands via fieldbus are immediately executed again.

**Perform EMERGENCY operation via fieldbus command**

For control via fieldbus interface, the EMERGENCY command is done via fieldbus command **Fieldbus EMCY**.



### Switching behaviour:

- **Fieldbus EMCY** = 1 = EMERGENCY behaviour is initiated.
- **Fieldbus EMCY** = 0 = No EMERGENCY operation

If the EMERGENCY command is not to be transmitted via a fieldbus command but using a binary signal, (e.g. + 24 V DC) via <Additional inputs> or via an additional <Parallel interface>, a digital input has to be available and configured.

### Configuration of digital input

Required access level: **Specialist (4)**.

**M ▶** **Device configuration** M0053  
**I/O interface** M0139  
**Digital inputs** M0116

**Example** Use input DIN 4 for signal **EMERGENCY**:

**Parameter:** Signal DIN 4 M0118

**Setting value:** **EMERGENCY** (wiring diagram designation: **EMERGENCY**)

**Information** The logic for the digital inputs may be inverted. Depending on the parameter setting (e.g. **Coding DIN 4** M0126), the input is either **High active** or **Low active**. For safety reasons, the **EMERGENCY** signal input is generally set to **Low active**.

### Perform EMERGENCY operation via digital input

#### Switching behaviour for coding **Low active**:

- Input **EMERGENCY** = **low level** (0 V DC or input open-circuit)  
EMERGENCY operation is initiated.
- Input **EMERGENCY** = **high level** (standard: +24 V DC)  
No EMERGENCY operation

### 9.3.1. EMERGENCY behaviour: activate

Required user level: **Specialist (4)** or higher.

**M ▶** **Device configuration** M0053  
**Application functions** M0178  
**Activation** M0212  
**EMCY behaviour** M0589

**Default value:** Function not active

#### Setting values:

**Function not active** Function <EMERGENCY behaviour> deactivated.

**Function active** Function <EMERGENCY behaviour> activated.

#### For activated EMERGENCY behaviour:



#### Risk of actuator operation due to an EMERGENCY signal!

*Risk of personal injuries or damage to the valve.*

- For commissioning and maintenance work: Set selector switch to position **0** (OFF). Motor operation can only be interrupted in this selector switch position.
- If the actuator starts unexpectedly: Immediately turn selector switch to position **0** (OFF).

**Information** EMERGENCY behaviour must be completely configured during first activation. This means the setting of the following parameters must be adapted to the required actuator behaviour in particular: **EMCY fail.reac.** **EMCY source** **EMCY operation mode** **EMCY operation** **EMCY position**

**9.3.2. EMERGENCY failure reaction**

Required user level: **Specialist (4)** or higher.

M ▶ **Customer settings** **M0041**  
**EMCY behaviour** **M0198**  
**EMCY fail.reac.** **M0203**

**Default value:** **Good signal first**

**Setting values:**

**Good signal first** The <EMERGENCY behaviour> is initiated as soon as the EMERGENCY signal changes from high to low. Example: for binary EMERGENCY input of +24 V DC to 0 V. This prevents the <EMERGENCY behaviour> from being initiated immediately once the actuator controls are switched on and no EMERGENCY signal is present.

**Immediately active** The <EMERGENCY behaviour> is initiated by a low level at the EMERGENCY signal. For this setting, the EMERGENCY signal has to have a high level before switching on the actuator controls; otherwise <EMERGENCY behaviour> is initiated immediately after switching on.

**For the setting** **Immediately active:**

**The actuator can start immediately when switching on!**

*Risk of personal injuries or damage to the valve.*

- Ensure that the EMERGENCY signal is present when switching on.
- Should the actuator start unexpectedly: Immediately set selector switch to position **0** (OFF).

**9.3.3. Failure source (failure reason) for an EMERGENCY operation: set**

M ▶ **Customer settings** **M0041**  
**EMCY behaviour** **M0198**  
**EMCY source** **M0591**

**Default value:** **I/O interface**

**Setting values:**

**I/O interface** The EMERGENCY signal is present as binary signal (standard: +24 V DC) at a digital input. If this voltage (i. e. the signal) is no longer present, the EMERGENCY behaviour is initiated.

**Fieldbus interface** The EMERGENCY signal is sent as fieldbus command. If the command is no longer present, the EMERGENCY behaviour is initiated.

**I/O or fieldbus** If the fieldbus command or the binary signal is no longer present, the EMERGENCY behaviour is initiated.

**Active interface** If active interface fails, the EMERGENCY behaviour is initiated; e.g. when changing the command source the failure source for the EMERGENCY signal also fails.

**9.3.4. Operation mode for EMERGENCY behaviour**

The EMERGENCY behaviour can be activated for the operation modes Remote and/or Local

M ▶ **Customer settings** **M0041**  
**EMCY behaviour** **M0198**  
**EMCY operation mode** **M0202**

**Default value:** **Remote only**

**Setting values:**

**Remote only** EMERGENCY behaviour is active in the operation modes: **Remote**, **Remote II**, **Fieldbus**

**Remote and local** EMERGENCY behaviour is active in the operation modes: **Remote**, **Remote II**, **Fieldbus**, **Local**, **Service**

**Information** In the operation mode Off (selector switch position 0), no emergency operation is executed.

### 9.3.5. EMERGENCY operation

The EMERGENCY operation determines which action is executed by the actuator once the EMERGENCY behaviour is initiated.

**M ▷** **Customer settings** M0041  
EMCY behaviour M0198  
EMCY operation M0204

**Default value:** STOP

**Setting values:**

**STOP** The actuator stops in the current position.

**CLOSE** The actuator runs to end position CLOSED.

**OPEN** The actuator runs to end position OPEN.

**Approach EMCY pos.** The actuator runs to the specified position.

### 9.3.6. EMERGENCY position

If the **Approach EMCY pos.** EMERGENCY operation is set, the actuator runs to the indicated EMERGENCY position.

Required user level: **Specialist (4)** or higher.

**M ▷** **Customer settings** M0041  
EMCY behaviour M0198  
EMCY position M0232

**Default value:** 0.0 %

**Setting range:** 0.0 ... 100.0 % (from end position OPEN to CLOSED)

### 9.3.7. EMERGENCY position MPV

This parameter is only visible for Multiport valve product variant and replaces the EMERGENCY position parameter.

If the **Approach EMCY pos.** EMERGENCY operation is selected, the actuator runs to the currently specified EMERGENCY position of the Multiport valve.

Required user level: **Specialist (4)** or higher.

**M ▷** **Customer settings** M0041  
EMCY behaviour M0198  
EMCY position MPV M1171

**Default value:** 0.0 °

**Setting range:** 0.0° ... 360.0° (degree)

### 9.3.8. EMERGENCY speed

Speed for an EMERGENCY operation.

Required user level: **Specialist (4)** or higher.

**M ▷** **Customer settings** M0041  
EMCY behaviour M0198  
Speed EMCY OPEN M1934  
Speed EMCY CLOSE M2041

**Default value:** 6 (rpm)

**Setting range:** 6 ... 240 (rpm)

The adjustable speed range is indicated on the actuator name plate.

### 9.3.9. Torque switching: by-pass

If an EMERGENCY operation is initiated, the torque switches can be by-passed during this operation.

Required access level: **Specialist (4)** or higher.

- M ▷ **Customer settings** M0041  
**EMCY behaviour** M0198  
**By-pass torque** M0199

**Default value:** Off

**Setting values:**

- Off** No by-pass of the torque switching.  
**On** The signals of the torque switching in the actuator are by-passed.

### 9.3.10. Motor protection: by-pass

If an EMERGENCY operation is initiated, the motor protection can be by-passed during this operation.

Required user level: **Specialist (4)** or higher.

- M ▷ **Customer settings** M0041  
**EMCY behaviour** M0198  
**Thermal by-pass** M0200

**Default value:** Off

**Setting values:**

- Off** No by-pass of motor protection.  
**On** The signals of the thermostiches or the PTC thermistors of the motor winding are by-passed.

**Information** It is not possible to by-pass the motor protection for actuators with explosion protection.

### 9.3.11. Stepping mode: by-pass

If an EMERGENCY operation is initiated, stepping mode can be by-passed during this operation.

Required user level: **Specialist (4)** or higher.

- M ▷ **Customer settings** M0041  
**EMCY behaviour** M0198  
**By-pass timer** M0201

**Default value:** Off

**Setting values:**

- Off** No by-pass of stepping mode.  
**On** Stepping mode is by-passed.

### 9.3.12. Operation profile: by-pass

If an EMERGENCY operation is initiated, the pre-set operation profile (operation behaviour) can be by-passed.

Required user level: **Specialist (4)** or higher.

- M ▷ **Customer settings** M0041  
**EMCY behaviour** M0198  
**By-pass operat.profile** M0596

**Default value:** Off

**Setting values:**

- Off** No by-pass of operation profile.
- On** The operation profile is by-passed.

### 9.3.13. Interlock: by-pass

If the Interlock function is activated, you may by-pass this function during EMERGENCY operation to prevent that an enable command must be issued to perform EMERGENCY operation.

Required user level: **Specialist (4)** or higher.

- M ▶** **Customer settings** **M0041**
- EMCY behaviour** **M0198**
- By-pass Interlock** **M0668**

**Default value:** **Off**

**Setting values:**

- Off** By-pass mode is deactivated. Interlock function is even active during EMERGENCY operation.
- On** By-pass mode is activated. Interlock function is deactivated during EMERGENCY operation.

### 9.3.14. Local stop: by-pass

If activated, you may by-pass Local Stop function during an EMERGENCY operation to prevent interruption of EMERGENCY operation by pressing the push button STOP.

Required user level: **Specialist (4)** or higher.

- M ▶** **Customer settings** **M0041**
- EMCY behaviour** **M0198**
- By-pass Local STOP** **M0682**

**Default value:** **Off**

**Setting values:**

- Off** By-pass mode is deactivated. Local Stop function is even active during EMERGENCY operation.
- On** By-pass mode is activated. Local Stop function is deactivated during EMERGENCY operation.

### 9.3.15. Speed profile: by-pass

If an EMERGENCY operation is initiated, the pre-set speed profile can be by-passed during this operation.

Required user level: **Specialist (4)** or higher.

- M ▶** **Customer settings** **M0041**
- EMCY behaviour** **M0198**
- Bypass speed profile** **M0596**

**Default value:** **Off**

**Setting values:**

- Off** No by-pass of torque profile. In EMERGENCY operation, the actuator operates into the EMERGENCY position following the pre-set speed profile.
- On** The speed profile is by-passed. In EMERGENCY operation, the actuator operates into the EMERGENCY position at EMERGENCY speed (**Speed EMCY OPEN** parameters **M1934** or **Speed EMCY CLOSE** **M2041**). Refer to <EMERGENCY speed> chapter.

**9.3.16. Delay time for EMERGENCY operation**

An EMERGENCY operation is only performed once the delay time has expired. Consequently, a short-term signal failure will not have an impact on the process and will not immediately initiate an EMERGENCY operation.

Required user level: AUMA (6) or higher.

M ▶ Customer settings M0041  
EMCY behaviour M0198  
Delay time M0804

Default value: 00:01.00 min : s

Setting range: 00:00.0 ... 30:00.0 min : s

**9.4. Enable local controls**

- Application**
- Protection against unauthorised operation via local controls
  - Protection against unauthorised parameter setting via local controls

**Properties** The selector switch functions LOCAL and/or OFF may be enabled or disabled.

**Enable/disable local controls via fieldbus commands**

For control via fieldbus interface, the command for enabling the local controls is done via fieldbus command **Fieldb. enable LOCAL**.

**Switching behaviour:**

- **Fieldb. enable LOCAL** = 1 = enable:  
Operation via local controls enabled
- **Fieldb. enable LOCAL** = 0 = disabled:  
Operation via local controls disabled

**Information** In the event of loss of fieldbus communication, the local controls will be disabled since no enable signal is present.

If operation commands are not transmitted via fieldbus commands, but via <Additional inputs> or an additional <Parallel interface>, a digital input has to be available and configured to enable/disable the local controls.

**Configuration of digital input**

Required user level: Specialist (4).

M ▶ Device configuration M0053  
I/O interface M0139  
Digital inputs M0116

**Example** Use input DIN 5 for signal **Enable Local**:

**Parameters:** Signal DIN 5 M0122

**Setting value:** **Enable Local** (wiring diagram designation: Enable LOCAL)

**Information** The logic for the digital inputs may be inverted. Depending on the parameter setting (e.g. **Coding DIN 5 M0127**), the input is either **High active** or **Low active**. Default setting is **High active**.

**Enable/disable local controls via digital input****Switching behaviour for coding High active:**

- Input **Enable Local** = **high level** (standard: +24 V DC):  
Operation via local controls enabled
- Input **Enable Local** = **low level** (0 V DC or input open):  
Operation via local controls disabled

#### 9.4.1. Enabling function: activate

Required user level: **Specialist (4)** or higher.

M ▶ **Device configuration** M0053  
**Application functions** M0178  
**Activation** M0212  
**Enable LOCAL** M0631

**Default value:** Function not active

**Setting values:**

**Function not active** Function <Local controls: enable from REMOTE> deactivated.  
**Function active** Function <Local controls: enable from REMOTE> activated.

#### 9.4.2. Enabling function behaviour

The enable behaviour determines which selector switch functions (LOCAL, OFF) require an additional enable signal.

Required user level: **Specialist (4)** or higher.

M ▶ **Customer settings** M0041  
**Local controls** M0075  
**Enable LOCAL** M0628

**Default value:** Sel. sw. Local

**Setting values:**

**Sel. sw. Local** Disabling or enabling is only effective in operation mode LOCAL (selector switch is in position **Local control**). If no enable signal is present, operation via push buttons on the local controls is disabled and the display shows the following signal: **Disabled**.  
**Sel. sw. Local + Off** Disabling or enabling is effective in operation modes LOCAL and OFF (selector switch positions **Local control** and **0**). If no enable signal is present, operation via push buttons on the local controls is disabled and the display shows the following signal: **Disabled**.

**Information** If the <Priority REMOTE> function is also activated, the two functions should have different setting values. In case of identical setting values, e.g. **Sel. sw. Local + Off**, the <Enable local controls> function will have no function, since the actuator controls will be exclusively in operation mode REMOTE if the enable signal is missing.

#### 9.5. Priority REMOTE

**Properties** A control signal can provide REMOTE control with priority over actuator operation via local controls (irrespective of the selector switch position)

This function uses the same input signal as the <Enabling local controls> function.

**Application** No changing possibility via selector switch from LOCAL

##### Priority REMOTE over fieldbus command

For control via fieldbus interface, the Priority REMOTE command is done via fieldbus command **Fieldb. enable LOCAL**.

**Switching behaviour:**

- **Fieldb. enable LOCAL** = 1 = enable:  
Operation via local controls enabled
- **Fieldb. enable LOCAL** = 0 = Priority REMOTE:  
Operation via local controls disabled

If the operation commands are not transmitted via fieldbus commands, but via <Additional inputs> or additional <Parallel interface>, a digital input has to be available and configured for the <Priority REMOTE> function.



**Configuration of digital input**

Required user level: **Specialist (4)**.

**M ▶** **Device configuration** M0053  
**I/O interface** M0139  
**Digital inputs** M0116

**Example** Use input DIN 5 for signal **Enable Local**:

**Parameters:** **Signal DIN 5** M0122

**Setting value:** **Enable Local** (wiring diagram designation: **Enable LOCAL**)

**Information** The logic for the digital inputs may be inverted. Depending on the parameter setting (e.g. **Coding DIN 5** M0127), the input is either **High active** or **Low active**. Default setting is **High active**.

**Priority REMOTE via digital input**

**Switching behaviour for coding High active:**

- Input **Enable Local** = **high level** (standard: +24 V DC):  
Operation via local controls enabled
- Input **Enable Local** = **low level** (0 V DC or input open):  
Priority REMOTE: Operation via local controls disabled

**9.5.1. Priority REMOTE: activate**

Required user level: **Specialist (4)** or higher.

**M ▶** **Device configuration** M0053  
**Application functions** M0178  
**Activation** M0212  
**Priority REMOTE** M0770

**Default value:** **Function not active**

**Setting values:**

**Function not active** <Priority REMOTE> function is deactivated.

**Function active** <Priority REMOTE> function is activated.

**9.5.2. Priority REMOTE behaviour**


This function determines which selector switch function (**LOCAL**, **OFF**) requires an additional enable signal.


Required user level: **Specialist (4)** or higher.

**M ▶** **Customer settings** M0041  
**Local controls** M0075  
**Priority REMOTE** M0773

**Default value:** **Sel. sw. Local**

**Setting values:**

**Sel. sw. Local** Priority of control from REMOTE is only effective in operation mode **LOCAL** (selector switch is in position **Local control**). If no enable signal is present, operation via push buttons on the local controls is disabled and the actuator can be controlled from REMOTE. The actuator controls indicates the symbol  in the status line of the display (menu **S0001**).

**Sel. sw. Local + Off** Priority of control from REMOTE is effective in operation modes **LOCAL** and **OFF** (selector switch positions **Local control** and **0**). If no enable signal is present, operation via push buttons on the local controls is disabled and the actuator can be controlled from REMOTE. The actuator controls indicates the symbol  in the status line of the display (menu **S0001**).



### 9.5.3. Fieldbus auto enable

<b>Properties</b>	Generating an enable signal for the <Priority REMOTE> function in case of fieldbus communication failure
<b>Condition</b>	<Priority REMOTE> function.
<b>M ▶</b>	<b>Customer settings</b> M0041 <b>Local controls</b> M0075 <b>Fieldbus auto enable</b> M0774  <b>Default value:</b> On  <b>Setting values:</b>
<b>Off</b>	<Fieldbus auto enable> function is deactivated. In case of bus failure, NO enable signal is generated via fieldbus (command <b>Fieldb. enable LOCAL</b> = 0). <Priority REMOTE> function is active and operation via local controls disabled.
<b>On</b>	In case of bus failure, the actuator controls generate the enable signal themselves to be able to operate the actuator locally.

### 9.6. Interlock (enabling operation commands)

<b>Characteristics</b>	<ul style="list-style-type: none"> <li>An operation command will only be executed if an additional enable signal for the operation command is present.</li> <li>Enabling may be activated or deactivated individually for operation commands OPEN and CLOSE.</li> <li>Enabling can be set for the different operation modes.</li> </ul>
------------------------	---

#### Enable/disable operation commands via fieldbus commands

For control via fieldbus interface, the commands for enabling the operation commands is done via commands **Fieldb. enable OPEN** or **Fieldb. enable CLOSE**.

#### Switching behaviour:

- Fieldb. enable OPEN** or **Fieldb. enable CLOSE** = 1 = enabled:  
Operation command enabled.
- Fieldb. enable OPEN** or **Fieldb. enable CLOSE** = 0 = disabled:  
Operation command disabled.

If operation commands are not transmitted via fieldbus commands, but via <Additional inputs> or an additional <Parallel interface>, a digital input has to be available and configured to enable/disable the local controls.

#### Configuration of digital input

Required user level: **Specialist (4)**.

<b>M ▶</b>	<b>Device configuration</b> M0053 <b>I/O interface</b> M0139 <b>Digital inputs</b> M0116
------------	--

**Example** Use input DIN 5 to enable operation commands in direction CLOSE:

**Parameter:** **Signal DIN 5** M0122

**Setting value:** **Enable CLOSE** (wiring diagram designation: **Interlock CLOSE**)

**Information** The logic for the digital inputs may be inverted. Depending on the parameter setting (e.g. **Coding DIN 5** M0127), the input is either **High active** or **Low active**. Default setting is **High active**.

#### Enable/disable commands via digital input

#### Switching- behaviour for coding **High active**:

- Input **Enable OPEN** = **low level** (0 V DC or input open):  
Operation command enabled.
- Input or **Enable OPEN** = **high level** (default: +24 V DC):  
Operation command disabled,

**9.6.1. Interlock: activate**

Required user level: **Specialist (4)** or higher.

- M ▷ **Device configuration** M0053  
**Application functions** M0178  
**Activation** M0212  
**Interlock** M0663

**Default value:** Function not active

**Setting values:**

- Function not active** Function <Interlock (enable operation commands)> deactivated.  
**Function active** Function <Interlock (enable operation commands)> activated.

**9.6.2. Source of Interlock enable signal: set**

- M ▷ **Customer settings** M0041  
**Interlock** M0664  
**Interlock source** M1013

**Default value:** Active comm. source

**Setting values:**

- Active comm. source** Signals for enabling operation commands are sent via the active interface. I.e. changing the command source also changes the failure source of the enable signal.  
**Interface** The enable signal for the operation commands must be configured as binary signal (default: +24 V DC) at a digital input (parameter: **Enable OPEN/Enable CLOSE**).  
**Fieldbus** The enable signal for the operation commands must be triggered by the fieldbus commands **Interlock OPEN** or **Interlock CLOSE**.

**9.6.3. Operation mode for interlock**

The additional enable signal can be activated for different operation modes.

- M ▷ **Customer settings** M0041  
**Interlock** M0664  
**Oper. mode Interlock** M0665

**Default value:** Off both directions

**Setting values:**

- Off** Interlock is off.  
**Remote** Interlock is active in operation modes: **Remote Remote II Fieldbus**  
**Local** Interlock is active in operation modes: **Local, Service**  
**Remote and local** Interlock is active in operation modes: **Remote, Remote II, Fieldbus, Local, Service**

**9.6.4. Interlock behaviour (running direction)**

The Interlock behaviour determines which selector switch functions (LOCAL, OFF) require an additional enable signal.

Required user level: **Specialist (4)** or higher.

- M ▷ **Customer settings** M0041  
**Interlock** M0664  
**Running dir. Interlock** M0666

**Default value:** OPEN and CLOSE

**Setting values:**

- OPEN** The enable signal is only required for operation commands in direction OPEN.  
**CLOSE** The enable signal is only required for operation commands in direction CLOSE.

**OPEN and CLOSE** The enable signal is required for operation commands in directions OPEN and CLOSE.

## 9.7. Local Stop

- Properties**
- The function Local Stop can be used to stop an operation from Remote locally with the push button STOP.
  - All operation commands are interrupted.
- Information** After releasing push button STOP, an operation command which might still be present will become active immediately.

### 9.7.1. Behaviour

Required user level: **Specialist (4)** or higher.

M ▶

**Customer settings** M0041  
**Local controls** M0075  
**Local STOP** M0627

**Default value:** Off

**Setting values:**

**Off** Push button STOP can only interrupt an operation in operation mode **Local** (selector switch = position **Local control**).

**Sel.sw.Local + Remote** In the operation modes **Local**, **Remote**, **Remote II**, **EMERGENCY** and **Service**, push button STOP interrupts an operation.

**Information** In operation mode **Disabled**, an interruption is NOT possible.

## 9.8. EMERGENCY stop function

**Conditions** An EMERGENCY stop button (latching) is either located on the electrical connection or outside.

- Characteristics**
- In an emergency, the EMERGENCY stop button can be used to interrupt the power supply. Possibly available operation commands will be reset via self-retaining.
  - The indication in the top row of the display shows: **EMCY stop**

Figure 48: EMERGENCY stop button on the electrical connection



**Information** The EMERGENCY stop button is reserved for operation in the event of an emergency. For maintenance work, the mains supply of the actuator controls has to be switched off and protected against accidental switching on.

**Information** The EMERGENCY stop push button is not available for explosion-proof versions, but only for weatherproof versions of the actuator controls.

### Operation commands

After having unlocked the EMERGENCY stop button, a possibly active operation command will **NOT** immediately be re-activated, but only respective acknowledgement by the operator. This resets the EMERGENCY stop status.

The acknowledgement is made:

- via the **RESET** push button in selector switch position **Local control** (LOCAL).
- or via fieldbus reset byte 1 bit 3 of output data (for this, the selector switch must be set to **Remote control**).
- via a digital input from Remote. Assignment: **RESET**

## 9.9. Partial Valve Stroke Test (PVST)

**Properties** The Partial Valve Stroke Test (PVST) is used to check the function of both actuator and actuator controls. During this test, the function of the valve is tested by means of partial opening or closing within a defined period of time without interrupting the process. After successful testing, actuator controls operate the actuator to its initial position.

If the test was not successful, actuator controls will generate the following signals: **PVST fault** **PVST abort**. For monitoring the PVST, these signals must be evaluated by a PLC.

- Requirements**
- Position transmitter in the actuator
  - If the actuator is in safe state (caused by the failure behaviour), the test will not be performed.
  - The test can only be performed during OPEN - CLOSE control. For setpoint control (modulating duty), a test cannot be performed.

### Execute PVST via fieldbus command

For control via fieldbus interface, the tests are initiated via the **PVST** command.

#### Switching behaviour:

- **PVST** = 0 (low active) = no test
- **PVST** = 1 = test is initiated

If the test is not to be transmitted via a fieldbus command but using a binary signal, (e.g. +24 V DC) via <Additional inputs> or via an additional <Parallel interface>, a digital input has to be available and configured.

### Configuration of digital input

Required user level: **Specialist** (4).

**M ▶** **Device configuration** **M0053**  
**I/O interface** **M0139**  
**Digital inputs** **M0116**

**Example** Use input DIN 5 for **Execute PVST** signal:

**Parameters:** **Signal** **DIN 4** **M0118**

**Setting value:** **Execute PVST** (wiring diagram designation: **ESD**)

**Information** The logic for the digital inputs may be inverted. Depending on the parameter setting (e.g. **Coding** **DIN 4** **M0126**), the input is either **High active** or **Low active**. For safety reasons, the **Execute PVST** signal input is generally set to **Low active**.

### Execute PVST via digital input

#### Switching behaviour for coding **Low active**:

- Input **Execute PVST** = **low level** (0 V DC or input open):  
No test
- Input **Execute PVST** = **high level** (standard: +24 V DC):  
Test is initiated

### Execute PVST manually via push buttons of the local controls

Required user level: **Specialist (4)** or higher.

M ▶ **Device configuration** M0053  
**Service functions** M0222  
**Execute PVST** M0850

The actuator must be in the initial position. The initial position depends on the following parameter settings: **PVST behaviour** M0853, **PVST stroke** M0854

- Information** Der PVST kann durch Senden eines Reset-Befehls abgebrochen werden:
- local (manual), in selector switch position **local operation**, via push button **Reset**.
  - From Remote, in selector switch position **Remote control** via a digital input. Assignment: **RESET**
  - or via fieldbus reset byte 1 bit 3 of output data (for this, the selector switch must be set to **Remote control**).

#### 9.9.1. PVST activation

Required user level: **Specialist (4)** or higher.

M ▶ **Device configuration** M0053  
**Application functions** M0178  
**Activation** M0212  
**PVST** M0851

**Default value:** **Function not active**

**Setting values:**

**Function not active** <PVST> function deactivated.  
**Function active** <PVST> function activated.

#### 9.9.2. PVST source: set

M ▶ **Customer settings** M0041  
**PVST** M0852  
**PVST source** M1339

**Default value:** **Active interface**

**Setting values:**

**Active interface** Signals for triggering a PVST are sent via the active interface, i.e. changing the command source also changes the failure source of the PVST.  
**I/O interface** Signals for triggering a PVST must be configured as binary signals (default: +24 V DC) at a digital input.  
**Fieldbus interface** Signals for triggering a PVST must be enabled via **PVST** fieldbus command.

#### 9.9.3. Operation mode for PVST

Required user level: **Specialist (4)** or higher.

M ▶ **Customer settings** M0041  
**PVST** M0852  
**PVST operation mode** M0889

**Default value:** **Stroke**

**Setting values:**

**Stroke** Stroke controlled PVST; operation across defined stroke (parameter **PVST stroke**) within a defined time (parameter **PVST monitoring**). In this operation mode, the PVST can be started in any valve position (even outside the end position).

**End position test** Operating time controlled PVST; operation within a defined time (parameter **PVST operating time**) after leaving an end position. In this operation mode, PVST can only be started from one of the end positions.

#### 9.9.4. Behaviour for PVST: define

The test can be performed in direction OPEN or direction CLOSE.

M ▶ **Customer settings** M0041  
       **PVST** M0852  
       **PVST behaviour** M0853

**Default value:** OPEN

**Setting values:**

**OPEN** Testing by operation in direction OPEN.

**CLOSE** Testing by operation in direction CLOSE.

#### 9.9.5. Partial stroke for PVST: set

During stroke controlled PVST execution (parameter **PVST operation mode** M0889 = **Stroke**), this parameter determines the partial stroke for a PVST.

Usually, the valve stroke amounts to 10 to 15 %. The amount of the partial stroke depends on process requirements and the required diagnostic coverage rate.

M ▶ **Customer settings** M0041  
       **PVST** M0852  
       **PVST stroke** M0854

**Default value:** 10.0 %

**Setting range:** 0.0 ... 100.0 %

#### 9.9.6. PVST monitoring time: set

The actuator remains in the current position if the test could not be completed within the pre-set time.

M ▶ **Customer settings** M0041  
       **PVST** M0852  
       **PVST monitoring** M0855

**Default value:** 01:00.0 min:s (1 minute)

**Setting range:** 00:01.0 ... 50:00.0 min:s (minutes:seconds)

#### 9.9.7. PVST operating time: set

During operating time controlled PVST execution (parameter **PVST operation mode** M0889 = **End position test**), this parameter determines the permissible PVST operating time.

M ▶ **Customer settings** M0041  
       **PVST** M0852  
       **PVST operating time** M0890

**Default value:** 00:02.0 min:s (2 seconds)

**Setting range:** 00:00.1 ... 15:00.0 min:s (minutes:seconds)

#### 9.9.8. PVST reversing time: set

Waiting time during PVST prior to returning to initial position.

M ▶ **Customer settings** M0041  
       **PVST** M0852  
       **PVST reversing time** M0891

**Default value:** 00:02.0 min:s (2 seconds)

**Setting range:** 00:00.1 ... 15:00.0 min:s (minutes:seconds)

#### 9.9.9. PVST reminder

If this function is active, a signal is generated if no PVST was executed during the reminder period.

##### Activate reminder

Required user level: **Specialist (4)** or higher.

M ▷ **Customer settings** M0041  
PVST M0852  
PVST reminder M0892

**Default value:** Function not active

##### Setting values:

Function not active Reminder not activated.

Function active Reminder activated.

##### Set reminder period

M ▷ **Customer settings** M0041  
PVST M0852  
PVST reminder period M0893

**Default value:** 0 d

**Setting range:** 0 ... 65535 d (days)

#### 9.9.10. Speed for PVST: set

The speed during PVST may be set individually for both directions (OPEN/CLOSE).

Required user level: **Specialist (4)** or higher.

M ▷ **Customer settings** M0041  
PVST M0852  
Speed PVST Open M2056  
Speed PVST Close M2057

**Default value:** 45 rpm

**Setting ranges:** 6 ... 240 rpm

The adjustable speed range is indicated on the actuator name plate.

#### 9.10. Bluetooth interface can be activated and deactivated

Behaviour of the Bluetooth interface of the actuator controls can be set.

M ▷ **Device configuration** M0053  
Application functions M0178  
Activation M0212  
M0573

**Information** The last menu only exists for configuration via local controls. For AUMA CDT and AUMA Assistant App, the parameter is already available for configuration in the **Activation** menu.

The parameter may have the following values:

- 0 Switched off (CDT & App)  
Off (local controls)
- 1 Switched on (CDT & App)  
On (local controls)



- 2 I/O or fieldbus
- 3 Selector switch position OFF (CDT & App)

Selector switch OFF (local controls)

The Bluetooth interface is permanently switched off for parameter value "0". To establish a connection is not possible.

The Bluetooth interface is permanently switched on and ready for reception for parameter value "1". A connection can be established at any time.

The parameter values "2" and "3" will be explained hereafter.

#### Activation/deactivation via I/O, fieldbus or selector switch position OFF

The Bluetooth interface can have three different states:

<b>BT_OFF</b>	The Bluetooth interface is deactivated. To establish a connection via a master is not possible. The Bluetooth LED (blue) of the local controls is switched off.
<b>BT_READY</b>	The Bluetooth interface is activated and waits for connection by a master. The Bluetooth LED (blue) of the local controls is blinking.
<b>BT_CONNECTED</b>	The Bluetooth interface is connected to a master. The Bluetooth LED is permanently illuminated.

Properties of the input signals:

- The inputs are edge triggered.
- The Bluetooth interface is activated by rising edge.
- The Bluetooth interface is deactivated by falling edge.

**Information** For details on the process representation, please refer to <Manual (Device integration Fieldbus) AC .2/ACV .2 actuator controls>.

If the parameter corresponds to the value "2" or "3", the Bluetooth interface is in status "BT\_OFF" when switching on the actuator controls.

By activating the Bluetooth interface, the status will change from "BT\_OFF" to "BT\_READY". The duration for the interface to remain in status "BT\_READY" depends on the selected parameter value.

#### Parameter value 2 – fieldbus or I/O

The Bluetooth interface remains in the "BT\_READY" status until a connection is established. Exception: In case a master was already connected, the status will change to "BT\_OFF" once the set time is exceeded.

#### Parameter value 3 – selector switch position OFF

The Bluetooth interface remains in the "BT\_READY" status until the set time is exceeded. Once the set time is exceeded, the status will change to "BT\_OFF".


If a Bluetooth master tries to connect within the set time, the connection will be established. The interface will then change to status "BT\_CONNECTED".

- Generally, the status is always signalled either via fieldbus or via I/O interface.
- The Bluetooth interface may at any time be interrupted via the fieldbus or the I/O interface. The status will then directly change to "BT\_OFF".
- Deactivation via the selector switch is not possible.

The following graphic chart describes the overall behaviour of the Bluetooth interface:



Figure 49: Behaviour of the Bluetooth interface



- [1] Activation of the Bluetooth interface via I/O or fieldbus (value 2) or via the selector switch position OFF (value 3)
- [2] Establishment of connection by Bluetooth master
- [3] Separation of the connection by the master
- [4] Abort by the DCS
- [5] Timeout
- [6] Abort by the DCS

When changing the parameter value, the Bluetooth interface behaviour pattern in states “BT\_READY” and “BT\_OFF” is as follows:

Table 12: Change of parameter value

Current parameter value	Current status	New parameter value	New status
0 (switched off)	BT_OFF	1 (switched on)	BT_READY
0 (switched off)	BT_OFF	2 (fieldbus or I/O)	BT_OFF
0 (switched off)	BT_OFF	3 (selector switch position OFF)	BT_OFF
1 (switched on)	BT_READY	0 (switched off)	BT_OFF
1 (switched on)	BT_READY	2 (fieldbus or I/O)	BT_OFF
1 (switched on)	BT_READY	3 (selector switch position OFF)	BT_OFF
2 (fieldbus or I/O)	BT_READY or BT_OFF	0 (switched off)	BT_OFF
2 (fieldbus or I/O)	BT_READY or BT_OFF	1 (switched on)	BT_READY
2 (fieldbus or I/O)	BT_READY or BT_OFF	3 (selector switch position OFF)	BT_OFF
3 (selector switch position OFF)	BT_READY or BT_OFF	0 (switched off)	BT_OFF
3 (selector switch position OFF)	BT_READY or BT_OFF	1 (switched on)	BT_READY
3 (selector switch position OFF)	BT_READY or BT_OFF	2 (fieldbus or I/O)	BT_OFF

If the Bluetooth interface is in the status “BT\_CONNECTED”, a change of parameter value does not cause a status change. In order to change the status, the master must interrupt the connection or the connection must be interrupted otherwise:

Table 13: Status change for disconnect or abort

Current parameter value	Current status	Cause	New status
0 (switched off)	BT_CONNECTED	Disconnect by master	BT_OFF
0 (switched off)	BT_CONNECTED	Abort by DCS	BT_OFF
1 (switched on)	BT_CONNECTED	Disconnect by master	BT_READY
1 (switched on)	BT_CONNECTED	Abort by DCS	BT_CONNECTED
2 (fieldbus or I/O)	BT_CONNECTED	Disconnect by master	BT_READY (until timeout)
2 (fieldbus or I/O)	BT_CONNECTED	Abort by DCS	BT_OFF
3 (selector switch position OFF)	BT_CONNECTED	Disconnect by master	BT_READY (until timeout)
3 (selector switch position OFF)	BT_CONNECTED	Abort by DCS	BT_OFF

#### Timeout for Bluetooth activation

The time during which the Bluetooth interface remains in status “BT\_READY” after activating via “selector switch position OFF” or after the connection abort by the Bluetooth master, can be set via a parameter.

M ► Device configuration M0053  
Bluetooth interface M2235  
M2234

**Information** The last menu only exists for configuration via local controls. For AUMA CDT and AUMA Assistant App, the parameter is already available for configuration in the Bluetooth interface menu.

**Default value:** 180 [s]

**Setting range:** [60 ... 300] [s]

## 10. Monitoring functions

**Definition** The monitoring functions signal a warning or a fault as soon as a certain value is outside the permissible range. Faults generally cause an actuator shutdown.

### 10.1. Torque monitoring

Torque monitoring has the following functions:

- Valve overload protection against excessive torques (leads to switching off)
- Torque warning before overload protection tripping (only in combination with electronic control unit in the actuator)

#### Overload protection

Once the overload protection trips (torque exceeds set tripping torque), the actuator is stopped.

Actuator controls generate a fault indication if:

- Excessive torque occurs **between** end positions
- Excessive torque occurs **in** the end positions **and** limit seating is set.

The fault indication is shown in the display

- Status indication: **S0007 Fault** or **S0011 Failure**
  - Details: **Torque fault CLOSE** or **Torque fault OPEN**

The fault has to be acknowledged before the operation can be resumed:

1. Either by an operation command in the opposite direction.
  - For **Torque fault CLOSE**: Operation command in direction **OPEN**
  - For **Torque fault OPEN**: Operation command in direction **CLOSE**
2. Or, in case the torque applied is lower than the preset tripping torque after tripping:
  - via the **RESET** push button in selector switch position **Local control** (LOCAL).
  - or via Modbus, command reset (output data: byte 1, bit 3).

Depending on the version, tripping torques for overload protection are either set via switches in the actuator or via software parameters in the controls. For the settings, refer to <Torque switching> chapter.

#### Torque warning

**Requirements** Actuator with electronic control unit (MWG) .

The torque warning can be used e.g. for self-monitoring or for anticipating maintenance requirements.

**M ▶** **Customer settings** **M0041**  
**Torque switching** **M0013**  
**Wrn torque CLOSE** **M0769**  
**Wrn torque OPEN** **M0768**

**Default value:** 80 %

**Setting range:** 20 ... 100 % of the set nominal torque

When exceeding the set limit values, the actuator is not stopped, however, the controls generate a warning signal:

- Status indications: **S0005 Warnings** or **S0008 Out of specification**
  - Details: **Torque wrn CLOSE** or **Torque wrn OPEN**

#### 10.1.1. Torque by-pass

By means of the torque by-pass, the torque monitoring is deactivated for a defined (short) time. During this interval, the full actuator torque may be used, for example, to release the actuator from a blocked end position or any other jammed position.

**NOTICE****Valve damage due to excessive torque!**

→ Only apply torque by-pass with the consent of the valve manufacturer.

**Torque by-pass: activate**

- M ▷ Customer settings M0041  
Torque switching M0013  
Torque by-pass M0092

**Default value:** Function not active

**Setting values:**

Function active

The torque by-pass is activated.

Function not active

The torque by-pass is deactivated.

**Time interval for torque by-pass**

During the time interval set here, the torque monitoring is deactivated.

- M ▷ Customer settings M0041  
Torque switching M0013  
Torque by-pass [s] M0205

**Default value:** 0.0 s

**Setting range:** 0.0 ... 10.0 s seconds

**Information**

If torque by-pass is activated, the interval should be longer than the set time period for reversing prevention time to ensure torque by-pass will also be effective in the event of reversal of operation.

**10.1.2. Torque limitation of torque by-pass**

For activated torque by-pass, the torque monitoring (parameter **Torque by-pass M0092**) is deactivated for a defined (short) time. By activating the torque limitation, torque monitoring will be activated again, but not in relation to the set tripping torque but in relation to a torque peak which can be set separately via this function.

**Condition**

Electronic control unit with MWG in the actuator (non-intrusive version).

**Activate torque limitation**

- M ▷ Customer settings M0041  
Torque switching M0013  
Torque limitation M1805

**Default value:** Function not active

**Setting values:**

Function active

The torque limitation of the torque by-pass is activated.

The actuator will be stopped during the by-pass interval and a torque fault will be generated once the permitted torque peak has been exceeded.

Function not active

The torque limitation of the torque by-pass is deactivated.

There is no torque monitoring. During the by-pass interval, no torque fault will be generated.

**Set torque peak**

- M ▷ Customer settings M0041  
Torque switching M0013  
Torque peak [%] M1806

**Default value:** 120 %

**Setting range:** 100 ... 150 % (in relation to the set tripping torque)

## 10.2. Motor protection monitoring (thermal monitoring)

In order to protect against overheating and impermissibly high surface temperatures at the actuator, PTC thermistors or thermostats are embedded in the motor winding. Motor protection trips as soon as the max. permissible winding temperature has been reached.

The actuator is switched off and the following fault signals are issued:

- LED 3 (factory setting: motor protection tripped) on the local controls is illuminated.
- Status indications **S0007 Fault** or **S0011 Failure** display a fault. The fault **Details** is displayed when selecting **Thermal fault**.

The motor has to cool down before the operation can be resumed.

Depending on the parameter setting (motor protection behaviour), the fault signal is either automatically reset or the fault signal has to be acknowledged manually.

Manual acknowledgement can be made:

- In selector switch position **Local control** (LOCAL) via push button **RESET**.
- In selector switch position **Remote control** (REMOTE):
  - Via fieldbus, Reset command, byte 1 bit 3 of output data if fieldbus is the active command source.
  - Or via a digital input (I/O interface) with RESET command if a digital input is configured for **RESET** signal and the I/O interface is the active command source.

In addition, the actuator controls cyclically (once per month) check the motor protection monitoring for its proper function. If this check fails, the actuator controls generate the fault indication: **IE mot. prot. monitor**

### Motor protection behaviour

Required user level: **AUMA (6)**.

**M ▷** **Device configuration** **M0053**  
**Actuator** **M0168**  
**Motor prot. mode** **M0169**

#### Default values:

Non-explosion-proof actuators = **Auto**

Explosion-proof actuators = **Reset**

#### Setting values:

**Auto** Automatic reset after the motor has cooled down.  
 Not possible for explosion-proof version.

**Reset** Manual reset.

Once the motor has cooled down, the fault has to be acknowledged (reset) manually as described above.

If required the thermal overload relay has to be reset manually. To this end, remove the cover on the back of actuator controls and operate the reset button on the thermal overload relay.

## 10.3. Type of duty monitoring (motor starts and running time)

This function monitors the permissible type of duty (e.g. S2 - 15 min) of the actuator.

For this, actuator controls monitor possible excess of

- Permissible motor starts (cycles) per hour
- Permissible running time (on-time) per hour

If any of these values has been exceeded, the actuator will however not be stopped, but the following warning signals are issued.

- Status indications: S0005 or S0008
  - Details: Wrn op.mode starts
- Status indications: S0005 or S0008
  - Details: Wrn op.mode run time

The warning signals will automatically be cleared if the permissible motor starts per second or the permissible running time per hour are no longer reached.

The operational info logger records the number of excesses (warnings) as well as the number of motor starts and motor running times.

**M ▶** Asset Management M01231  
       Operational info M0177  
       Operational info M0188

On time warning 1 M0325 contains total number of all on time warnings.


On time warning 2 M0326 contains maximum duration of on time warning

**Example:** Due to excess of defined starts/h or defined running time/h, AC issue in total 4 on time warnings: two for 5 min, once for 10 min, once for 17 min. Afterwards the operating data counters contain the following values:

On time warning 1 M0325 = 37 min = total of all periods (5+5+10+17 min)

On time warning 2 M0326 = 17 min = longest period

Figure 50: Example



[1] Running time/h  
 [2] Starts/h  
 [3] On time warning

#### Activate on time monitoring

Required user level: Specialist (4) or higher.

**M ▶** Customer settings M0041  
       Duty type monitoring M0355  
       Duty type monitoring M0358

**Default value:** Function not active

**Setting values:**

Function not active Function <On-time monitoring> deactivated.

Function active Function <On-time monitoring> activated.

#### Set permissible starts/h

**M ▶** Customer settings M0041  
       Duty type monitoring M0355  
       Permissible starts M0357

**Default value:** 1,200 starts/h

**Setting range:** 1 ... 1,800 starts/h

#### Set permissible running time/h

**M ▶** Customer settings M0041  
       Duty type monitoring M0355  
       Perm. run time M0356

**Default value:** 15 min (minutes)

**Setting range:** 10 ... 60 min (minutes)

#### 10.4. Operating time monitoring

This function allows the monitoring of the operating time of the actuator. If the actuator needs longer than the set time to move from end position OPEN to end position CLOSED, a warning is issued (the actuator is not stopped):

- Status indication S0005 Warnings
  - Details: Op. time warning
- Via fieldbus: Op. time warning

The warning indication is automatically cleared once a new operation command is executed.

When the actuator moves from an intermediate position to an end position, the set monitoring time for the whole stroke is assigned in relation to the remaining stroke/travel.

##### Activate operation mode

Required access level: Specialist (4) or higher.

- M ▶ Customer settings M0041  
     Oper. time monitoring M0568  
     Operation mode M0569

**Default value:** Off

**Setting values:**

- Off The operating time monitoring is switched off
- Manual The operating time monitoring is activated. The permissible operation time is set via parameter Perm.op. time, manual M0570.

##### Set permissible operating time manually

Required user level: Specialist (4) or higher.

- M ▶ Customer settings M0041  
     Oper. time monitoring M0568  
     Perm.op. time, manual M0570

**Default value:** 15:00.0 min:s (15 minutes)

**Setting range:** 00:00.0 ... 59:59.9 min:s (minutes:seconds)

##### Display operating times

Operating times can be displayed via Asset Management. Refer to <Display operating times>

#### 10.5. Reaction monitoring

The actuator controls monitor whether the actuator moves after receiving an operation command.

If no reaction is recorded at the output drive of the actuator within a set time, either a warning or a fault signal is generated depending on the setting:

- Status indication: S0005 Warnings or S0008 Out of specification
  - Details: Wrn no reaction
- Status indication: S0007 Fault or S0011 Failure
  - Details: Fault no reaction

In the event of a fault signal, the fault has to be acknowledged to be able to resume the operation. The acknowledgement is made:

- In selector switch position **Local control** (LOCAL) via push button **RESET**.

- in selector switch position **Remote control** (REMOTE):
  - Via fieldbus, Reset command, byte 1 bit 3 of output data if fieldbus is the active command source.
  - Or via a digital input (I/O interface) with RESET command if a digital input is configured for **RESET** signal and the I/O interface is the active command source.

In case of operation from an intermediate position, reaction monitoring will only be performed if the actuator is equipped with position feedback function.

#### Activate switching off for reaction time error

Required user level: **Specialist (4)** or higher.

M ▷ Customer settings M0041  
           Reaction monitoring M0632  
           Actuator behaviour M0633

**Default value:** No cut-off

#### Setting values:

**No cut-off** The reaction monitoring only issues a warning.

**Cut-off** The reaction monitoring issues a fault signal, the actuator is stopped.

#### Set reaction time

M ▷ Customer settings M0041  
           Reaction monitoring M0632  
           Reaction time M0634

**Default value:** 15.0 s

**Setting range:** 15.0 ... 300.0 seconds (0 seconds up to 5 minutes)

### 10.6. Motion detector

**Requirements** Position transmitter in the actuator.

**Characteristics** The motion detector checks whether the actuator moves even without operation command (e.g. in manual operation or if there is no self-retaining).  
 Controls identify motion if the actuator moves more than the pre-set travel difference within the predefined recording time. Controls signal: **Output drive rotates**

**Information** Parameters for motion detection have a direct impact on reaction monitoring.

#### 10.6.1. Activate motion detector

Required user level: **Specialist (4)** or higher.

M ▷ Customer settings M0041  
           Motion detector M0676  
           Motion detector M0675

**Default value:** Function active

#### Setting values:

**Function not active** Monitoring is deactivated.

**Function active** Monitoring is activated.

#### 10.6.2. Detection time dt

Required user level: **Specialist (4)** or higher.

M ▷ Customer settings M0041  
           Motion detector M0676  
           Detect. time dt M0677  
           Detect. time dt (MWG) M0681



**Default values:**

Detect. time dt (for potentiometer/EWG/RWG within actuator) = 00:05.0 min:s ( 5 seconds)

Detect. time dt (MWG) (for MWG within actuator) = 00:00.5 min:s (0.5 seconds)

**Setting ranges:**

Detect. time dt = 00:01.0 ... 30:00.0 min:s (minutes:seconds)

Detect. time dt (MWG) = 00:00.1 ... 00:02.0 min:s (minutes:seconds)

### 10.6.3. Travel difference dx

Required user level: Specialist (4) or higher.

M ▷ Customer settings M0041  
Motion detector M0676  
Travel diff. dx M0678  
Travel diff. dx (MWG) M0679

**Default values:**

Travel diff. dx (for potentiometer/EWG/RWG within actuator) = 1.0 %

Travel diff. dx (MWG) (for MWG within actuator) = 3 (increments)

**Setting ranges:**

Travel diff. dx = 1.0 ... 10.0 %

Travel diff. dx (MWG) = 2 ... 20 (increments)

### 10.6.4. Delay time

Delay time of the signal: Handwheel oper.

Required user level: Specialist (4) or higher.

M ▷ Customer settings M0041  
Motion detector M0676  
Delay time M0764

**Default value:** 6.000 s (seconds)

**Setting range:** 0.001 ... 65.535 s

## 10.7. Monitoring of electronics power supply

Actuator controls monitor the following voltages and signal a warning (refer to <Fault signals and warnings> chapter):

- Auxiliary voltage 24 V DC, e.g for supplying the control inputs
- Voltage 24 V AC for controlling the reversing contactors, for thermoswitches and heater within the actuator and for generating the 115 V AC auxiliary voltage for the customer (option)
- Internal 24 V DC power supply of the electronics components (within the actuator controls and in the actuator)
- External 24 V DC supply of the electronics (option)

### Activate monitoring of auxiliary voltage 24 V DC

Required user level: Specialist (4).

M ▷ Device configuration M0053  
Monitoring function M0645  
Monitor 24 V DC cust. M0650

**Default value:** Function not active

**Setting values:**

Function not active Monitoring is deactivated.

- On** Monitoring is activated. Should the auxiliary voltage 24 V DC for supplying the control inputs fail, a warning will be issued.

#### Activate monitoring of external supply 24 V DC

Required user level: **Specialist (4)**.

- M ▶** **Device configuration** M0053  
**Monitoring function** M0645  
**Monitor 24 V DC ext.** M0649

**Default value:** Function not active

#### Setting values:

**Function not active** Monitoring is deactivated.

- On** Monitoring is activated. Should the external supply 24 V DC fail, a warning will be issued.

### 10.8. Temperature monitoring

- Characteristics** If the respective sensors are installed in the devices, the actuator controls monitor different temperatures.
- If certain temperature limits are exceeded or fallen short of, the controls either send a warning or a fault signal.
- Conditions:**
- For temperature within the control unit of the actuator: MWG (magnetic limit and torque transmitter)
  - For motor temperature: additionally temperature sensor (PT 100) in the motor
  - For gear housing temperature: additionally temperature sensor (PT 100) in the gearing
- Information** Current device temperatures can also be displayed. Refer to <Display device temperatures>.

### 10.9. Heater system/heater monitoring

The heater system within the actuator controls housing and the heater on the control unit (within the switch compartment of the actuator) can be monitored. If the monitoring is activated the following warning will be generated if the heater system or the heater (circuit = interrupted) fails:

- In the display of the local controls, status indication **S0005 Warnings**  
- Details: **Internal warning Wrn heater**
- Via fieldbus: **Wrn heater**

For further information on the heater system and the heater refer to separate <Heater system and heater> chapter.

#### Activate heater system monitoring

Heater system monitoring monitors all connected heaters for failure.

Required user level: **Specialist (4)**.

- M ▶** **Device configuration** M0053  
**Monitoring function** M00645  
**Monitor heat. system** M0647

**Default value:** Function not active

#### Setting values:

**Function not active** Heater monitoring is deactivated.

**Function active** Heater monitoring is activated.

### Activate heater control unit monitoring

**Information** If a heater system is installed within the actuator controls, heater monitoring is not activated/deactivated via this parameter, but via parameter **Monitor heat. system M0647** of the heater system.

Required user level: **Specialist (4)**.

**M ▶** **Device configuration M0053**  
**Actuator M0168**  
**Heater monitor M0646**

**Default value:** Function not active

**Setting values:**

**Function not active** Heater monitoring is deactivated.

**Function active** Heater monitoring is activated. If the heater fails, a warning will be issued.

**Information** Monitoring can only be made once the heater is activated (parameter **Heater control unit**).

### Set reaction time for heater monitoring

Heater monitoring will only respond once a fault persists longer than the set monitoring time. Short-time faults occurring for less than the set monitoring time are not signalled as warning.

Required user level: **AUMA (6)**.

**M ▶** **Device configuration M0053**  
**Actuator M0168**  
**Heating sys. mon. time M0859**

**Default value:** 300.0 seconds

**Setting range:** 60 ... 3600 seconds (1 minute to 1 hour)

## 10.10. Verification of sub-assemblies

**Conditions** • Actuators with electronic control unit

**Characteristics** The controls verify whether sub-assemblies mounted in actuators and controls correspond to the desired version.

In case incorrect sub-assemblies are mounted or if sub-assemblies are missing the controls either send a warning or a fault signal.

For detailed information on this indication refer to <Fault signals and warnings> chapter.

## 10.11. Phase failure monitoring

**Conditions:** Phase failure monitoring is only valid for connections to 3-phase AC power supplies. For versions with 1-phase AC or DC, phase failure monitoring is not possible.

**Properties** The actuator controls monitor phase L2. If phase L2 is missing for a certain time interval, the actuator controls can still send and receive signals and generate a fault indication. Since the actuator controls are supplied via phases L1 and L3, the two phases cannot be monitored. In case L1 or L3 fails, the actuator controls are inoperable and the actuator stops.

**Information** In case of L2 phase loss during motor operation, this does not necessarily lead to an immediate standstill of the actuator. The reason is that the rotating motor generates the missing phase itself. This leads, however, to a reduction of the motor output torque. If the applied torque is sufficient for valve operation, the missing phase L2 is only detected when switching off (e.g. in an end position) and the **Phase fault** fault signal is generated as a consequence.

**Configuration of tripping time**

Required user level: Specialist (4) or higher.

M ▶ Device configuration M0053  
Phase monitoring M0170  
Tripping time M0172

**Default value:** 10.0 s

**Setting range:** 1.0 – 300.0 s

**Information** Faults in supply voltage (e.g. voltage drops) do not generate a fault signal during the adjustable tripping time.

## 11. Functions: activate and enable

### 11.1. Functions: activate

Via **Activation** menu **M0212**, functions can be switched on (activated) or off (deactivated).

Required user level for enabling/disabling: **Specialist (4)** or higher.

**M ▶** **Device configuration** **M0053**  
**Application functions** **M0178**  
**Activation** **M0212**

**Information** Some functions require enabling. Only enabled functions are visible and can be activated or deactivated.

Table 14:

Function	Menu	Enabling required
EMCY behaviour	M0589	No
Timer CLOSE	M0156	No
Timer OPEN	M0206	No
Positioner	M0158	Yes
Operation profile	M0294	No
Process controller	M0741	Yes
Bluetooth	M0573	No
Enable LOCAL	M0631	Yes
Priority REMOTE	M0770	Yes
Auto change-over I/O	M0790	Yes
Interlock	M0663	Yes
Torque wrn	M0796	No
PVST	M0851	Yes
By-pass function	M0941	Yes
Maintenance signals	M1136	No
Maintenance interval	M1137	No
Maintenance reminder	M1884	No
Limit sw. via CDT/App	M1197	Yes
Fieldbus operation	M1236	No
Split range operation	M1650	No
Automatic deblocking	M1679	Yes
DMF evaluation	M1842	No
Mean value curves	M1890	No
Com. eval. REMOTE	M1709	No
Speed profile	M2122	Yes

### 11.2. Functions: enable

Via **Enabling** menu **M0179**, optional functions can be enabled or disabled.

This menu is visible in the display from user level **Specialist (4)**.

**M ▶** **Device configuration** **M0053**  
**Application functions** **M0178**  
**Enabling** **M0179**

Table 15:

Function	Menu and user level
Positioner	M0209 AUMA (6)
Process controller	M0338 AUMA (6)
Enable LOCAL	M0630 AUMA (6)
Priority REMOTE	M0771 AUMA (6)
Auto change-over I/O	M0789 AUMA (6)
Interlock	M0661 AUMA (6)
PVST	M0856 AUMA (6)
By-pass function	M0940 AUMA (6)
Actuator config.	M1138 AUMA (6)
Limit sw. via CDT/App	M1198 AUMA (6)
Automatic deblocking	M1678 AUMA (6)
Speed profile	M2121AUMA (6)

**Information** In user level **Specialist (4)**, an additional activation password (depending on the serial number) is required for enabling the function. The activation password can only be assigned and generated by the AUMA service.

## 12. Product variants

### 12.1. Multiport valve

#### Properties

The multiport valve function is considered as **product variant** and must be activated in the factory. Only for an activated multiport valve function will the respective parameters be available for setting in the actuator controls menu.

The multiport valve function allows to directly access a valve port of a valve equipped with several ports without stopping at any other port. Example: Operation from position 2 to 4 without stopping at position 3.

In operation modes Local and Fieldbus, up to 16 positions can be approached. Operation mode Remote allows the function "next position" also up to 16 positions.

Depending on the setting, the actuator will either operate the valve at a defined direction of rotation (counterclockwise or clockwise) or as quickly as possible (irrespective of the actuator position) to the specified valve port.

#### Procedure for commissioning a multiport valve

1. Set/check multiport valve parameters:  
(generally, they are set in the factory prior to delivery)
  - Actuator type
  - Gear reduction ratio
  - Number of ports (positions)
  - Configuration of digital inputs
2. Define/check positions (of valve ports).
3. Set/check signal behaviour of positions.
4. Set home port (zero position).
5. Approach positions.
6. If required, perform/correct multiport valve parameter settings like inertia, dead band, backlash compensation and hysteresis.
7. If further multiport valve parameters were set: Reset the homeport and re-set parameters as required.

#### 12.1.1. Actuator type: set/check

The actuator type is set in the factory but can be modified at a later date.

Required user level: **Specialist (4)** or higher.

M ▶ **Customer settings** M0041  
     **Multiport valve** M1140  
         **Actuator type** M1142

**Default value:** Actuator type set in the factory

**Setting ranges:** Selection list of all AUMA actuators

#### 12.1.2. Gear reduction ratio: set/check

The reduction ratio of the gear stage of the actuator mounted to the valve gearbox must be set here. To facilitate adjustment, a selection table of supported gearboxes is available.

Required user level: **Specialist (4)** or higher.

M ▶ **Customer settings** M0041  
     **Multiport valve** M1140  
         **Reduction ratio** M1143

**Default values:** GS50.3

**Setting values:**

Table 16: Selection of gearboxes supported by AUMA

Sizes GS 50.3 – GS 125.3	Sizes GS160.3 – GS 250.3
GS50.3	GS160.3
GS63.3	GS160.3/GZ160.3(4:1)
GS80.3	GS160.3/GZ160.3(8:1)
GS100.3	GS200.3
GS100.3/VZ2.3	GS200.3/GZ200.3(4:1)
GS100.3/VZ3.3	GS200.3/GZ200.3(8:1)
GS100.3/VZ4.3	GS250.3
GS125.3	GS250.3/GZ250.3(4:1)
GS125.3/VZ2.3	GS250.3/GZ250.3(8:1)
GS125.3/VZ3.3	
GS125.3/VZ4.3	

**12.1.3. Number of ports (positions)**

Number of valve ports (positions)

Required user level: **Specialist (4)** or higher.

- M ▶** **Customer settings** M0041  
**Multiport valve** M1140  
**Number of ports** M1141

**Default value:** 8

**Setting ranges:**

In operation mode Remote **2** to **10**

In operation mode Local or Fieldbus **2** to **16**

**12.1.4. Home port (zero position): set**

The home port is the zero position (0° or 360° of one turn) and is consequently the starting point for all other intermediate positions.

**Information** Set the gear reduction ratio (parameter **Reduction ratio** M1143) and the actuator type (parameter **Actuator type** M1142) prior to setting the home port.

- Set home port**
- Position multiport valve to zero position either via manual operation (handweel) or via motor operation (via push buttons of local controls)
  - In a next step, confirm this position (with **Yes**) as homeport via parameter **MPV home port** M1162.  
As an alternative, the home port position can also be confirmed via a signal at a digital input. To this end, a digital input has to be available and configured.

**Set home port (zero position) via parameter**

Required user level: **Specialist (4)** or higher.

- M ▶** **Customer settings** M0041  
**Multiport valve** M1140  
**MPV home port** M1162  
**Set?**

Successful homeport setting is visualised by a black circle on the actuator controls display: ●.


**Reset homeport (zero point)**

Required user level: **Specialist (4)** or higher.

- M ▶** **Customer settings** M0041  
**Multiport valve** M1140



### Reset MPV homeport M2863 Reset?

Successful resetting of the homeport is shown by a white circle with a black line on the actuator controls display: .

### Configuration of digital input

Required user level: Specialist (4).

M ▶ Device configuration M0053  
I/O interface M0139  
Digital inputs M0116

**Example** Use input DIN 5 for "Set home port" signal:

**Parameters:** Signal DIN 5 M0122

**Setting value:** MPV set home pos. (wiring diagram designation: Home port)

**Information** The logic for the digital inputs may be inverted. Depending on the parameter setting (e.g. Coding DIN 5M0127), the input is either **High active** or **Low active**. Default setting is **High active**.

## 12.1.5. Positions (of valve ports): define/check

Each position can be set to any value between 0° and 360° (one full turn of the valve).

**Information** Prior to setting the positions, the home port must be defined (parameter **MPV home port**).

This corresponds to the zero position of the valve (0° or 360° of one full valve turn as well as 0 % or 100 % of position feedback).

The positions of the valve ports have to be set afterwards.

M ▶ Customer settings M0041  
Multiport valve M1140  
MPV positions M1149

**Setting ranges:** 0.0 to 359.9°

**Default values:** 0.0° (for all positions)

If desired, positions can be preset in the factory.


Example configuration for a multiport valve comprising 8 ports: All 8 positions are evenly spread across 360°.

Position 1	=	0.0	(bzw. 359,9°)
Position 2	=	45.0	
Position 3	=	90.0	
Position 4	=	135.0	
Position 5	=	180.0	
Position 6	=	225.0	
Position 7	=	270.0	
Position 8	=	315.0	

## 12.1.6. Operate to position via push buttons of the local controls

To operate to a position via push buttons of the local controls, status indication **S0017** must be shown (refer to <Indications in the display>).


Figure 51: Status indication of multiport valve (selector switch in position OFF)



#### Operation in clockwise or counterclockwise direction:

When changing the selector switch to position **Local control** (LOCAL), the display changes:

Figure 52: Status indication of multiport valve (selector switch in position LOCAL)




As a consequence, the valve can be operated into clockwise or counterclockwise direction (display shows CW or CCW)

#### Direct operation to a position:


When selector switch is in position **0** (OFF), the function “Direct operation to a position via push buttons” is activated via **->STEP** (push button **↔**) (display shows **->JOG**).

Figure 53: Status indication of multiport valve (selector switch in position OFF)



When changing the selector switch to position **Local control** (LOCAL), the display changes for selection of the desired position:

Figure 54: Status indication of multiport valve (selector switch in position LOCAL)




Select the desired position (P1, P2, ...) via push buttons **▲▼** and confirm selection via **Ok** (push button **↔**).

→ The operation is issued as soon as push button **Ok** is pressed.

Symbol	
▼	Set positions (of valve ports)
P	(P1, P2, ...) selected position (1, 2, ...)
-- / -N/A-	No position has been selected.
E2	Actual position value
●	Homeport (zero point) set
○	No homeport (zero point) has been set

To interrupt an operation (triggered operation command):

→ Select “– / –N/A–” during operation and confirm via **OK** (push button ). The actuator stops in its current position.

### 12.1.7. Operate to position from Remote

For direct operation to position from remote, make sure that selector switch position **Remote control** (REMOTE) is selected.

#### Approach position via fieldbus command

If fieldbus interface control has been selected, the operation command for direct position approach is performed via a fieldbus command.

**Example:** Fieldbus command **Fieldb. interm. pos. 1**:

- **Fieldb. interm. pos. 1** = 0 (low active) = no operation command
- **Fieldb. interm. pos. 1** = 1 = intermediate position 1 is approached selecting the shortest path

The commands are described in the Manual (Device integration fieldbus).

If the operation commands for direct position approach are not issued via fieldbus command but are to be transmitted using a binary signal, (e.g. + 24 V DC) via <Additional inputs> or via an additional <Parallel interface>, digital inputs must be provided and configured accordingly.

#### Operation to position via digital inputs

An input (DIN) must be configured for each position (valve port).

#### Configuration of digital inputs

Required user level: **Specialist (4)** or higher.

**M ▶** **Device configuration M0053**  
**I/O interface M0139**  
**Digital inputs M0116**

**Example** DIN4 input to operate to position 1 selecting the shortest path:

**Parameters:** Signal DIN 4 M0118 = **Intermediate pos. 1**

Setting values for digital inputs (DIN)	Operation behaviour for input control
Intermediate pos. 1 to Intermediate pos. 16	Operation to defined position while selecting the shortest path
MPV: CW Position 1 to MPV: CW Position 10	Operation to defined position in clockwise direction
MPV: CCW Position 1 to MPV: CCW Position 10	Operation to defined position in counterclockwise direction
MPV DriveCW	Actuator operates in clockwise direction (without stop at any position).
MPV DriveCCW	Actuator operation in counterclockwise direction (without stop at any position).

#### Command “Next position”

Required user level: **Specialist (4)** or higher.

A digital input is used to select the desired operation to the next port including the direction of operation. Thus, up to 16 ports can be approached in both directions, even without fieldbus connection with only 2 inputs.

**Device configuration M0053**  
**I/O interface M0139**  
**Digital inputs M0116**

**Example** Parameter Signal DIN 1 M0117:

- **Next position CW** = clockwise
- **Next position CCW** = counterclockwise

Self-retaining when leaving the factory in both direction (cw and ccw).

#### 12.1.8. Dead band

The dead band prevents operation to a new setpoint position within a specified band.

Required user level: **Specialist (4)** or higher.

M ▷ **Customer settings M0041**  
**Multiport valve M1140**  
**Dead band M1145**

**Default value:** 0.00°

**Setting range:** 0.00 – 36.0° (degrees)

#### 12.1.9. Correction of inertia

Due to reaction times and inertia, each Multiport valve has a specific inertia. This can be compensated by inertia correction.

Required user level: **Specialist (4)** or higher.

M ▷ **Customer settings M0041**  
**Multiport valve M1140**  
**Overrun M1656**

**Default value:** 0.00°

**Setting range:** 0.00° – 10.0° (degrees)

#### 12.1.10. Backlash compensation

Adjustable backlash compensation of the overall system including valve coupling.

Required user level: **Specialist (4)** or higher.

M ▷ **Customer settings M0041**  
**Multiport valve M1140**  
**Backlash comp. M1146**

**Default value:** 0.00°

**Setting range:** 0.00 – 36.0° (degrees)

#### 12.1.11. Signalling behaviour of positions: set/check

Reaching of a point (valve port) can be signalled:

- via bus (see separate instructions)
- via indication lights (LEDs) of the local controls or (refer to chapters <Indications> <Indication lights>)
- via output contacts (refer to chapters <Indications> <Assignment of outputs>)

Signal behaviour, this means the signal behaviour upon reaching a position, is set via parameter **MPV sign. beh. 1**.

M ▷ **Customer settings M0041**  
**Multiport valve M1140**  
**MPV sign. beh. 1 M1147**

**Default value:** No signal

**Setting values:**

**No signal**

A: Signal behaviour Off. Position is not signalled.

C ☐ ☐ O

B: Signal is active from reaching the position up to 360°.


C ☐ ☐ O

C: Signal is active from 0° until the position is reached.

C ☐ ☐ O

D: When passing the position, a pulse signal is issued. The pulse range (range +/- around the pivot point) depends on the set hysteresis.

Figure 55: Signal behaviour of positions




**Information** The set signal behaviour is valid for all positions.

#### 12.1.12. Hysteresis for signalling intermediate positions: set

The hysteresis determines the tripping point.

**Example** Parameter **Position 4 M1153** is set to 180° (50 % of the travel).  
Parameter **Hysteresis M1148** is set to 3.0°.

Figure 56: Switching behaviour for signalling behaviours B, C, D and hysteresis 3.0°.



P1 Switch-on point (●)

P2 Switch-off point (○)

pT Pulse duration = 2 times XT + hysteresis

Required user level: AUMA (6).

**M ▷** **Customer settings M0041**  
**Multiport valve M1140**  
**Hysteresis M1148**

**Default values:** 0.5° for all 16 intermediate positions

**Setting range:** 0.0° to 5.0° (degree)

## 13. Service functions

The functions described here may only be changed by the AUMA service or by authorised and trained personnel.

Menu item **Service functions** is only visible, if user level **Specialist (4)** or higher is selected.

### 13.1. Direction of rotation

**Properties** This function allows changing the direction of rotation for actuator with 3-phase AC motors.

The direction of rotation indicates the direction into which the drive shaft rotates around its own axis. The view is on the top of the actuator. Distinction is made between clockwise and counterclockwise rotation.

- Information**
- When changing from clockwise closing to counterclockwise closing or vice versa, only the direction of rotation of the motor is changed. The change-over requires further action:
    - The wiring diagram designation is marked on the actuator controls name plate. In case of a change, a new name plate with the new wiring diagram number has to be requested from AUMA.
    - The wiring diagram number of the actuator is stored in the electronic device ID (parameter **Wiring diag. actuator M0060**). The ID has to be adapted to the new designation once conversion is complete.
    - The actuator mounted to the actuator controls must be configured for the set direction of rotation. Subsequent conversion from clockwise closing to counterclockwise closing is possible using an AUMA conversion kit.

#### Parameters and instructions for setting

Setting the direction of rotation using parameters is only possible for actuators with electronic control unit/MWG (Non-intrusive version).

#### NOTICE

#### Valve damage due to incorrect direction of rotation!

→ For 3-phase AC motors, the rotation direction of the actuator must match the rotation direction of the valve.

Required user level: **AUMA (6)**.

**M ▶** **Device configuration M0053**  
**Actuator M0168**  
**Closing rotation M0176**

**Default value:** **Clockwise rotation**

#### Setting values:

**Clockwise rotation** The motor is controlled with a clockwise rotating field with the following sequence: L1-U1, L2-U2, L3-U3 (clockwise closing).

**Counterclockwise rot.** The motor is controlled with a counterclockwise rotating field with the following sequence: L1-U3, L2-U2, L3-U1 (counterclockwise closing).

### 13.2. Factory setting

The factory setting corresponds to the delivery state of the actuator controls.

When converting the controls e.g. by the AUMA service, a new factory setting can be generated to adapt the modified configuration.

Former factory settings can be restored.

#### Generate new factory setting

Required user level: **Service (5)** or higher.

- M ▶ **Device configuration** M0053  
**Service functions** M0222  
**Create factory settings** M0225
- Generates new factory settings by accepting the current settings.

#### Restore factory setting

Required user level: **Specialist (4)** or higher.

- M ▶ **Device configuration** M0053  
**Service functions** M0222  
**Reset factory settings** M0226
- Resets the current settings to factory settings.

### 13.3. Languages: reload

If texts are changed or if a new display language is available, the language file can be updated from the external data carrier (SD card).

Required user level: **Specialist (4)** or higher.

- M ▶ **Device configuration** M0053  
**Service functions** M0222  
**Reload languages** M0227

### 13.4. Data export

During data export the data is saved from the device to an external data carrier (SD card).

#### Export data

Comprehensive export of all data (parameters, operation data and event protocol).  
Operation data is device-specific data.

Required user level: **Service (5)** or higher.

- M ▶ **Device configuration** M0053  
**Service functions** M0222  
**Export all data** M0223

#### Export parameters

Export of all parameters. No operation data is transmitted.

Required user level: **Specialist (4)** or higher.

- M ▶ **Device configuration** M0053  
**Service functions** M0222  
**Export all parameters** M0297

#### Export event report

Required user level: **Specialist (4)** or higher.

- M ▶ **Device configuration** M0053  
**Service functions** M0222  
**Export event report** M0298

### 13.5. Data import

During data import, the data is transmitted to the controls from an external data carrier (SD card).

#### Import parameters

Import of all parameters. Operating data is not overwritten.

Required user level: **Specialist (4)** or higher.

M ▶ **Device configuration** M0053  
**Service functions** M0222  
**Import all parameters** M0311

### 13.6. Actual configuration: accept

When retrofitting controls, sub-assemblies are replaced by new sub-assemblies with different functions.

Example: Replacing the PSU (different voltage).

If the controls detect a modified sub-assembly during start up, the following fault signal is generated: **Configuration error**

#### Accept current actual configuration

Accept new actual configuration as target configuration.

Required user level: **AUMA (6)**.

M ▶ **Device configuration** M0053  
**Service functions** M0222  
**Accept actual config.** M0590

### 13.7. Firmware update

A firmware update is required in the following cases:

- Upgrade with new functions
- Corrective actions

A firmware update can be performed in the following ways:

1. via Bluetooth connection with AUMA CDT software
2. via an SD card (card slot in local controls)

#### Firmware version

The firmware version can be displayed via the following menu:

M ▶ **Device ID** M0021  
**Version** M0062  
**Firmware** M0077

#### Firmware update via SD card

The menu **Update firmware** is only displayed if an SD card has engaged in the card slot of the local controls.

Required access level: **Service (5)** or higher.

M ▶ **Device configuration** M0053  
**Service functions** M0222  
**Update firmware** M0564

### 13.8. Service software

Using the **AUMA CDT** software for Windows-based computers (notebooks or tablets) and the **AUMA Assistant App** for Android-based devices, actuator data can be uploaded and read, settings can be modified and stored. The connection between computer and AUMA actuator is established wireless via Bluetooth interface. With the **AUMA Cloud**, we provide an interactive platform to collect and assess e.g. detailed device data of all actuators within a plant.



### AUMA CDT



AUMA CDT is a user-friendly setting and operation program for AUMA actuators controls.

Connection between computer (notebook, tablet) and actuator controls is wireless via Bluetooth interface.

AUMA CDT software can be downloaded free of charge from our website [www.auma.com](http://www.auma.com).

### AUMA Cloud



The AUMA Cloud is the driving element of the digital AUMA world, acting as interactive platform for efficient maintenance of AUMA actuators at moderate cost. The AUMA Cloud collects all device data of all actuators within one site and provides a clear overview at a glance. Detailed analysis provides valuable information on potential maintenance requirements. Additional functions foster smooth asset management.

### AUMA Assistant App



The AUMA Assistant App enables remote setting and remote diagnostics of AUMA actuators via Bluetooth using an Android smartphone or Android tablet.

The AUMA Assistant App is available on Google Play Store for free download.

Figure 57: Link to Google Play Store



### Activate/deactivate Bluetooth

Required user level: **Specialist (4)** or higher.

**M ▶** **Device configuration** **M0053**  
**Application functions** **M0178**  
**Activation** **M0212**  
**Bluetooth** **M0573**

**Default value:** **Function active**

**Setting values:**

**Function not active**

Function deactivated.

**Function active**

Function activated. If the connection is active, the blue LED on the local controls is illuminated.

### Addresses and device tag

Required user level: **Specialist (4)** or higher.

**M ▶** **Diagnostics** **M0022**  
**Bluetooth** **M0244**  
**Device tag** **M0423**  
**Bluetooth address** **M0422**  
**Bluetooth add.partner** **M0576**

## 14. Diagnostics

Diagnostics comprise information on the device and on device sub-assemblies for support during commissioning, maintenance or corrective action.

### 14.1. Electronic device ID

The electronic device ID provides information about the order data (important for enquiries with the factory).

M ► **Device ID** M0021  
**Identification** M0026  
**Version** M0062

Information on device identifications can be modified with the appropriate rights (user level).

Table 17: Information on device identifications

Identification M0026		
Indication on display	Description	User level required for modification
Device designation M0072	Device designation of the actuator controls	Service (5)
Device tag M0072	Device ID for identification within the plant marking (e.g. KKS (Power Plant Classification System))	Specialist (4)
Project name M0068	Project name of the plant	Specialist (4)
Actuator controls M0028	Menu with information regarding identification of the actuator controls	
Order no. controls M0055	Order number of the actuator controls	Service (5)
Serial no. controls M0056	Serial number of the actuator controls	Service (5)
Wiring diagram M0059	Wiring diagram number of the actuator controls	Service (5)
Date of manufacture M0063	Date of manufacture of controls	Service (5)
Actuator M0029	Menu with information regarding identification of the actuator	
Order no. actuator M0057	Order number of the actuator	Service (5)
Serial no. actuator M0220	Serial number of the actuator	Service (5)
Wiring diag. actuator M0060	Wiring diagram number of the actuator	Service (5)

Table 18: Information on device version

Version M0062	
Indication on display	Description
Firmware M0077	Firmware version
Language M0565	Language version
Details Firmware M0515	Menu with further items for requesting the current image file versions of current sub-assemblies (only visible for user level AUMA (6))
Hardware art. no. M0684	Menu with further items for requesting the hardware article number of the actual sub-assemblies (only visible for user level AUMA (6))

### 14.2. Bluetooth connection diagnostic

Menu is only visible if function **Bluetooth** M0573 is activated.

Required user level: **Specialist (4)** or higher.

M ▶ **Diagnostics M0022**  
**Bluetooth M0244**

The following states can be checked via diagnostic:

Parameters	Menu ID	Signification
Device tag	M0223	Device tag (Can be changed for user level <b>Specialist (4)</b> and higher)
Bluetooth address	M0222	Bluetooth address
Bluetooth add.partner	M0576	Bluetooth add.partner

### 14.3. Diagnostic Interface

Required user level: **Specialist (4)** or higher.

M ▶ **Diagnostics M0022**  
**Interface M0239**

The following states can be checked via the menu:

Parameters	Menu ID	Signification
States DIN	M0245	Shows configuration, coding and state of the input signals.
States AIN 1	M0246	Shows configuration and current value at analogue input 1.
States AIN 2	M0583	Shows configuration and current value at analogue input 2.
States DOUT	M0247	Shows configuration, coding and state of the output signals.
States AOOUT 1	M0248	Shows configuration and current value at analogue output 1.
States AOOUT 2	M0584	Shows configuration and current value at analogue output 2.
Interface status	M0730	Status of the interface


#### Diagnostics of digital inputs

For the digital inputs (DIN), both coding and signal states are indicated at the input by means of symbols.

Table 19: Symbol explanation

Symbol	Code	Signal (command)	Input state
△	High active	Not active	Low level = 0 V or input open
▲	High active	Active	High level = Default: +24 V DC
▽	Low active	Not active	High level = Default: +24 V DC
▼	Low active	Active	Low level = 0 V or input open

Figure 58: Example of DIN 4 and DIN 5



- Configuration:
  - DIN 4: Operation command OPEN
  - DIN 5: Operation command for EMERGENCY behaviour
- Coding:
  - DIN 4: **High active** (Triangle pointing in upward direction)
  - DIN 5: **Low active** (Triangle pointing in downward direction)

- Signal state at input:
  - DIN 4: Not active (triangle not filled in)  
Low level = 0 V = No operation command in direction OPEN
  - DIN 5: Active (triangle is black)  
Low level = 0 V = EMERGENCY operation command is available


#### Diagnostic of digital outputs

For the digital outputs (DOUT), both coding and signal states are indicated at the output by means of symbols.

Table 20: Symbol explanation

Symbol	Code	Signal (indication)	State output (output contact)
△	High active	Not active	Low = 0 (output contact not operated)
▲	High active	Active	High = 1 (output contact operated)
▽	Low active	Not active	High = 1 (output contact operated)
▼	Low active	Active	Low = 0 (output contact not operated)

Figure 59: Example of DOUT 1 and DOUT 2



- Configuration:
  - DOUT 1: Indication: Fault has occurred.
  - DOUT 2: Indication: End position CLOSED reached
- Coding:
  - DOUT 1: **Low active** (Triangle pointing in downward direction)
  - DOUT 2: **High active** (Triangle pointing in upward direction)
- Signal state at output:
  - DOUT 1: Not active (triangle not filled in)  
High level = +24 V DC = no indication (no fault available)
  - DOUT 2: Active (triangle is black)  
High level = +24 V DC = indication (end position CLOSED reached)

#### 14.4. Position transmitter and potentiometer diagnostic

Menu is only visible if the actuator is equipped with a potentiometer.

Required user level: **Observer (1)** or higher.

**M ▶ Diagnostics M0022**  
**Position transm. potent. M0831**

The following states can be checked via diagnostic:

Parameters	Menu ID	Signification
Low limit Uspan	M0832	Low limit Uspan
Volt.level diff. potent.	M0833	Volt.level diff. potent.
Raw val. pos. OPEN	M0999	Raw val. pos. OPEN
Raw val. pos. CLOSED	M1001	Raw val. pos. CLOSED
Potent. raw value /mV	M1005	Potent. raw value /mV

#### 14.5. Diagnostic Position transmitter RWG

Menu is only visible if the actuator is equipped with electronic position transmitter (RWG).

Required user level: **Observer (1)** or higher.

**M ▶** **Diagnostics M0022**  
**Position transm. RWG M0996**

The following states can be checked via diagnostic:

Parameters	Menu ID	Signification
Low limit RWG	M1010	
Raw val. pos. OPEN	M0997	
Raw val. pos. CLOSED	M0998	
RWG raw value /mA	M1000	

#### 14.6. Diagnostic Position transmitter MWG

Menu is only visible if the actuator is equipped with magnetic limit and torque transmitter (MWG).

Required user level: **Observer (1)** or higher.

**M ▶** **Diagnostics M0022**  
**Position transm. MWG M1006**

The following states can be checked via diagnostic:

Parameters	Menu ID	Signification
Minimum stroke	M1007	
Maximum stroke	M1012	
Abs. end pos. OPEN	M1011	
Abs. end pos. CLOSED	M1008	
Absolute value	M1009	

#### 14.7. Diagnostic Positioner

Required user level: **Specialist (4)** or higher.

**M ▶** **Diagnostics M0022**  
**Positioner M0613**

Menu **M0613** is only visible if function **Positioner M0158** is activated.

The following states can be checked via diagnostic:

Parameters	Menu ID	Bedeutung
Adaptive behaviour	M0626	
Setpoint position	M0622	
Actual position	M0623	
Outer dead b. OPEN	M0625	
Outer dead b. CLOSE	M1002	
Inner dead b. OPEN	M1003	
Inner dead b. CLOSE	M1004	

#### 14.8. Diagnostic On time monitoring

Menu is only visible if on time monitoring (parameter **Duty type monitoring M0573**) is activated.

Required user level: **Observer (1)** or higher.

**M ▶** **Diagnostics M0022**  
**Operation mode M0593**

The following states can be checked via diagnostics:

Parameters	Menu ID	Signification
On time	M0594	
No. mot. starts/h	M0595	

**14.9. Diagnostic Process controller**

Required user level: **Specialist (4)** or higher.

- M ▶ **Diagnostics** M0022  
**Process controller** M0883

Menu M0883 is only visible if function **Process controller** M0741 is activated.

The following states can be checked via diagnostic:

Parameters	Menu ID	Signification
Process setpoint	M0884	
Actual process value	M0885	
Op. com. PID contr.	M0886	

**14.10. Modbus interface: diagnostic**

This diagnostic provide information on the current status of the Modbus sub-assemblies.

Required user level: **Specialist (4)** or higher.

- M ▶ **Diagnostics** M0022  
**Modbus MD1** M0241  
**Modbus MD2** M0775  
**Details Modbus** M0777

For a detailed description of the indications included in these menus refer to Manual (Device integration fieldbus) Modbus.

**14.11. Diagnostic FO cable**

Required user level: **Observer (1)** or higher.

- M ▶ **Diagnostics** M0022  
**FO cables** M0638

The following states can be checked via diagnostic:

Parameters	Menu ID	Signification
FOC level channel 1	M0639	
DIN 4 configuration	M0640	
FOC RS-485 error	M0762	
FO cable baud rate	M0641	
FOC FPGA version	M0711	

**14.12. Simulation (inspection and test function)**

The service personnel or the commissioning engineer can use this simulation function to simulate the operation and failure behaviour of the actuator or the actuator controls to check the interface to the DCS and the correct behaviour of the DCS.

**14.12.1. Actuator signals**

By simulating the actuator signals, the signal behaviour of the actuator controls to the DCS can be tested, for example, without having to connect the actuator.

Required user level: **Specialist (4)** or higher.

- M ▶ **Diagnostics** M0022  
**Simulation** M0023  
**Actuator signals** M0024

**Simulation values:**

- End position OPEN** End position OPEN reached.  
**End position CLOSED** End position CLOSED reached.

Torque fault OPEN	Torque in direction OPEN reached.
Torque fault CLOSE	Torque in direction CLOSE reached.
Thermal fault	Motor protection tripped (thermal fault)
	The simulation is activated and deactivated by push button <b>Ok</b> .
	A loop on the display indicates that the simulation is active.

#### 14.12.2. Interface signals

By simulating the interface signals, the signal behaviour of the AUMATIC to the DCS can be tested, for example, without having to connect the actuator.

Required access level: **Specialist (4)** or higher.

**M ▶** **Diagnostics** M0022  
**Simulation** M0023  
**Signals DOUT** M0025  
**Signals AOOUT 1** M0413  
**Signals AOOUT 2** M0585

##### Signals for simulating digital outputs:

Only the assigned outputs are displayed.

Numbers **1, 2, 3, ...** indicate the digital output.

##### Example: **1Fault**

Indication **Fault** is assigned to digital output 1 (parameter **Signal DOUT 1** M0109).

Simulation is activated and deactivated by push button **Ok**.

Triangles indicate the activation:

Triangle pointing in upward direction: Output is coded high active.	
▲	High active (voltage is present, e.g. + 24 V DC)
△	High active (voltage is not present)
Triangle pointing in downward direction: Output is coded low active.	
▼	Low active (voltage is not present)
▽	Low active (voltage is present, e.g. + 24 V DC)

##### Signals for simulating analogue outputs:

<b>Signals AOOUT 1</b>	Simulation of output signal <b>Actual position</b> , setting range: <b>0 ... 20 mA</b>
<b>Signals AOOUT 2</b>	Simulation of output signal <b>Torque</b> , setting range: <b>0 ... 20 mA</b>

## 15. Asset Management

The Asset Management function provides information (operational data, signals, reports and characteristics), which can be used within an asset management system but also generally for support during commissioning, maintenance or corrective action.

### 15.1. Operating data

Operating data provides details e.g. about the running time, the number of starts, number of torque faults etc.

The analysis of this data provides valuable information regarding the optimization of both actuator and valve. When using this information purposefully, actuator and valve will be carefully operated, e.g. through appropriate parameter setting. In case of faults, the logging of operating data allows for quick fault diagnostic.

#### View the operating data

Two counters are available, a lifetime counter and a resettable counter.

M ► **Asset Management M1231**  
     **Operational info M0177**  
     **Operational info total M0183**  
     **Operational info M0188**

#### Description of the indications:

**Operational info total** = Lifetime counter

**Operational info** = Counter can be reset to 0

Table 21: Operating data

Indication on display	Description
Motor running time	Motor running time
Motor starts	Number of motor starts (starts)
No. thermal faults	Number of thermal faults (motor protection)
Torque fault CLOSE	Number of torque faults in direction CLOSE
Torque fault OPEN	Number of torque faults in direction OPEN
Limit trip CLOSED	Number of limit switch trippings in direction CLOSE
Limit trip OPEN	Number of limit switch trippings in direction OPEN
Torque trip CLOSE	Number of torque switch trippings in direction CLOSE
Torque trip OPEN	Number of torque switch trippings in direction OPEN
On time warning 1	Total of all time intervals during which a start/run warning was signalled.
On time warning 2	Max. time interval during which a start/run warning was signalled.
No. system starts	Total of AUMATIC system starts
Max. temp. controls	Maximum temperature of the controls
Min. temp. controls	Minimum temperature of the controls
Max. temp. MWG	Maximum temperature of the MWG
Min. temp. MWG	Minimum temperature of the MWG
Operating hours	Operating hours counter: Number of hours during which controls are supplied with power

#### Reset operating data

Required user level: **Specialist (4)** or higher.

M ► **Asset Management M1231**  
     **Operational info M0177**  
     **Reset operation. info M0197**

The entries in the operating data logging can be reset (deleted) via this menu.



## 15.2. Event report

The event report records system events and status signals. The event report can be exported to the external SD card or read via AUMA CDT software or the AUMA Assistant App. This allows e.g. comparisons of previous operations of actuator and valve.

**Information** Since the events are recorded with a time-stamp, date and time (parameter **Date and time M0221**) should be properly set.

### Event filter for system events

The actuator controls record system events such as operation commands or modifications of the parameter settings. A filter is used to define the system events to be recorded in the event report.

Required user level: **AUMA (6)**.

**M ▷** **Asset Management M1231**  
**Event report M0195**  
**System event filter M0334**

An event is recorded (i.e. filter is active) if a black dot is placed behind the value displayed.

### Events which can be recorded:

**Commands** All operation commands recognised as valid and executed are recorded. The command source of the operation command is also recorded.

**Parameterization** All modifications of parameter settings are also recorded. Both former and new value are recorded.

**Enable processes** The enabling of a function is recorded.

**System events** All important system events are recorded. These include: System start, change of date, downloads, modifications of the event filter, resetting of operating data and switching on the mains voltage.

### Event filter for status indications

The actuator controls record status indications such as faults, errors, warnings or Actuator is in end position CLOSED/OPEN. A filter is used to define the status indications to be recorded in the event report.

Required user level: **AUMA (6)**.

**M ▷** **Asset Management M1231**  
**Event report M0195**  
**Event filter for Events M0333**

An event is recorded (i.e. filter is active) if a black dot is placed behind the value displayed.

### Events which can be recorded:

The events which can be selected here are described in the <Faults and warnings> chapter.

### File size of event report

The file size of the event report can be modified to record more or less events as desired. If the file is full, the oldest events will be overwritten so that the latest and current events are recorded.

Required user level: **AUMA (6)**.

**M ▷** **Asset Management M1231**  
**Event report M0195**  
**File size event. rep. M0330**

**Default value:** 548 [kByte]

**Setting range:** 1 ... 1,024 [kByte]

With the maximum setting range of 1,024 kbyte, at least 20,000 events can be stored.

**Information** Some events are stored in a sector which cannot be overwritten. This includes, for example, modifications of the parameter setting, enabling of functions and certain special functions.

#### Number of events in the buffer

The events are first stored into an internal RAM. From this buffer, they are written to the event report after the set report cycle. The number of events in the buffer can be set here.

**Information** In case of power failure, the events in the buffer will be lost.

Required user level: AUMA (6).

M ▶ **Asset Management M1231**  
Event report M0195  
Buffer size M0332

**Default value:** 50 [events]

**Setting range:** 10 ... 100 [events]

#### Save interval

The event report is updated and saved at a defined cycle. This cycle (save interval) can be reduced or extended

Required user level: AUMA (6).

M ▶ **Asset Management M1231**  
Event report M0195  
Save interval M0331

**Default value:** 50,000

**Setting range:** 1,000 ... 65,535 [ms]

## 15.3. Characteristics

### 15.3.1. Torque-travel characteristic

- Conditions**
- Electric actuators with electronic control unit
  - Actuator controls (non-intrusive version) from firmware version 02.03.01

**Properties** Representation of torque requirement across complete travel (resolution of 0.1 %) During each travel, actuator controls continuously record the torques applied.

**Application** When comparing two characteristics (current characteristic with archived characteristic), the wear within the valve or the actuator can be assessed.

#### Display torque-travel characteristics


M ▶ **Asset Management M1231**  
Characteristics M0313  
Torque-travel M1229  
Characteristics M0546

3 characteristics with two diagrams each (direction OPEN and direction CLOSE) are displayed while the arrow indicates the operation direction diagram.

Each characteristic has a designation (e.g. REF 1\_), which can be changed.

Use push buttons ▲▼ Up ▲Down ▼ to change between characteristics.

Figure 60: Example of torque-time characteristic



The displayed characteristics are records which were previously saved.

The following further information is saved with the characteristic (can be requested via push button **Details**)

- **Saving date:** Time of last torque measurement
- **Starting date:** Time of first torque measurement
- **Scaling:** Y-axis (torque)
- **Tripping torque:** Set torque in direction OPEN/CLOSE
- **Min tripping torque:** Min. adjustable tripping torque
- **Max. value:** Max. measured torque value
- **Mean value:** Calculated mean value

#### Characteristics recording procedure

1. Reset characteristic (clear buffer)
2. Change characteristic designation
3. Record characteristic: Perform operation (e.g. CLOSE-OPEN-CLOSE)
4. Save characteristic

#### Reset characteristic

This parameter is used to reset the data in the buffer (RAM).

Required user level: **Specialist (4)** or higher.

M ► **Asset Management M1231**  
**Characteristics M0313**  
**Torque-travel M1229**  
**Reset characteristic M0656**

After resetting the buffer, new characteristics can be recorded and saved.

#### Change characteristic designation

Each of the three characteristics can be named with an additional 20 characters.

Required user level: **Specialist (4)** or higher.

M ► **Asset Management M1231**  
**Characteristics M0313**  
**Torque-travel M1229**  
**Tag torque-position 1 M0658**  
**Tag torque-position 2 M0659**  
**Tag torque-position 3 M0660**

#### Record characteristic: Perform operation (e.g. CLOSE-OPEN-CLOSE)

Set selector switch to position **Local control (LOCAL)** or **Remote control (REMOTE)** to record the characteristic.

**Save characteristics**

3 characteristics can be saved.

Each characteristic consists of two charts (direction OPEN and direction CLOSE).  
When saving, data is transferred from the buffer (RAM) to the read-only memory (ROM).

Required user level: **Specialist (4)** or higher.

M ▶ **Asset Management M1231**  
**Characteristics M0313**  
**Torque-travel M1229**  
**Save characteristic 1 M0652**  
**Save characteristic 2 M0653**  
**Save characteristic 3 M0654**

**15.3.2. Position-time characteristic**

- Conditions**
- Actuator of the type range SA 07.2 – SA 16.2/SAR 07.2 – SAR 16.2
  - MWG position transmitter in actuator

**Properties** During recording, the current position, for modulating actuators also the setpoint position, within an adjustable time interval (between 1 second and 1 hour).

**Application** By assessing the position-time characteristics, the control behaviour can be assessed or insights on the use of the actuator can be gained.

**Display position-time characteristics**

M ▶ **Asset Management M1231**  
**Characteristics M0313**  
**Position-time M0806**


Each characteristic has a designation:

**ACTUAL-POSITION** = actual position

**NOMINAL-POSITION** = setpoint position (modulating actuators only)

Use push buttons ▲▼ Up ▲Down ▼ to change between characteristics.

Figure 61: Example of position-time characteristic



— — 50 % (position between OPEN = 100 % and CLOSED = 0 %)

The following further information is saved with the characteristic (can be requested via push button **Details**).

- **Saving date:** Time of last position measurement
- **Starting date:** Time of first position measurement
- **Scaling:** Y-axis (position)

**Set resolution (time interval)**

Actuator controls records 10,000 measured values. Set resolution of e.g. approx. 1 second (parameter **Interval position-time** = 1 [s] ) results in a recording time of 2.7 hours (10 000 seconds). Once this value has been exceeded, the former positions will be overwritten (ring buffer)

Required user level: **Specialist (4)** or higher.

M ▶ **Asset Management M1231**

Characteristics M0313  
Interval position-time M0805

Default value: 10 [s]

Setting values: 1 ... 3600 [s]

### 15.3.3. Temperature-time characteristic

**Properties** Up to four temperature-time characteristics can be recorded unless the devices are fitted with suitable sensors.

- Conditions**
- For recording the temperature within the control unit: MWG (magnetic limit and torque transmitter)
  - For recording the temperature within the motor: additionally temperature sensor (PT 100) in the motor
  - For recording the temperature within the gear housing: additionally temperature sensor (PT 100) in the gearing

**Application** Evaluation of the temperature-time characteristics allows to gain knowledge about the service conditions (ambient temperatures) of the actuator.

#### Display temperature-time characteristic

M ► Asset Management M1231  
Characteristics M0313  
Temperature-time M0714

Up to four characteristics are shown in the display.

CONTROLS TEMPERATURE = temperature within the control unit


MWG TEMPERATURE = MWG temperature

MOTOR TEMPERATURE = temperature within the motor

GEAR TEMPERATURE = within the gear housing

Use push buttons ▲▼ Up ▲Down ▼ to change between available characteristics.

Figure 62: Example of temperature-time (within the control unit)



--- 0° line

| Recording interrupted e.g. due to power failure

The actuator controls display shows temperature evolution during one week. AUMA CDT software reads out the evolution during an entire year.

The following further information is saved with the characteristic (can be requested via push button **Details**)

- **Saving date:** Time of last temperature measurement
- **Starting date:** Time of first temperature measurement
- **Scaling:** Y-axis (temperature)
- **Min. value:** Minimum measured value
- **Max. value:** Maximum measured value

## 15.4. Histograms

### 15.4.1. Motor running time-position (histogram)


- Conditions**
- Actuators of the type range SA 07.2 – SA 16.2/SAR 07.2 – SAR 16.2

- Properties** The entire travel (from 0 – 100 %) is divided into 20 segments for recording the motor running time. When passing a segment, the counter, shown as bar graph, increments. The histogram is cyclically saved once a minute, in case a change has occurred.
- Application** The motor running time position histogram shows the travel range within which the actuator is predominantly operated. This allows to draw conclusions for the sizing of the valve.

#### Display motor running time-position

M ▶ Asset Management M1231  
Histograms M0712  
Motor RunTime-Position M0713

Figure 63: Example of a motor running time position histogram



The following detailed information is saved with the histogram (may be called up via push buttons **Details**)

- **Starting date:** date of first running time measurement
- **Saving date:** date of last running time measurement
- **Scaling:** Y-axis (motor running time)


#### 15.4.2. Motor running time-temperature (histogram)

- Conditions**
- MWG position transmitter in actuator
  - Temperature sensor in the motor (option)
- Properties** The motor temperature is divided into the following segments:  
< -20°C to -10°C, > -10°C to 0°C, > 0°C to 10°C, ..., 120°C to 130°C, > 130°C to 140°C, > 140°C.
- During each operation, the counter of the segment corresponding to the current motor temperature will be incremented. The result is shown in a bar chart. The histogram is cyclically saved once a minute in case of change.
- Application** The histogram indicates the ambient conditions (temperatures) at which the actuator motor was predominantly operated.

#### Display motor running time-temperature

M ▶ Asset Management M1231  
Histograms M0712  
Motor RunTime-Temp. M0715

Figure 64: Example of motor running time - motor temperature histogram



The following further information is saved with the histogram (can be requested via push button **Details**)

- **Starting date:** Date of first running time measurement
- **Saving date:** Date of last running time measurement
- **Scaling:** Y-axis (motor running time)


### 15.4.3. Motor running time-torque (histogram)

- Conditions** MWG position transmitter in actuator
- Properties** The torque scale is divided into the following segments for both directions (OPEN/CLOSE):  
from 0 – 30 %  
from 30 – 110 % (8 segments with a width of 10 % each)  
more than 110 %
- During each operation, the counter of the segment corresponding to the currently required torque will be incremented. The result is shown in a bar chart. The histogram is cyclically saved once a minute, in case a change has occurred.
- Application** The motor running time-torque histogram indicates the actuator load during service life.

#### Display motor running time-torque

M ► Asset Management M1231  
Histograms M0712  
Motor TunTime-Torque M0830

Figure 65: Example of motor running time-torque histogram



The following further information is saved with the histogram (can be requested via push button **Details**)

- Starting date:
- Saving date:
- Scaling:

### 15.5. Maintenance (information and signals)

- Properties** Actuator controls monitor various parameters set in the factory which have an impact on the wear of the actuator. Once one of these parameters exceeds a determined limit, the actuator controls generate a signal:
- Status indication: S0005 Warnings (AUMA category)
    - Details: Maintenance required
  - Status indication: S0010 Maintenance required (NAMUR category)
    - Details: shows the parameter(s) for which the limit was exceeded, causing the Maintenance required signal.

Apart from the parameter monitoring preset in the factory (MT lifetime mechanics/seals/lubricant), a fixed maintenance interval can additionally be configured, triggering the same signal when exceeding the configured time.

The current maintenance status of the monitored parameters is represented in a bar chart.

Once maintenance is complete, the parameter initiating maintenance must be reset to zero.

- Application** Maintenance on demand, i.e. the function can be used to perform maintenance depending on the intensity and load of the actuator.

#### Activate maintenance signals

Required user level: Specialist (4) or higher.

M ► Device configuration M0053



Application functions M0178  
Activation M0212  
Maintenance signals M1136

**Default value:** Function not active

**Setting values:**

Function not active <Maintenance signals> function deactivated.  
Function active <Maintenance signals> function activated.

#### Activate maintenance interval

Required user level: Specialist (4) or higher.

M ▷ Device configuration M0053  
Application functions M0178  
Activation M0212  
Maintenance interval M1137

**Default value:** Function not active


**Setting values:**

Function not active <Maintenance interval> function deactivated.  
Function active <Maintenance interval> function activated.

#### Display maintenance information

M ▷ Maintenance signals M1231  
Maintenance M1644  
Maintenance informat. M1037

Figure 66: Example of bar chart



The bar charts indicates the current consumption of the following lifetime accounts:

Lifetime mechanics

Lifetime seals (O-rings)

Lifetime lubricants

Lifetime contactors (only for actuator controls which are not provided with variable speed function)

Maintenance interval (adjustable)

Once a bar reaches the threshold ( - - - ), maintenance will be required.

#### Reset parameter

Once maintenance is complete, the parameter initiating the request must be reset.


Starting from Maintenance informat. M1037 indication, you can change via Edit to the reset mode.

Required user level: Specialist (4) or higher.

M ▷ Device configuration M0053  
Application functions M0178  
Activation M0212



Figure 67:



Use push buttons **Up ▲** **Down ▼** to select the desired parameter. The arrow below the symbols shows the selected parameter. Pressing push button **Reset** resets the lifetime account of the selected parameter to zero.

**Set maintenance interval**

Parameters for setting a defined maintenance interval. Once the set time has elapsed, a maintenance signal is issued.

Required user level: **Specialist (4)** or higher.

- M ▶ **Maintenance signals M1231**
  - Maintenance M1644**
  - Maintenance interval M1233**
- Default value:** 10 years
- Setting range:** 1 month... 10 years

**15.6. Operating times display**

- Characteristics** The actuator controls automatically determine the operating time for an operation between two end positions. For both directions (from OPEN to CLOSE and from CLOSE to OPEN), the last determined value is saved within a parameter.
- Application** Operating time measurement indicated how an actuator installed in plant or a combination of actuator/gearbox/valve behave with regard to inertia without performing an operation and measuring the time manually.

**Display measured operating times**

- M ▶ **Asset Management M1231**
  - Operating time M1232**
  - Operating time CLOSE M1234**
  - Operating time OPEN M1235**

**Indications:**

- Operating time CLOSE** Indicates the measured operating time for the last operation in direction CLOSE
- Operating time OPEN** Indicates the measured operating time for the last operation in direction OPEN

**15.7. Device temperature display**

Required user level: **Specialist (4)** or higher.

- M ▶ **Asset Management M1231**
  - Device temperatures M0524**

**Indications:**

- Temp. controls** Indication of current temperature in actuator controls housing
- Temp. control unit** Indication of current temperature in control unit of the actuator (actuator housing)

## 16. Corrective action

### 16.1. Primary fuses

The actuator controls have to be opened to exchange the primary fuses. For detailed information, refer to operation instructions for actuator.

### 16.2. Fault indications and warning indications

**Faults** interrupt or prevent the electrical actuator operation. In the event of a fault, the display backlight is red.

**Warnings** have no influence on the electrical actuator operation. They only serve for information purposes. The display remains white.


**Collective signals** include further indications. They can be displayed via the  **Details** push button. The display remains white.

Table 22:








Faults and warnings via status indications in the display		
Indication on display	Description/cause	Remedy
S0001	Instead of the valve position, a status text is displayed.	For a description of the status texts, refer to <Status texts in Menu S0001>.
S0005 Warnings	Collective signal 02: Indicates the number of active warnings.	For indicated value > 0: Press push button  <b>Details</b> . For details, refer to <Warnings and Out of specification> table.
S0006 Not ready REMOTE	Collective signal 04: Indicates the number of active signals.	For indicated value > 0: Press push button  <b>Details</b> . For details, refer to <Not ready REMOTE and Function check> table.
S0007 Fault	Collective signal 03: Indicates the number of active faults. The actuator cannot be operated.	For indicated value > 0: Press push button  <b>Details</b> to display a list of detailed indications. For details, refer to <Faults and Failure> table.
S0008 Out of specification	Collective signal 07: Indication according to NAMUR recommendation NE 107 Actuator is operated outside the normal operation conditions.	For indicated value > 0: Press push button  <b>Details</b> . For details, refer to <Warnings and Out of specification> table.
S0009 Function check	Collective signal 08: Indication according to NAMUR recommendation NE 107 The actuator is being worked on; output signals are temporarily invalid.	For indicated value > 0: Press push button  <b>Details</b> . For details, refer to <Not ready REMOTE and Function check> table.
S0010 Maintenance required	Collective signal 09: Indication according to NAMUR recommendation NE 107 Recommendation to perform maintenance.	For indicated value > 0: Press push button  <b>Details</b> to display a list of detailed indications.
S0011 Failure	Collective signal 10: Indication according to NAMUR recommendation NE 107 Actuator function failure, output signals are invalid	For indicated value > 0: Press push button  <b>Details</b> to display a list of detailed indications. For details, refer to <Faults and Failure> table.

Table 23:

Warnings and Out of specification		
Indication on display	Description/cause	Remedy
Config. warning	Collective signal 06: Possible cause: Configuration setting is incorrect. The device can still be operated with restrictions.	Press push button  Details to display a list of individual indications. For a description of the individual signals, refer to <Individual signals> table/ <b>Config. warning</b> (collective signal 06).
Internal warning	Collective signal 15: Device warnings The device can still be operated with restrictions.	Press push button  Details to display a list of individual indications. For a description of the individual signals, refer to <Individual signals> table/ <b>Internal warning</b> (collective signal 15).
24 V DC external	The external 24 V DC voltage supply of the controls has exceeded the power supply limits.	Check 24 V DC voltage supply.
Wrn op.mode run time	Warning on time max. running time/h exceeded	<ul style="list-style-type: none"> <li>Check modulating behaviour of actuator.</li> <li>Check parameter <b>Perm. run time M0356</b>, re-set if required.</li> </ul>
Wrn op.mode starts	Warning on time max. number of motor starts (starts) exceeded	<ul style="list-style-type: none"> <li>Check modulating behaviour of actuator.</li> <li>Check parameter <b>Permissible starts M0357</b>, re-set if required.</li> </ul>
Failure behav. active	The failure behaviour is active since all required setpoints and actual values are incorrect.	Verify signals: <ul style="list-style-type: none"> <li>Setpoint E1</li> <li>Actual value E2</li> <li>Actual process value E4</li> <li>Check connection to master.</li> </ul>
Wrn input AIN 1	Warning: Loss of signal analogue input 1	Check wiring.
Wrn input AIN 2	Warning: Loss of signal analogue input 2	Check wiring.
Wrn setpoint position	Warning: Loss of signal setpoint position Possible causes: For an adjusted setpoint range of e.g. 4 – 20 mA, the input signal is 0 (signal loss). For a setpoint range of 0 – 20 mA, monitoring is not possible.	Check setpoint signal.
Op. time warning	The set time (parameter <b>Perm.op. time, manual M0570</b> ) has been exceeded. The preset operating time is exceeded for a complete travel from end position OPEN to end position CLOSED.	The warning indications are automatically cleared once a new operation command is executed. <ul style="list-style-type: none"> <li>Check valve.</li> <li>Check parameter <b>Perm.op. time, manual M0570</b>.</li> </ul>
Wrn controls temp.	Temperature within controls housing too high.	Measure/reduce ambient temperature.
Time not set	Real time clock has not yet been set.	Set time.
RTC voltage	Voltage of the RTC button cell is too low.	Replace button cell.
PVST fault	Partial Valve Stroke Test (PVST) could not be successfully completed.	Check actuator (PVST settings).
PVST abort	Partial Valve Stroke Test (PVST) was aborted or could not be started.	Perform RESET or restart PVST.
Wrn no reaction	No actuator reaction to operation commands within the set reaction time.	<ul style="list-style-type: none"> <li>Check movement at actuator.</li> <li>Check parameter <b>Reaction time M0634</b>.</li> </ul>
Wrn FOC <sup>1)</sup>	Optical receiving signal (channel 1) incorrect (no or insufficient Rx receive level) or RS-485 format error (incorrect bit(s))	Check/repair FO cables.
Wrn FO cable budget <sup>1)</sup>	Warning: FO cable system reserve reached (critical or permissible Rx receive level)	Check/repair FO cables.
Wrn FOC connection <sup>1)</sup>	Warning FO cable connection is not available.	Fit FO cable connection.
Torque wrn OPEN	Limit value for torque warning in direction OPEN exceeded.	Check parameter <b>Wrn torque OPEN M0768</b> , re-set if required.

Warnings and Out of specification		
Indication on display	Description/cause	Remedy
Torque wrn CLOSE	Limit value for torque warning in direction CLOSE exceeded.	Check parameter <b>Wrn torque CLOSE M0769</b> , re-set if required.
PVST required	Execution of PVST (Partial Valve Stroke Tests) is required.	
Maintenance required	Maintenance is required.	

1) For actuator controls with FOC connection

Table 24:

Faults and Failure		
Indication on display	Description/cause	Remedy
Configuration error	Collective signal 11: Configuration error has occurred.	Press push button  <b>Details</b> to display a list of individual indications. For a description of the individual signals, refer to <Individual signals> table/ <b>Configuration error</b> (collective signal 11).
Config. error REMOTE	Collective signal 22: Configuration error has occurred.	Press push button  <b>Details</b> to display a list of individual indications. For a description of the individual signals, refer to <Individual signals> table/ <b>Config. error REMOTE</b> (collective signal 22).
Internal error	Collective signal 14: Internal error has occurred.	AUMA service Press push button  <b>Details</b> to display a list of individual indications. For a description of the individual signals, refer to <Individual signals> table/ <b>Internal error</b> (collective signal 14).
Torque fault CLOSE	Torque fault in direction CLOSE	Perform one of the following measures: <ul style="list-style-type: none"> <li>• Issue operation command in direction OPEN.</li> <li>• Set selector switch to position <b>Local control</b> (LOCAL) and reset fault indication via push button <b>RESET</b>.</li> <li>• Execute reset command via fieldbus.</li> </ul>
Torque fault OPEN	Torque fault in direction OPEN	Perform one of the following measures: <ul style="list-style-type: none"> <li>• Issue operation command in direction CLOSE.</li> <li>• Set selector switch to position <b>Local control</b> (LOCAL) and reset fault indication via push button <b>RESET</b>.</li> <li>• Execute reset command via fieldbus.</li> </ul>
Phase fault	<ul style="list-style-type: none"> <li>• When connecting to a 3-ph AC system and with internal 24 V DC supply of the electronics: Phase 2 is missing.</li> <li>• When connecting to a 3-ph AC system: One of the phases L1, L2 or L3 is missing.</li> </ul>	Test/connect phases.
Thermal fault	Motor protection tripped	<ul style="list-style-type: none"> <li>• Cool down, wait.</li> <li>• If the fault indication display persists after cooling down: <ul style="list-style-type: none"> <li>- Set selector switch to position <b>Local control</b> (LOCAL) and reset fault indication via push button <b>RESET</b>.</li> <li>- Execute reset command via fieldbus.</li> </ul> </li> <li>• Check fuses.</li> </ul>
Fault no reaction	No actuator reaction to operation commands within the set reaction time.	Check movement at actuator.
Poti Out of Range	Potentiometer is outside the permissible range.	Check device configuration: Parameter <b>Low limit Uspan M0832</b> must be less than parameter <b>Volt.level diff. potent. M0833</b> .
Wrn input AIN 1	Loss of signal analogue input 1	Check wiring.
Wrn input AIN 2	Loss of signal analogue input 2	Check wiring.

Faults and Failure		
Indication on display	Description/cause	Remedy
Incorrect rotary direct.	Contrary to the configured direction of rotation and the active operation command, the motor turns into the wrong direction.	Check operation command control. For 3-phase AC current mains, activate phase monitoring (parameter <b>Adapt rotary dir. M0171</b> ). Check device configuration setting (parameter <b>Closing rotation M0176</b> ). To delete the fault indication: Disconnect actuator controls from the mains and perform reboot.
Rectifier fault	Motor protection: Fault within converter	
DMF fault OPEN <sup>1)</sup>	The torque in direction OPEN, measured at the output drive shaft using the torque measurement flange, is too high.	Check <b>DMF trip torque OP</b> parameter. Check <b>DMF fault level</b> parameter.
DMF fault CLOSE <sup>1)</sup>	The torque in direction CLOSE, measured at the output drive shaft using the torque measurement flange, is too high.	Check <b>DMF trip torque CL</b> parameter. Check <b>DMF fault level</b> parameter.

1) For actuators equipped with torque measurement flange (DMF)

Table 25:


Not ready REMOTE and Function check (collective signal 04)		
Indication on display	Description/cause	Remedy
Wrong oper. cmd	Collective signal 13: Possible causes: <ul style="list-style-type: none"> <li>Several operation commands (e.g. OPEN and CLOSE simultaneously, or OPEN and SET-POINT operation simultaneously)</li> <li>A setpoint is present and the positioner is not active</li> </ul>	<ul style="list-style-type: none"> <li>Check operation commands (reset/clear all operation commands and send one operation command only).</li> <li>Set parameter <b>Positioner</b> to <b>Function active</b>.</li> <li>Check setpoint.</li> </ul> Press push button  <b>Details</b> to display a list of individual indications. For details, refer to <Individual indications> table.
Sel. sw. not REMOTE	Selector switch is not in position REMOTE.	Set selector switch to position REMOTE.
Service active	Operation via service interface (Bluetooth) and AUMA CDT service software.	Exit service software.
Disabled	Actuator is in operation mode Disabled.	Check setting and status of function <Local controls enable>.
EMCY stop active	The EMERGENCY stop switch has been operated. The motor control power supply (contactors or thyristors) is disconnected.	<ul style="list-style-type: none"> <li>Enable EMERGENCY stop switch.</li> <li>Reset EMERGENCY stop state by means of Reset command.</li> </ul>
EMCY behav. active	Operation mode EMERGENCY is active (EMERGENCY signal was sent). 0 V are applied at the EMERGENCY input.	<ul style="list-style-type: none"> <li>Detect cause for EMERGENCY signal.</li> <li>Verify failure source.</li> <li>Apply +24 V DC at EMERGENCY input.</li> </ul>
I/O interface	The actuator is controlled via the I/O interface (parallel).	Check I/O interface.
Handwheel active	Manual operation is activated.	Start motor operation.
FailState fieldbus	Fieldbus connection available, however no process data transmission by the master.	Verify master configuration
Local STOP	A local STOP is active. Push button STOP of local controls is operated.	Release push button STOP.
Interlock	An interlock is active.	Check interlock signal.
Interlock by-pass	By-pass function is interlocked.	Check states of main and by-pass valve.
PVST active	Partial Valve Stroke Test (PVST) is active.	Wait until PVST function is complete.

Table 26:

Individual indications	
Indication on display	Remedy
Config. warning (Collective signal 06)	
Wrn Setpoint Source	Configure analogue inputs AIN 1 or AIN 2, refer to <Input for setpoint position>
Wrn dead bands	Check positioner setting.
Wrn Fieldbus config.	Check fieldbus interface configuration.
Torque config. CLOSE	Verify torque switching setting.
Torque config. OPEN	Verify torque switching setting.
DIN 1 configuration – DIN 10 configuration	Signal assignment for the indicated digital input (DIN 1 – DIN 10) is incorrect. Reconfigure digital input.
Configuration EMCY	Check configuration.
Config. operat. profile	Check configuration.
FO configuration	Check configuration.
Heat.monitor.config.	Check configuration.
Fail.beh. config.	Check configuration.
Config. PID controller	Check configuration.
Configuration error (Collective signal 11)	
IE MCM	Check hardware equipment/article number MCM.
IE PSO	Check hardware equipment/article number PSO.
IE config. pos. transm.	Check hardware equipment/article number position transmitter.
IE parameter config.	Check position transmitter parameters.
IE SIL config.	The configuration for the SIL function is invalid.
IE FQM	The configuration for the FQM (fail safe) unit is invalid.
Configuration FUP	The configuration for the function plan is invalid. Check configuration.
MPV and CW closing	Multiport valve and clockwise closing.
Config.fault speed prof.	<ul style="list-style-type: none"> <li>Pivot points were not defined in ascending order.</li> <li>Positions of neighbouring pivot points were defined with identical positions.</li> <li>No pivot points have been activated for the individual directions</li> <li>Verify positions (order) of the pivot points.</li> <li>Verify activation of the pivot points.</li> </ul>
Hydraulics fault (Collective signal 12)	
Phase fault	When connecting to a 3-phase network: One of the phases L1, L2 or L3 is missing. Test/connect phases.
Thermal fault	Motor protection tripped <ul style="list-style-type: none"> <li>Cool down, wait.</li> <li>If the fault indication display persists after cooling down:               <ul style="list-style-type: none"> <li>Set selector switch to position <b>Local control</b> (LOCAL) and reset fault indication via push button <b>RESET</b>.</li> <li>Execute reset command via fieldbus.</li> </ul> </li> <li>Check fuses.</li> </ul>
Wrong oper. cmd (Collective signal 13)	
Incorr. cmd REMOTE1	Correct operation command, i.e. delete and set anew.
Incorr. cmd REMOTE2	Correct operation command, i.e. delete and set anew.
Command fieldbus	Correct operation command.
Setpoint pos. disabled	Verify availability of function (parameter <b>Activation M0212</b> )
Internal error (Collective signal 14)	

Individual indications	
Indication on display	Remedy
IE mot. prot. monitor	Check motor protection monitoring.
IE selector switch	Replace selector switch.
IE phase monitoring	Check power supply.
IE 24 V AC	Internal error: The internal 24 V AC voltage supply of the controls has exceeded the power supply limits. The 24 V AC voltage supply is used to control the reversing contactors, to assess the thermostats, to supply the internal actuator heater and, as an option, to generate the 115 V AC supply for the customer. <ul style="list-style-type: none"> <li>• Check power supply (level and wiring).</li> <li>• Check power supply unit.</li> </ul>
IE output defective	Check switchgear control.
IE position transmitter	Check actuator.
IE logic	Check logic.
IE fieldbus	Check fieldbus interface.
IE MWG	Check MWG.
IE LC	Check local controls.
IE Hall 1 calibration – IE Hall 5 calibration	Internal error: Calibration of Hall sensor 1 – 5 of the MWG is incorrect. Check MWG.
IE MWG calibration	Check MWG.
IE version	Check device configuration.
IE EEPROM	Check device configuration.
IE parameter	Check device configuration.
IE file access	Check device configuration.
IE reserve backup	Check device configuration.
IE registration	Check device configuration.
IE startup FB	Check device configuration.
IE startup sub-assy	Check device configuration.
IE LC exception	Check device configuration.
IE logic exception	Check device configuration.
IE MWG exception	Check device configuration.
IE bus exception	Check device configuration.
IE MWG end positions	Check device configuration.
Internal warning (Collective signal 15)	
Wrn heater	Check heater.
24 V DC customer	The 24 V DC customer auxiliary supply to control the digital inputs has failed. Check 24 V DC inputs (DIN).
24 V DC internal	The internal 24 V DC power supply of the controls used to provide the electronics components (sub-assemblies within the AC 01.2 controls and in the actuator) has exceeded the power supply limits . Check internal 24 V DC voltage supply.
Wrn res. data in use	Reboot AUMATIC.
Wrn ref.actual position	Operate actuator fully in end positions OPEN and CLOSED.
Wrn range act.pos.	Verify primary reduction gearing settings within the actuator.
Wrn sign.loss act.pos.	Check position feedback.
Wrn event mark	Check system configuration.
Wrn Tm mark	Check system configuration.
Config. error REMOTE (Collective signal 22)	
IE I/O interface	<ul style="list-style-type: none"> <li>• Check I/O interface M0139 parameter. The setting must correspond to the wiring diagram.</li> <li>• Check wiring.</li> <li>• Check I/O interface.</li> </ul>

Individual indications	
Indication on display	Remedy
IE remote interface	Check configuration.
IE remote Prm Config	Check configuration.

Table 27:

Status texts in menu S0001		
Indication on display	Description/cause	Remedy
Sensor failure	Hardware is either defective or not available: <ul style="list-style-type: none"> <li>for potentiometer, RWG, EWG = signal loss</li> <li>for MWG = calibration active or Hall sensor defective</li> </ul>	Check or replace hardware.
Not referenced	For potentiometer, RWG, EWG: end positions not set	Set end positions and perform reference operation.
Calibration	Calibration active	
Out of range	Outside the value range <ul style="list-style-type: none"> <li>for potentiometer = insufficient stroke between the set end positions</li> <li>for RWG, EWG = end position OPEN = end position CLOSED</li> <li>for MWG = excessive stroke between the set end positions</li> </ul>	Set valid stroke.
Invalid command	Invalid command	
Replacement value	Substitute value	
PCB failure	Sub-assembly failure	
Commlost	Communication between MWG and logic is interrupted. Possible causes: problem with contacts	AUMA service Replace MWG



## 17. Appendix

### 17.1. Selection overview for output contacts and indication lights (digital outputs DOUT)

Depending on the version, the actuator controls are equipped with up to 6 output contacts (digital outputs).

Table 28:

Signal	Description
Not used	–
End position CLOSED	End position CLOSED reached Indication depends on the type of seating and means either <ul style="list-style-type: none"> <li>• limit seating, end position CLOSED reached, or</li> <li>• torque seating, end position CLOSED reached</li> </ul>
End position OPEN	End position OPEN reached Indication depends on the type of seating and means either <ul style="list-style-type: none"> <li>• limit seating, end position OPEN reached, or</li> <li>• torque seating, end position OPEN reached</li> </ul>
End p. CLOSED, blink	End position CLOSED reached or intermediate position reached (The intermediate position is only indicated if parameter <b>Signal interm. pos. M0167</b> = OPEN/CLOSED = On.) Signal blinking: Actuator runs in direction CLOSE.
End p. OPEN, blink	End position OPEN reached or intermediate position reached. (The intermediate position is only indicated if parameter <b>Signal interm. pos. M0167</b> = OPEN/CLOSED = On.) Signal blinking: Actuator runs in direction OPEN.
Setpoint pos.reached	The position setpoint is within maximum error variable (outer dead band). Is only signalled if Modbus master has set the <b>Fieldbus SETPOINT</b> bit (process representation output).
Running CLOSE	Actuator runs in direction CLOSE.
Running OPEN	Actuator runs in direction OPEN.
Selector sw. LOCAL	Selector switch is in position LOCAL.
Selector sw. REMOTE	Selector switch is in position REMOTE.
Selector sw. OFF	Selector switch is in position OFF.
Limit switch CLOSED	Limit switch operated in direction CLOSE
Limit switch OPEN	Limit switch operated in direction OPEN
Torque sw. CLOSED	Torque in direction CLOSE exceeded
Torque sw. OPEN	Torque in direction OPEN exceeded
NAMUR failure	Collective signal 10: Indication according to NAMUR recommendation NE 107 Actuator function failure, output signals are invalid.
NAMUR funct. check	Collective signal 08: Indication according to NAMUR recommendation NE 107 The actuator is being worked on; output signals are temporarily invalid.
NAMUR out of spec.	Collective signal 07: Indication according to NAMUR recommendation NE 107 Difference between setpoint and actual value is too important (exceeding the normal operation conditions).
NAMUR mainten. req.	Collective signal 09: Indication according to NAMUR recommendation NE 107 Recommendation to perform maintenance.
Fault	Collective signal 03: Contains the result of a disjunction (OR operation) of all faults.
Warning	Collective signal 02: Contains the result of an OR disjunction of all warnings.
Not ready REMOTE	Collective signal 04: Contains the result of a disjunction (OR-operation) of the signals, forming the "Not ready REMOTE" group. The actuator cannot be operated from REMOTE. The actuator can only be operated via the local controls.

Signal	Description
Fault (configurable)	<p>Collective signal 19:</p> <p>This signal can be configured (parameter <b>Fault (Cfg) M0880</b>) and comprises a combination of the following signals:</p> <ul style="list-style-type: none"> <li>• Configuration error</li> <li>• Config. error REMOTE</li> <li>• Internal error</li> <li>• Torque fault CLOSE</li> <li>• Torque fault OPEN</li> <li>• Phase fault</li> <li>• Incorrect phase seq</li> <li>• Mains quality</li> <li>• Thermal fault</li> <li>• Fault no reaction</li> <li>• Wrn input AIN 1</li> <li>• Wrn input AIN 2</li> <li>• Rectifier fault</li> <li>• DMF fault OPEN</li> <li>• DMF fault CLOSE</li> </ul>
Warnings (Cgg)	<p>Collective signal 20:</p> <p>This signal can be configured (parameter <b>Warnings (Cfg) M0881</b>) and comprises a combination of the following signals:</p> <ul style="list-style-type: none"> <li>• Config. warning</li> <li>• Internal warning</li> <li>• 24 V DC external</li> <li>• Wrn op.mode run time</li> <li>• Wrn op.mode starts</li> <li>• Failure behav. active</li> <li>• Wrn input AIN 1</li> <li>• Wrn input AIN 2</li> <li>• Wrn setpoint position</li> <li>• Op. time warning</li> <li>• Wrn controls temp.</li> <li>• Time not set</li> <li>• RTC voltage</li> <li>• PVST fault</li> <li>• PVST abort</li> <li>• Wrn no reaction</li> <li>• Wrn FOC</li> <li>• Wrn FO cable budget</li> <li>• Wrn FOC connection</li> <li>• Torque wrn OPEN</li> <li>• Torque wrn CLOSE</li> <li>• PVST required</li> <li>• Maintenance required</li> <li>• AUMA warning 2</li> </ul>
Not ready REM (Cfg)	<p>Collective signal 21:</p> <p>This signal can be configured (parameter <b>Not ready REMOTE (Cfg) M0882</b>) and comprises a combination of the following signals:</p> <ul style="list-style-type: none"> <li>• Wrong oper. cmd</li> <li>• Sel. sw. not REMOTE</li> <li>• Service active</li> <li>• EMCY stop active</li> <li>• EMCY behav. active</li> <li>• I/O interface</li> <li>• Handwheel active</li> <li>• FailState fieldbus</li> <li>• Local STOP</li> <li>• Interlock</li> <li>• Interlock by-pass</li> <li>• PVST active</li> </ul>
Operation pause active	Actuator is in pause time of stepping mode.

Signal	Description
Start stepping mode	The actuator is within the set stepping range.
Actuator running	Actuator is running (output drive is moving). Hard wired collective signal consisting of: <ul style="list-style-type: none"> <li>Running LOCAL</li> <li>Running REMOTE</li> <li>Handwheel oper.</li> </ul>
Running LOCAL	Output drive rotates due to operation command from LOCAL.
Running REMOTE	Output drive rotates due to operation command from REMOTE.
Handwheel oper.	Output drive rotates without electric operation command.
In intermediate pos.	The actuator is in an intermediate position e.g. neither in end position OPEN nor in end position CLOSED.
Intermediate pos. 1	Intermediate position 1 reached
Intermediate pos. 2	Intermediate position 2 reached
Intermediate pos. 3	Intermediate position 3 reached
Intermediate pos. 4	Intermediate position 4 reached
Intermediate pos. 5	Intermediate position 5 reached
Intermediate pos. 6	Intermediate position 6 reached
Intermediate pos. 7	Intermediate position 7 reached
Intermediate pos. 8	Intermediate position 8 reached
Intermediate pos. 9	Intermediate position 9 reached
Intermediate pos. 10	Intermediate position 10 reached
Intermediate pos. 11	Intermediate position 11 reached
Intermediate pos. 12	Intermediate position 12 reached
Intermediate pos. 13	Intermediate position 13 reached
Intermediate pos. 14	Intermediate position 14 reached
Intermediate pos. 15	Intermediate position 15 reached
Intermediate pos. 16	Intermediate position 16 reached
Input DIN 1	A high signal (+24 V DC) is present at digital input 1.
Input DIN 2	A high signal (+24 V DC) is present at digital input 2.
Input DIN 3	A high signal (+24 V DC) is present at digital input 3.
Input DIN 4	A high signal (+24 V DC) is present at digital input 4.
Input DIN 5	A high signal (+24 V DC) is present at digital input 5.
Input DIN 6	A high signal (+24 V DC) is present at digital input 6.
EMCY stop active	Operation mode EMERGENCY stop is active (EMERGENCY stop button has been pressed).
Torque fault CLOSE	Torque fault in direction CLOSE
Torque fault OPEN	Torque fault in direction OPEN
Torque fault	Torque fault in directions CLOSE or OPEN
Thermal fault	Motor protection tripped
Phase fault	One phase missing
Fieldbus DOUT 1	High signal at fieldbus, digital output 1
Fieldbus DOUT 2	High signal at fieldbus, digital output 2
Fieldbus DOUT 3	High signal at fieldbus, digital output 3
Fieldbus DOUT 4	High signal at fieldbus, digital output 4
Fieldbus DOUT 5	High signal at fieldbus, digital output 5
Fieldbus DOUT 6	High signal at fieldbus, digital output 6
Fieldbus DOUT 7	High signal at fieldbus, digital output 7
Fieldbus DOUT 8	High signal at fieldbus, digital output 8
Fieldbus DOUT 9	High signal at fieldbus, digital output 9
Fieldbus DOUT 10	High signal at fieldbus, digital output 10

Signal	Description
Fieldbus DOUT 11	High signal at fieldbus, digital output 11
Fieldbus DOUT 12	High signal at fieldbus, digital output 12
FailState fieldbus	No valid communication via fieldbus (despite available connection).
Handwheel active	Manual operation is active (handwheel is engaged); optional signal.
PVST active	Partial Valve Stroke Test (PVST) is active.
PVST fault	Partial Valve Stroke Test (PVST) could not be successfully completed.
PVST abort	Partial Valve Stroke Test (PVST) was aborted or could not be started. Remedy: Perform RESET or restart PVST.
Failure (configurable)	This signal can be configured (parameter <b>Failure (configurable) M0879</b> ) and comprises a combination of the following signals which can also be configured: <ul style="list-style-type: none"> <li>• <b>Fault (Cfg) M0880</b></li> <li>• <b>Warnings (Cfg) M0881</b></li> <li>• <b>Not ready REMOTE (Cfg) M0882</b></li> </ul>
Interlock Remote	Function Interlock is active for operation mode REMOTE.
Interlock Local	Function Interlock is active for operation mode Local.
Interlock OPEN	Interlock OPEN is active (enable signal for operation commands in direction OPEN available).
Interlock CLOSE	Interlock CLOSED is active (enable signal for operation commands in direction CLOSE available).
Interlock	The operation mode Interlock is active.
Bypass Sync Out	<By-pass function> enable for operation commands of main or by-pass valves is active.
Interlock by-pass	Operation command executed without enable signal <b>Bypass Sync Out</b> .
Safe ESD	Safe ESD function (Emergency Shut Down) is active.
Safe Stop	Safe STOP function is active.
SIL fault	A SIL fault has occurred (collective signal).
SIL function active	A SIL function is active. Collective signal of both states, Safe ESD or Safe STOP.
System ok	The actuator is switched on and no fault is present
Torque wrn OPEN	
Torque wrn CLOSE	
Maintenance reminder	This signal will be activated if at least on the lifetime accounts (in %) has passed the activation threshold configured for this signal. This signal can be configured (parameter <b>Maintenance required M0871</b> ) and comprises a combination of the following signals: <ul style="list-style-type: none"> <li>• <b>Mainten. mechanics</b></li> <li>• <b>Mainten. lubricant</b></li> <li>• <b>Mainten. interval</b></li> </ul>
Disabled	The operation via the push buttons on the local controls is disabled.
Runs_OP/CL+blinker	The actuators runs while the indication light for the respective direction of operation (OPEN/CLOSE) is blinking simultaneously at local controls.

## 17.2. Selection list of binary signals for digital inputs (DIN)

**Conditions:** <Additional inputs> or additional <Parallel interface>

Depending on the version, the actuator controls are equipped with up to 10 digital inputs.

The inputs are designed for binary signals (standard input level: +24 V DC) and can be used, for example, to receive operation commands OPEN, STOP, CLOSE, to control intermediate positions or for the EMERGENCY signal.

### Configuration of digital inputs

Required user level: **Specialist (4)**.

M ▶ **Device configuration M0053**  
**I/O interface M0139**  
**Digital inputs M0116**

Table 29:

Signal	Description
Not used	Input not assigned
MODE	Change-over between OPEN - CLOSE control and setpoint control
OPEN	Operation command OPEN
CLOSE	Operation command CLOSE
STOP	Operation command STOP
RESET	Reset fault signal
I/O interface	Change-over between fieldbus interface and parallel interface
OPEN / CLOSE	Operation command OPEN/CLOSE for two-wire control
EMERGENCY	Operation mode for EMERGENCY behaviour
Intermediate pos. 1	Operation command: Run to intermediate position 1.
Intermediate pos. 2	Operation command: Run to intermediate position 2.
Intermediate pos. 3	Operation command: Run to intermediate position 3.
Intermediate pos. 4	Operation command: Run to intermediate position 4.
Intermediate pos. 5	Operation command: Run to intermediate position 5.
Intermediate pos. 6	Operation command: Run to intermediate position 6.
Intermediate pos. 7	Operation command: Run to intermediate position 7.
Intermediate pos. 8	Operation command: Run to intermediate position 8.
Intermediate pos. 9	Operation command: Run to intermediate position 9.
Intermediate pos. 10	Operation command: Run to intermediate position 10.
Intermediate pos. 11	Operation command: Run to intermediate position 11.
Intermediate pos. 12	Operation command: Run to intermediate position 12.
Intermediate pos. 13	Operation command: Run to intermediate position 13.
Intermediate pos. 14	Operation command: Run to intermediate position 14.
Intermediate pos. 15	Operation command: Run to intermediate position 15.
Intermediate pos. 16	Operation command: Run to intermediate position 16.
MPV: CW Position 1	Clockwise approach of position 1
MPV: CCW Position 1	Counterclockwise approach of position 1
MPV: CW Position 2	Clockwise approach of position 2
MPV: CCW Position 2	Counterclockwise approach of position 2
MPV: CW Position 3	Clockwise approach of position 3
MPV: CCW Position 3	Counterclockwise approach of position 3
MPV: CW Position 4	Clockwise approach of position 4
MPV: CCW Position 4	Counterclockwise approach of position 4
MPV: CW Position 5	Approach position 5 clockwise
MPV: CCW Position 5	Approach position 5 counterclockwise
MPV: CW Position 6	Approach position 6 clockwise
MPV: CCW Position 6	Approach position 6 counterclockwise
MPV: CW Position 7	Approach position 7 clockwise
MPV: CCW Position 7	Approach position 7 counterclockwise
MPV: CW Position 8	Approach position 8 clockwise
MPV: CCW Position 8	Approach position 8 counterclockwise
MPV: CW Position 9	Approach position 9 clockwise
MPV: CCW Position 9	Approach position 9 counterclockwise
MPV: CW Position 10	Approach position 10 clockwise
MPV: CCW Position 10	Approach position 10 counterclockwise
MPV: CW Position 11	Approach position 11 clockwise
MPV: CCW Position 11	Approach position 11 counterclockwise

Signal	Description
MPV: CW Position 12	Approach position 12 clockwise
MPV: CCW Position 12	Approach position 12 counterclockwise
MPV: CW Position 13	Approach position 13 clockwise
MPV: CCW Position 13	Approach position 13 counterclockwise
MPV: CW Position 14	Approach position 14 clockwise
MPV: CCW Position 14	Approach position 14 counterclockwise
MPV: CW Position 15	Approach position 15 clockwise
MPV: CCW Position 15	Approach position 15 counterclockwise
MPV: CW Position 16	Approach position 16 clockwise
MPV: CCW Position 16	Approach position 16 counterclockwise
MPV DriveCW	Clockwise actuator operation
MPV DriveCCW	Counterclockwise actuator operation
Input DIN 1	Signal for controlling output contact
Input DIN 2	Signal for controlling output contact
Input DIN 3	Signal for controlling output contact
Input DIN 4	Signal for controlling output contact
Enable Local	Enables the selector switch function (LOCAL/OFF) on the local controls
Enable OPEN	Interlock: Enables operation command in direction OPEN
Enable CLOSE	Interlock: Enables operation command in direction CLOSE
PID internal setpoint 2	Internal PID setpoint
Remote2_active	Activation of operation mode Remote II
Remote2_OPEN	Operation command OPEN in operation mode Remote II
Remote_2_CLOSE	Operation command CLOSE in operation mode Remote II
Remote2_STOP	Operation command STOP in operation mode Remote II
Execute PVST	PVST is executed
Bypass Sync In	Enable signal for <By-pass function>
PID setpoint I/O	Change-over of process controller setpoint source between fieldbus interface and I/O interface
PID act. value I/O	Change-over of process controller actual value source between fieldbus interface and I/O interface
RelOPENandCLOSE	Enable signal OPEN/CLOSE
Speed int. sel. bit 0	Signal 1 for external speed selection
Speed int. sel. bit 1	Signal 2 for external speed selection

## Index

### A

Activate/deactivate heater	83
Activate functions	117
Actual configuration	128
Actual value - indication on display	21
Actual value source - process controller	72
Actuator controls heater system	83
Actuator operation from remote	14
Actuator type (MPV)	119
Adaptive behaviour	61
Additional inputs for fieldbus	76
Analogue output 1	28
Analogue output 1 adjustment	30
Analogue output 1 signal range	29
Analogue output 2	30
Analogue output 2 adjustment	30
Analogue output 2 signal range	30
Analogue outputs	28
Analogue signals	28
Appendix	153
Application functions	49
AUMA Assistant App	129
AUMA Cloud	129
Auto change-over I/O	78
Automatic deblocking	81

### B

Backlash compensation (MPV)	124
Basic settings	36
Baud rate	75
Behaviour	99
Binary input signals	156
Bluetooth	129
Bluetooth diagnostic	130
Bluetooth interface	103
Bus address	74
Bus failure	97
By-pass function	79
By-pass speed profile	93

### C

CDT	128, 129
Change-over between OPEN - CLOSE control and setpoint control	65
Change-over to passive channel	78
Characteristics	138, 138, 140, 141
Closing fully/opening fully	63
Combination of fieldbus-parallel interface	77
Commissioning	9
Commissioning (indications on display)	19
Configurable signals	27
Connection monitoring time	75
Contrast	48
Control	33
Controller behaviour (process controller)	68
Correction of inertia (MPV)	124
Corrective action	146
Cycles	109

### D

Data export	127
Data import	127
Date	44
Date format	44
Deactivate heater monitoring within actuator controls	114
Dead band	62, 62
Dead band (MPV)	124
Dead time	63
Define pivot points	54
Delay time	88
Delay time <EMERGENCY operation>	94
Device temperatures	145
Diagnostic Interface	131
Diagnostics	130
Digital inputs	156, 156
Digital inputs (diagnostics)	131
Digital outputs	27
Digital outputs (diagnostics)	131
Direct display via ID	16
Direction of rotation	126
Direction of rotation:	126
Directives	9
Display (indications)	19
Display formats	44
Display operating time	145
Down time	115

<b>E</b>			
Electronic device ID	130		
Electronics monitoring power supply	113		
EMERGENCY behaviour	88		
EMERGENCY operation	88, 91		
EMERGENCY speed	91		
EMERGENCY stop	34		
Enable functions	117		
Enable operation commands	97		
Enabling local controls	94		
End position seating	36		
End position tolerance	63		
Enforce REMOTE control	95		
Error - indication on display	20		
Error variable	62		
Event report	137		
<b>F</b>			
Factory setting	126		
Failure behaviour	85		
Failure functions	85		
Failure - indication on display	24		
Failure operation	85		
Failure position	86		
Failure source (EMERGENCY operation)	90		
Failure source (failure operation)	86		
Failure source (Interlock)	98		
Fault - indication on display	23		
Fault signal - configurable	27		
Fieldbus address	74, 74		
Fieldbus auto enable	97		
Fieldbus failure	78, 78, 97		
Firmware update	128		
Firmware version	128		
FOC (diagnostic)	134		
FO cable baud rate	79		
FO cable monitoring	78		
FO cable topology	79		
FO connection	78		
Function check - indication on display	23		
Functions: activate/enable	117		
Fuses	146		
<b>G</b>			
Gear reduction ratio	119		
<b>H</b>			
Heater	114		
Heater in switch compartment	83		
Heater monitoring	114		
Heater monitoring time	115		
Heater on control unit	83		
Heater system	114		
Heater system monitoring	114		
Histogram	141, 142, 143		
Histograms	141		
Home port	120		
<b>I</b>			
I/O interface change-over	77		
Incorrect entry	18		
Indication light colour	25		
Indication lights	25		
Indications	19		
Indications on display	19		
Input of setpoint position	66		
Interface (diagnostics)	131		
Interlock:	97		
Interlock: by-pass	93		
Interlock behaviour	98		
Intermediate position indication via LEDs	25		
Intermediate positions	56		
Internal process setpoint	70		
Intrusive	12		
Inverse operation	70		
<b>L</b>			
Language in the display	18		
LEDs (indication lights)	25		
Limit seating	36		
Limit setting range	63		
Limit switching	39		
Local actuator operation	13		
Local control	13		
Local controls	13		
Local setting	14		
Local Stop	99		
Local stop: by-pass	93		
Loss of process setpoint	70		
Loss of signal	85, 86		
Loss of signal (fieldbus)	78, 97		
Loss of signal process setpoint	70		



## M

Main menu	15
Maintenance	10
Maintenance required - indication on display	24
Maintenance signals	143
Menu navigation	14
Modbus address	74
Modbus interface	74
Modbus interface: diagnostic	134
MODE	65
Monitoring functions	107
Monitoring time (Modbus connection)	75
Motion detector	112
Motor heater	84
Motor protection. by-pass	92
Motor protection behaviour	109
Motor protection monitoring	109, 109
Motor running time position histogram	141
Motor running time-temperature (histogram)	142
Motor running time-torque (histogram)	143
Motor starts	109
MWG (diagnostic)	133

## N

Non-Intrusive	12
Not ready REMOTE - indication on display	23
Number format	45, 45
Number of ports (positions)	120

## O

Off time	60, 74
On time	74, 109
On time monitoring (diagnostics)	133
OPEN - CLOSE control (Remote OPEN - CLOSE)	65
Operating data	136
Operating the actuator from local controls	13
Operation	9, 13, 32
Operation commands - indications on display	21
Operation profile	58
Operation profile: by-pass	92
Operation time monitoring	111
Out of specification - indication on display	23
Output contacts	27
Output signals	27
Overload protection	107
Overrun	62

## P

Parity	75
Partial Valve Stroke Test	100
Password	16
Password change	17
Password entry	17
Permissible operation time	111
Permissible starts/h	110
Phase failure monitoring	115
Plant Asset Management	136
Positioner	60
Positioner (diagnostic)	133
Positioner - indication on display	21
Positions (pivot points)	57
Position setpoint – input	66
Position-time characteristic	140
Position transmitter (diagnostic)	132
Position unit	45
Potentiometer (diagnostic)	132
Primary fuses	146
Priority REMOTE	95
Process controller	67
Process controller (diagnostics)	134
Process factor unit	46
Process setpoint – loss	70
Product variants	119
Proportional amplification Kp	71
Protective measures	10
Push-to-run operation	13
Push-to-run operation local	32
Push-to-run operation Remote	33
PVST	100

## Q

Qualification of staff	9
------------------------	---

## R

Rate time Td	71
Reaction monitoring	111
Reaction time	112
Reaction time, permissible	112
Reaction time of heater monitoring	115
Redundancy	76
Remote actuator operation	14
Reset time Tn	71
Response telegrams	76
Reversing prevention time	85
Running time	109
Running time (motor)	141, 142, 143
RWG (diagnostic)	132

**S**

Safety instructions	9
Safety instructions/warnings	9
Selection overview for output contacts and indication lights	153
Selector switch functions	94
Self-retaining	13
Self-retaining local	32
Self-retaining Remote	33
Service	35
Service functions	126
Setpoint control (Remote SETPOINT)	65
Setpoint - indication on display	21
Setpoint source - process controller	69
Set speed range	51
Signal behaviour (multiport valve)	124
Signal loss	86
Signal output units (AOUT)	47
Signals	27
Signals (analogue)	28
Signals - configurable	27
Simulation	134
Slave address	74
Source (PVST)	101
Speed: set	50
Speed (failure behaviour)	87
Speed (PVST)	103
Speed change	51
Speed functions	49
Speed profile	53
Speed reduction (before end positions)	52
Speed reduction (positioner)	64
Speed setpoint	49
Speed source	49
Speed source - process controller	72
Split Range operation	66
Standards	9
Start of stepping mode	74
Status menu	15
Status signals	27
Status signals - configurable	27
Stepping mode	72
Stepping mode: by-pass	92
Stop bit	75
Stop step	74
Switching off for reaction time error	112

**T**

Target configuration	128
Temperature (motor)	142
Temperature indication	145
Temperature monitoring	114
Temperature-time characteristic	141
Temperature unit	45
Thermal monitoring	109
Time	44
Time for speed increase	51
Timeout	18
Torque (histogram)	143
Torque by-pass	107, 107
Torque - indication on display	21
Torque limitation	108
Torque monitoring	107
Torque seating	36
Torque switching	37, 38
Torque switching: by-pass	92
Torque-travel characteristic	138
Torque unit	45
Torque warning	107
Two-wire control	60
Type of seating for end positions	36

**U**

User level	16
------------	----

**V**

Valve position - indication on display	20
Verification of sub-assemblies	115

**W**

Warnings - indication on display	22
Working value units (AIN)	47

## Parameter index

103, 103, 106, 106

### 0

0/4 mA (initial value) 31

### 2

20 mA (final value) 31

24 V DC customer 151

24 V DC external 147

24 V DC internal 151

### A

Abs. end pos. CLOSED 133

Abs. end pos. OPEN 133

Absolute value 133

Accept actual config. 128

Activation 103, 103

Actual position 28, 133

Actual process value 134

Actuator behaviour 112

Actuator type 119

Adjustment AOUT 1 30

Adjustment AOUT 2 31

### B

Backlash comp. 124

Behaviour Tx 76

Bluetooth add.partner 129, 131

Bluetooth address 129, 131

Buffer size 138

By-pass application 81

By-pass Interlock 93

By-pass Local STOP 93

By-pass operat.profile 92

Bypass speed profile 93

By-pass timer 92

By-pass torque 92

### C

Calibration 152

Change passwords 17

Closing rotation 126

Coding DOUT 1 27

Colour ind.light 1 26

Colour ind.light 2 26

Colour ind.light 3 26

Colour ind.light 4 26

Colour ind.light 5 26

Command fieldbus 150

Commlost 152

Config. error REMOTE 148, 148, 151

Config.fault speed prof. 150

Config. operat. profile 150

Config. PID controller 150

Config. warning 147, 147, 150

Configuration EMCY 150

Configuration error 148, 148, 150

Configuration FUP 150

Create factory settings 127

### D

Date and time 44

Dead band CLOSE 62

Dead band OPEN 62

Deblocking attempts 82

Detect. time dt 112

Detect. time dt (MWG) 112

Device ID 130

Device tag 129, 131

DIN 1 configuration 150

DIN 4 configuration 134

Disabled 149

DMF fault CLOSE 149

DMF fault OPEN 149

Duty type monitoring 110

### E

EMCY behav. active 149

EMCY behaviour 89

EMCY fail.reac. 90

EMCY operation 91

EMCY operation mode 90

EMCY position 91

EMCY position MPV 91

EMCY source 90

EMCY stop active 149

End position CLOSED 36

End position OPEN 36

End stepping CLOSE 74

End stepping OPEN 74

Event filter for Events 137

Export all data 127

Export all parameters 127

Export event report 127

**F**

Fail.beh. config.	150
Fail.pos.OPEN CLOSE	87
FailState fieldbus	149
Failure	146
Failure (configurable)	28
Failure behav. active	147
Failure position MPV	87
Failure speed CLOSE	87
Failure speed OPEN	87
Fault	146
Fault (Cfg)	28
Fault no reaction	148
Fieldbus AOUT 1	29
Fieldbus AOUT 2	29
Fieldbus operation	78
File size event. rep.	137
Firmware	128
FO cables	134
FOC connection	78, 79, 79
FOC FPGA version	134
FOC level channel 1	134
FO configuration	150
FOC RS-485 error	134
Function check	146

**H**

Handwheel active	149
Heat.monitor.config.	150
Heater control unit	83
Heater monitor	115
Heating sys. mon. time	115
High limit AIN 1	66
High limit target value	67
Hydraulics fault	150
Hysteresis	58, 125
Hysteresis 1	58

<b>I</b>		Invalid command	152
I/O interface	149		
Identification	130	<b>L</b>	
IE 24 V AC	151	Language	18
IE bus exception	151	Limit CLOSE	64
IE config. pos. transm.	150	Limit OPEN	64
IE EEPROM	151	Local STOP	99, 149
IE fieldbus	151	Low limit AIN 1	66
IE file access	151	Low limit RWG	133
IE FQM	150	Low limit target value	67
IE Hall 1 calibration	151	Low limit Uspan	132
IE Hall 5 calibration	151		
IE I/O interface	151	<b>M</b>	
IE LC	151	Maintenance interval	144, 145
IE LC exception	151	Maintenance required	146, 148
IE logic	151	Max. value at 100.0 %	46, 47, 47, 48
IE logic exception	151	Maximum stroke	133
IE MCM	150	MD1 slave address	74
IE mot. prot. monitor	151	MD2 slave address	74
IE MWG	151	Minimum stroke	133
IE MWG calibration	151	Modbus	74, 75, 75, 75, 75, 76, 76
IE MWG end positions	151	Modulating behaviour	69
IE MWG exception	151	Monitor 24 V DC cust.	113
IE output defective	151	Monitor 24 V DC ext.	114
IE parameter	151	Monitor heat. system	114
IE parameter config.	150	Monitoring time	75
IE phase monitoring	151	MPV and CW closing	150
IE position transmitter	151	MPV home port	120
IE PSO	150	MPV sign. beh. 1	124
IE registration	151		
IE remote interface	152	<b>N</b>	
IE remote Prm Config	152	No. mot. starts/h	133
IE reserve backup	151	Not ready REMOTE	146
IE selector switch	151	Not ready REMOTE (Cfg)	28
IE SIL config.	150	Not referenced	152
IE startup FB	151	Number of ports	120
IE startup sub-assy	151		
IE version	151	<b>O</b>	
Import all parameters	128	Off time 1	60
Incorr. cmd REMOTE1	150	Off time CLOSE	74
Incorr. cmd REMOTE2	150	Off time OPEN	74
Incorrect rotary direct.	149	Off times	60
Indicat. light 5 (right)	25	On time CLOSE	74
Indication light 1 (left)	25	On time OPEN	74
Indication light 2	25	On time warning 1	110
Indication light 3	25	On time warning 2	110
Indication light 4	25	Op. com. PID contr.	134
Inner dead b. CLOSE	133	Op. time warning	147
Inner dead b. OPEN	133	Oper. mode Interlock	98
Input AIN 1	29	Oper. time monitoring	111, 111
Input AIN 2	29	Oper. time opposite	82
Interface	131	Operating time	145
Interface status	131	Operational info	136, 136, 136
Interlock	98, 149	Operational info total	136
Interlock by-pass	149	Operation behaviour	59
Interlock source	98	Operation behaviour 1	59
Internal error	148, 148, 150	Operation mode	111, 133
Internal warning	147, 147, 151	Outer dead b. CLOSE	133
Interval position-time	141	Outer dead b. OPEN	133

Outer dead band	63	<b>S</b>	
Out of range	152	Save interval	138
Out of specification	146	Scaling	46, 47, 47, 48
<b>P</b>		Sel. sw. not REMOTE	149
Parity/stop bit	75	Self-retaining Local	32
PCB failure	152	Self-retaining Remote II	33
Perm.op. time, manual	111	Sensor failure	152
Perm. run time	110	Service active	149
Permissible starts	110	Set end pos.CLOSED?	39, 42
Phase fault	148, 150	Set end pos. OPEN?	39, 42
Phase monitoring	116	Setpoint pos. disabled	150
Pivot point 1	57	Setpoint position	133
Posit. hyst. CLOSE	63	Sig. outp. activ. (AOUT)	47
Posit. hyst. OPEN	63	Signal AIN 1	50, 66
Position	46, 46	Signal AIN 2	50, 66
Position activation	46	Signal AOUT 1	28
Position-time	140	Signal AOUT 2	30
Position transm. MWG	133	Signal behaviour	57
Position transm. potent.	132	Signal behaviour 1	57
Position transm. RWG	133	Signal DOUT 1	27, 135
Potent. raw value /mV	132	Signal interm. pos.	25
Poti Out of Range	148	Signal loss beh.	85
Proc. var. activation	46	Signal outputs (AOUT)	47, 48
Process factor	46, 47	Signal range AOUT1	29
Process setpoint	134	Signal range AOUT2	30
PVST abort	147	Source	86
PVST active	149	Sp. source LOCAL CL	49
PVST behaviour	102	Sp. source LOC OP	49
PVST fault	147	Sp. source REM CL	49
PVST monitoring	102	Sp. source REM OP	49
PVST operating time	102	Speed adapt.prior end	52, 52
PVST operation mode	101	Speed EMCY CLOSE	91
PVST reminder	103	Speed EMCY OPEN	91
PVST reminder period	103	Speed internal1	50
PVST required	148	Speed internal2	50
PVST reversing time	102	Speed internal3	50
PVST source	101	Speed internal 4	51
PVST stroke	102	Speed profile mode	54
<b>R</b>		Speed PVST Close	103
Raw val. pos. CLOSED	132, 133	Speed PVST Open	103
Raw val. pos. OPEN	132, 133	Speed red.pr.end pos.	52
Rectifier fault	149	Speed red.prior setp.	64
Reduction ratio	119	Speed red. range	52, 65
Reload languages	127	Speed rem. max	51
Replacement value	152	Speed rem. min.	51
Reset characteristic	139	Split range operation	67
Reset factory settings	127	Start stepping CLOSE	74
Reset MPV homeport	121	Start stepping OPEN	74
Reset operation. info	136	States AIN 1	131
Response Timeout	75	States AIN 2	131
Revers. prevent. time	85	States AOUT 1	131
RTC voltage	147	States AOUT 2	131
Running dir. Interlock	98	States DIN	131
RWG raw value /mA	133	States DOUT	131
		Step mode CLOSE	73
		Step mode OPEN	73
		Switchgear	85
		System event filter	137

## T

Targ.speed end pos.	53
Temp. ctrls norm. ‰	29
Temp. ctrl unit norm ‰	29
Temperature-time	141
Thermal by-pass	92
Thermal fault	148, 150
Time format	45
Time not set	147
Timer CLOSE	73
Timer OPEN	73
Time speed incr.	51
Tolerance CLOSE	63
Tolerance OPEN	63
Tolerance range	83
Torque	29
Torque by-pass [s]	108
Torque config. CLOSE	150
Torque config. OPEN	150
Torque fault CLOSE	148
Torque fault OPEN	148
Torque peak [%]	108
Torque-travel	138, 139, 139, 140
Torque wrn CLOSE	148
Torque wrn OPEN	147
Travel diff. dx	113
Travel diff. dx (MWG)	113
Tripping time	116
Trip torque CLOSE	38
Trip torque OPEN	38
Type of seating	36

## U

Unit	46, 47, 47, 48
Units	46, 46, 46, 47, 47, 47, 47, 48
Update firmware	128

## V

Version	130
Volt.level diff. potent.	132

## W

Warnings	146
Warnings (Cfg)	28
Work. val. activ. (AIN)	47
Working values (AIN)	47, 47
Wrn controls temp.	147
Wrn dead bands	150
Wrn event mark	151
Wrn Fieldbus config.	150
Wrn FOC	147
Wrn FO cable budget	147
Wrn FOC connection	147
Wrn heater	151
Wrn input AIN 1	147, 148
Wrn input AIN 2	147, 148
Wrn no reaction	147
Wrn op.mode run time	147
Wrn op.mode starts	147
Wrn range act.pos.	151
Wrn ref.actual position	151
Wrn res. data in use	151
Wrn setpoint position	147
Wrn Setpoint Source	150
Wrn sign.loss act.pos.	151
Wrn Tm mark	151
Wrn torque CLOSE	107
Wrn torque OPEN	107
Wrong oper. cmd	149, 150

**AUMA Riester GmbH & Co. KG**

P.O. Box 1362  
**DE 79373 Muellheim**  
Tel +49 7631 809 - 0  
Fax +49 7631 809 - 1250  
info@auma.com  
www.auma.com