


Spare parts list  
**auma**<sup>®</sup>  
 Lever gearboxes  
 GF 50.3 – GF 125.3



**GF 50.3 – GF 125.3****Spare parts list – Lever gearboxes**

Please state type and commission no. of the device (see name plate) when ordering spare parts. Only original AUMA spare parts should be used. Failure to use original spare parts voids the warranty and exempts AUMA from any liability. Delivered spare parts may slightly vary from the representation.

No.	Designation	Type
003.0	Housing cover with drive shaft VZ	Sub-assembly
019.0	Housing VZ	Sub-assembly
020.0	Housing cover VZ	Sub-assembly
021.0	Drive shaft VZ	Sub-assembly
022.0	Planet carrier VZ	Sub-assembly
045.0	Internal geared wheel VZ	Sub-assembly
512.0	Flange for actuator	Sub-assembly
513.1	Grub screw	
517.0	Housing	Sub-assembly
518.0	Housing cover	Sub-assembly
519.1	Worm wheel	
520.0	Worm shaft	Sub-assembly
521.0	Travelling nut with pairs of safety wedge discs	Sub-assembly
521.1	Travelling nut	
521.2	Pair of safety wedge discs	
522.0	Bearing cover	Sub-assembly
523.0	End stop	Sub-assembly
526.0	End stop nut	Sub-assembly
527.0	Protection cover	Sub-assembly
534.0	Drive shaft	Sub-assembly
538.0	Bearing cover with drive shaft	Sub-assembly
546.0	Base flange	Sub-assembly
547.0	Lever	
S1	Seal kit	Set

We reserve the right to alter data according to improvements made. Previous documents become invalid with the issue of this document.

**Issue 1.11**

Y000.312/002/en

**auma<sup>®</sup>**