


Spare parts list
auma[®]
 Part-turn gearboxes
 GHE 05.1 – GHE 12.1



Spare parts list Part-turn gearboxes

Please state device type and our order number (see name plate) when ordering spare parts. Only original AUMA spare parts should be used. Failure to use original spare parts voids the warranty and exempts AUMA from any liability. Representation of spare parts may slightly vary from actual delivery.

Ref. no.	Designation	Type
525.0	Coupling	Sub-assembly
542.1-1.1	Crank handle with cylindrical grip	Sub-assembly
542.1-1.2	Crank handle with cylindrical grip and additional ball	Sub-assembly
542.1-2.1	Crank handle with conical grip	Sub-assembly
542.1-2.2	Crank handle with conical grip and additional ball	Sub-assembly
542.1-3.1	Handwheel with five-edge ring	Sub-assembly
542.1-3.2	Handwheel with five-edge ring and additional ball	Sub-assembly
542.1-4.1	Handwheel with five-ripple ring	Sub-assembly
542.1-4.2	Handwheel with five-ripple ring and additional ball	Sub-assembly