


Spare parts list  
**auma**<sup>®</sup>  
Electrical connections (straight)  
for actuators  
SGM 04.1 – SGM 10.1  
SVM 05.1 – SVM 07.5  
Fieldbus



**Spare parts list Electrical connections (straight) for actuators Fieldbus**

---

Please state device type and our order number (see name plate) when ordering spare parts. Only original AUMA spare parts should be used. Failure to use original spare parts voids the warranty and exempts AUMA from any liability. Representation of spare parts may slightly vary from actual delivery.

**Variants:**

**A:** Electrical connection type CANNON (bayonet connector) – not for SMG 12.1/14.1

**B:** Electrical connection type JOWO (screw-type connector, welded and sealed) – not for SGM 12.1/14.1

| <b>Ref. no.</b> | <b>Designation</b>          | <b>Type</b>  |
|-----------------|-----------------------------|--------------|
| 545.0-1         | Protective cap with cord    | Sub-assembly |
| 545.0-2         | Protective cap without cord | Sub-assembly |
| 545.0-3         | Mating plug                 | Sub-assembly |