

GST 10.1 - GST 16.1

Spare parts list Multi-turn gearboxes

Please state device type and our order number (see name plate) when ordering spare parts. Only original AUMA spare parts should be used. Failure to use original spare parts voids the warranty and exempts AUMA from any liability. Representation of spare parts may slightly vary from actual delivery.

auma®

| Ref. no. | Designation | Туре |
|----------|---|--------------|
| 001.0 | Housing | Sub-assembly |
| 002.0 | Bearing flange | Sub-assembly |
| 003.0 | Hollow shaft | Sub-assembly |
| 004.0 | Intermediate stage | Sub-assembly |
| 004.1 | Intermediate wheel | Sub-assembly |
| 005.0 | Input shaft | Sub-assembly |
| 010.0–1 | Bearing cover for second shaft end | Sub-assembly |
| 010.0–2 | Protection cover for second shaft end | Sub-assembly |
| 010.0–3 | Bearing cover | Sub-assembly |
| 511.0 | Threaded plug | Sub-assembly |
| 512.0 | Input mounting flange | Sub-assembly |
| 514.0 | Output drive type A (without stem nut) | Sub-assembly |
| 514.1 | Axial needle roller bearing | Sub-assembly |
| 516.0 | Output drive type D | Sub-assembly |
| 516.1 | Output drive shaft D | |
| 535.1 | Snap ring | |
| 539.0 | Screw plug | Sub-assembly |
| 549.0 | Output drive type B3/E/B4 | Sub-assembly |
| 549.1 | Output drive sleeve B3/E/B4 | |
| 551.1 | Parallel key | |
| 568.1 | Stem protection tube (without cap) | |
| 568.2 | Protective cap for stem protection tube | |
| 568.3 | V-seal | |
| 568.4 | Threaded sleeve | |
| 575.1 | Stem nut for output drive type A | |
| 595.0 | Screw kit for manual gearbox | Sub-assembly |
| 620.1 | Eyebolt (available as of GST 16.1) | |
| S1 | Seal kit | Set |

We reserve the right to alter data according to improvements made. Previous documents become invalid with the issue of this document. For further information on the product, refer to www.auma.com.